



Finalizing a disc enables the disc to be played on any other compatible machine. By doing this it changes the disc format so that you can no longer record to it turning it into a Play Only disc.

1. When you have finished the initial recording stop the disc and press the <FUNCTIONS> button. *See below.*




(DMR-ES10 & ES30)



OR (DMR-EH50 & EH60)

2. Using the <▲, ▼, ◀, ▶> keypad select “To Others” and <ENTER>.

3. Scroll down ▲, ▼, ◀, ▶ to “DISC MANAGEMENT” and <ENTER>.




4. When the disc management screen opens you need to use the <▲, ▼, ◀, ▶> and scroll down to **FINALIZE** and press <ENTER>.

5. Using the <▲, ▼, ◀, ▶> select **YES** and press <ENTER>.



6. Using the <▲, ▼, ◀, ▶> select **START** to begin finalizing the disc, please note by pressing start here you will no longer be able to record or edit the disc being finalized.



Finalizing may take up to 15 minutes

Do not disconnect the mains power in this time. A message appears when finalizing is finished, press the enter button when this appears. It will now play on other compatible machines.