

Philips  
CD Soundmachine with  
Dynamic Bass Boost

MP3

AZ3830



## Rip CD and enjoy USB Direct

Simply slide your CD into the motorized CD tray and let the stylishly compact AZ3830 rip and store your music in your USB device or MP3 player. Enjoy powerful sound thanks to 2x4W RMS power.

### Build your own digital music collections

- Rip your favorite CDs to MP3
- Enjoy MP3/WMA music directly from your portable USB devices
- 10 hours of MP3-CD or 20 hours of WMA-CD music

### Powerful sound you can hear and feel

- Bass Reflex speakers deliver a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic sound
- Total power 2x4W RMS

### Easy to use

- One-touch MP3 digital recording - no computer needed
- Motorized CD loader for convenience access
- FM/MW digital tuner with 25 presets

**PHILIPS**

sense and simplicity

## Specifications

### Audio Playback

- **Loader Type:** Motorised, Tray
- **Playback Media:** WMA-CD, MP3-CD, CD, CD-R, CD-RW
- **Disc Playback Modes:** Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- **Programmable Tracks:** 20

### Sound

- **Output power (RMS):** 2x4 W
- **Sound System:** Stereo
- **Loudspeaker types:** Bass Reflex Speaker System
- **Sound Enhancement:** Dynamic Bass Boost
- **Speaker diameter:** 3"
- **Volume Control:** rotary

### Tuner/Reception/Transmission

- **Tuner Bands:** FM, MW
- Auto digital tuning
- **Antenna:** FM Antenna

### Connectivity

- **USB:** USB host

- Aux in
- **Headphone:** 3.5 mm

### Convenience

- **Display Type:** LCD
- Backlight
- **Remote Control:** Multi-functional

### Power

- Mains power
- **Battery type:** LR20
- **Battery voltage:** 1.5 V
- **Number of batteries:** 6

### Accessories

- **Included Accessories:** AC Power Cord, User Manual, Warranty certificate

### Dimensions

- **Packaging dimensions (W x H x D):** 410 x 187 x 307 mm
- **Product dimensions (W x H x D):** 358.4 x 140.6 x 260 mm
- **Weight:** 2.22 kg
- **Weight incl. Packaging:** 3.15 kg

## Product highlights

### USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

### Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

### One-touch MP3 recording

Simply plug in your USB mass storage device to the USB port on Philips audio system and start recording your favorite music from CDs to your USB device or MP3 player - with one touch operation and no computer needed.

### Motorized CD loader



Issue date 2008-07-05

Version: 1.0.3

12 NC: 8670 000 29791  
EAN: 87 12581 33345 4

© 2008 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)