

Philips  
Portable MP3-CD Player



EXP2540



## Enjoy skip-free MP3 music

Get into your groove with the eXp2540 MP3-CD players and enjoy 10 hours of skip-free music on one MP3-CD. A classic favourite, it comes with LCD display and is a great choice for easy and hassle-free music enjoyment on the go

### Play your CDs and MP3-CDs

- Enjoy over 10 hours of music on one MP3-CD
- Plays CD, CD-R and CD-RW discs

### Jogproof

- 100-second Magic ESP™

### Enhanced bass performance

- Dynamic Bass Boost for deep and dramatic sound

**PHILIPS**  
sense and simplicity

## Specifications

### Sound

- **D/A converter:** 1-bit
- **Frequency response:** 20 - 20 000 Hz
- **Signal to noise ratio:** > 85dB
- **Sound Enhancement:** Dynamic Bass Boost
- **Output Power:** 2 x 4mW RMS
- **Volume Control:** digital

### Audio Playback

- **Playback Media:** MP3-CD, CD, CD-R, CD-RW
- **Disc Playback Modes:** Hold, Next/Previous Album Search, Next/Previous Track Search, Repeat Play, Shuffle Play
- **Electronic Skip Protection(CD):** 45 seconds
- **Magic ESP (MP3-CD):** 100 seconds
- **MP3 bit rates:** 32 - 320 kbps
- **File systems supported:** ISO-9660, Joliet

### Connectivity

- **DC in:** 4.0 mm, 4.5V, centre +
- **Headphone:** 3.5 mm

### Convenience

- **Display Type:** LCD
- **Indications:** album number, battery status, Cd functions, DBB, ESP, time, track

### Accessories

- **Headphones:** AY3806 earphones
- **Included Accessories:** User Manual

### Dimensions

- **Master carton dimensions:** 261 x 244 x 348 mm
- **Master carton weight:** 2.39 kg
- **Master carton quantity:** 5
- **Packaging dimensions (W x H x D):** 208 x 309 x 60 mm
- **Packaging type:** Clamshell
- **Product dimensions (WxDxH):** 140x140x27.5mm
- **Product weight:** 0.38 kg

### Power

- **Battery Playing Time MP3-CD:** 30
- **Battery Playing Time CD:** 20
- **Battery type:** AA, LR6, UM3

## Product highlights

### Dynamic Bass Boost

*Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.*



Issue date 2008-11-15

Version: 2.0.11

12 NC: 9073 101 02755  
EAN: 87 10895 97697 8

© 2008 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)