

Philips
Flash audio player

IGB*

SA1210















Wear it and flaunt it

Enjoy your MP3 and WMA music on the go with the Philips IGB* SA1210. Speedily transfer music and data via direct USB2.0. Enjoy your music your way with 4 equalizer presets and listen to music all day long on an AAA battery.

Your music, your data - on the go, everyday

- Enjoy MP3 and WMA playback
- Fast downloads from your PC via USB2.0
- · Make voice recordings

Ready to wear, Ready to go

- Enjoy up to 8-hour music playback
- Small and wearable goes where you go
- · USB mass storage to store and carry your data files

Easy, intuitive music experience

- Backlit LCD display
- Equaliser for optimised sound to suit your music style
- Folder Browsing to find your music fast



Specifications

Picture/Display

- Type: LCD
- Resolution: 32 x 128
- Lines of text: 2
- **Backlight**
- · Backlight colour: Green

Sound

- Equalizer settings: Classic, Jazz, Pop, Rock
- Channel separation: 45 dB
- Frequency response: 30 18 000 Hz Hz
- Output power (RMS): 2 x 4 mW
- Signal to noise ratio: > 85 dB

Audio Playback

- Compression format: MP3, WAV, Windows Media™ Audio
- ID3 Tag support: Track title and artist name
- MP3 bit rates: 8-320 kbps and VBR
- MP3 sample rates: 8, 11.025, 16, 22.050, 24, 32, 44.1, 48 kHz
- WMA bit rates: 5-192 kbps
- WMA sample rates: 8, 11.025, 16, 22.050, 32, 44.1, 48 kHz

Audio Capturing

- Built-in microphone: mono
- Voice recording: ADPCM
- · Audio file format: WAV

Storage Media

- Built-in Memory Capacity: I GB
- Built-in memory type: NAND Flash
- Music memory capacity, WMA: Up to 500 tracks (64 kbps)*
- · Mass storage class compliant

Connectivity

- Headphone: 3.5 mm
- USB: Full speed USB 2.0

- Firmware upgradeable
- · Function: Keypad lock

Accessories

- Headphones: AY3809
- Batteries: AAA Alkaline
- User Guide on CD-ROM
- USB cable: USB extension cable

Software

• Device manager: Firmware Manager to restore and upgrade

Green Specifications

Lead-free soldered product

System Requirements

- USB: Free USB port
- PC OS: 98SE, ME, 2000, XP
- CD-ROM drive
- Internet connection: Yes (for access to updated support documents, manuals, future firmware and PC software upgrades)

Dimensions

- Blister dimensions (WxDxH): 135 x 38 x 195 mm
- Product dimensions (WxDxH): 28.5 x 22.1 x 83
- Product weight: 0.030 kg
- Packaging type: Clamshell

Power

- Batteries included
- Battery type: AAA / LR03 Alkaline
- · Playtime on external battery: Up to 8 hours

Convenience

- Printed User Guide: English, French, German, Spanish, Dutch, Italian

Folder Browsing

from the device.

Product highlights USB mass storage device

You have a lot of music on your player and you want to find the right song, fast. Folder Browsing is a quick shortcut to finding and playing your music. Organise your music into folders on your PC. Give the folders any name you like, you might use the artist's or album's name. Then drag and drop the folders to your device in Windows Explorer. When you're listening to your player, you can zoom to the songs by holding the next or previous key to see folder names scrolling across one by one. Release the button when you see the folder you're looking for and the first song will start to play.

USB mass storage devices offer a convenient way to save,

backup and move your files around. The devices connect

automatically shows up as a removable drive in Windows

Explorer allowing you to simply drag and drop files to and

to your computer using a USB connection and do not

require any special software to be installed (only

Windows 98 and Me need drivers). The device



Issue date 2007-11-25

Version: 2.0

© 2007 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9073 101 02762 EAN: 87 10895 97796 8

www.philips.com