PHILIPS

PHILIPS

PRIME

Philips Micro Hi-Fi System

MCM204















The new classic

with USB Direct playback

Specifically designed for those who truly appreciate the ultimate in style and technology, Philips MCM204 exudes finesse and quality. Enjoy MP3/WMA music from your portable player with USB Direct playback.

Enrich your sound experience

- Enjoy MP3/WMA music directly from your portable USB devices
- Play MP3/WMA-CD, CD and CD-RW
- Autostop stereo cassette deck
- Digital Sound Control for optimized music style settings
- · Dynamic Bass Boost for deep and dramatic sound
- Total power 2x4W RMS

Start the day your way

- Wake-Up and Sleep Timer
- Digital tuning with 40 preset stations for extra convenience

Refined in sound and look

- Elegant wood-finished speakers
- · Easy-to-use remote control included



Specifications

Sound

- Output Power: 2x4W RMS / 350W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

 Main Speaker: 3.5" woofer, Bass Reflex Speaker System

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 20-Track Programmable
- Loader Type: Top
- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Electronic Speed Control
- USB Direct Modes: Play/Pause, Stop, Previous/ Next, Fast Backward/Fast Forward, Program Play, Repeat, Shuffle

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: Automatic Recording Level, CD Synchro Start Recording

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

Connectivity

- Other connections: FM fixed pigtail antenna, MW Antenna
- Aux in: Line-in, 3.5mm
- · Headphone: 3.5 mm

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- · Clock: On main display
- Display Type: LCD

Accessories

- Included Accessories: FM/MW Antenna, Guarantee booklet, Quick Use Guide
- Remote control: 24-key remote with Lithium battery
- Quick start guide: English, Traditional Chinese
- User Manual: English, Traditional Chinese

Dimensions

- Set dimensions (W x H x D): 146 x 228 x 216 mm
- Main speaker dimensions (W x H x D): 146 x 228 x 160 mm
- Packaging dimensions (W x H x D): 380 x 350 x 275 mm
- Weight incl. Packaging: 5.3 kg

Power

• Power supply: 110-240V, 50/60 Hz

Product highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high — at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2008-07-03

Version: 2.0.I

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 34632 EAN: 87 12581 37079 4

www.philips.com