

KAMBROOK

Frost Factory



Kambrook Safety

Welcome to Kambrook and your new Frost Factory. At Kambrook we believe that the safe performance is the first priority in any consumer product so that you, our valued customer, can confidently use and trust our appliances. We ask that any electrical appliance that you use be operated in a sensible fashion with due care and attention placed on the following important operating instructions:

IMPORTANT SAFEGUARDS FOR YOUR KAMBROOK FROST FACTORY

Carefully read all instructions before operating the appliance and save for future reference.

Remove any packaging material and promotional stickers before using the appliance for the first time.

Do not place the appliance near the edge of a bench or table during operation. Ensure the surface is level, clean and free of water, etc.

Do not place this appliance on or near a hot gas or electric burner, or where it could touch a heated oven.

Handle the Ice chamber with care – remember the blade assembly is very sharp and should be kept out of reach of children.

Do not use attachments other than those provided with the Frost Factory.

Do not attempt to operate the Frost Factory by any method other than those described in this booklet.

Do not operate the appliance with a heavy load.

Do not run the motor without ice in the ice chamber.

Always ensure the Frost Factory is switched off at the power outlet and the cord is unplugged from the power outlet. Particularly when not in use, if left unattended and when cleaning or storing.

Do not use the Frost Factory on metal surfaces, for example, a sink drain board.

Do not use ice cubes made from ice cube trays, automatic ice makers, bagged ice etc. Only use the ice made from the freezer containers supplied with this appliance.

Do not continuously run the motor for more than 6 minutes at a time and rest the appliance for 20 minutes before the next operation.

To protect against electric shock do not immerse the power cord, plug or motor housing in water or any other liquid.

Do not move the Frost Factory whilst in operation.

Keep the appliance clean. Follow the cleaning instructions provided in this book.

IMPORTANT SAFEGUARDS FOR ALL ELECTRICAL APPLIANCES

Unwind the cord before use.

Do not let the cord hang over the edge of a table or counter, touch hot surfaces or become knotted.

This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely. Young children should be supervised to ensure that they do not play with the appliance.

It is recommended to regularly inspect the appliance. Do not use the appliance if power supply cord, plug or appliance becomes damaged in any way. Return the entire appliance to the nearest authorised Kambrook Service Centre for examination and/or repair.

Any maintenance other than cleaning should be performed at an authorised Kambrook Service Centre.

This appliance is for household use only. Do not use this appliance for anything other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors.

The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.

KNOW YOUR KAMBROOK FROST FACTORY



1. Motor body

2. Ice chamber with shaving blade

3. Base

4. Freezer containers x 4

5. Push button to shave ice

Before first use

Remove all packaging material and promotional labels. Wash the ice chamber and base in warm, soapy water; rinse and dry thoroughly.

Wipe the motor body with a damp cloth.

Assembling/Operating the Frost Factory

Place water in the freezer container leaving 1cm from the top to place the lid on. Then place the container in the freezer for 24 hours.

Place the motor body on a flat, dry surface. Ensure the power plug is unplugged from the power outlet.

Place a deep bowl or container onto the base platform to hold shaved ice.

Place the ice chamber into the base by lining up the flat sides and pushing the chamber down.

Once the water in the freezer container has set and formed into ice, remove the freezer container from the freezer.

Remove the block of ice from the freezer container.

Place the ice in the ice chamber.

Place the motor body on top of the ice chamber. Plug the cord into a 230/240v power outlet and switch on at the power outlet.

Push the top of the motor housing to start shaving. Release the motor housing to stop shaving.

When ice shaving is complete, unplug the Frost Factory and clean. Please see *Disassembling/Cleaning your Frost Factory* for directions.

NOTE! Please handle the ice chamber carefully as the shaving blade is sharp. Mis-handling of the blade may cause injury.

Tips for the best use of your Kambrook Frost Factory

Do

Ensure all removable parts have been thoroughly washed and dried before assembly (except motor body).

Ensure the Frost Factory is correctly assembled before operating.

Ensure the Frost Factory is used on a clean, dry surface.

Don't

Do not use ice cubes in the ice chamber.

Do not use the ice chamber to store ice.

Do not immerse the motor body, cord or power plug in water or any other liquid.

Do not use harsh abrasives or cleaners.

Do not place any of the removable parts in the dishwasher.

Cleaning your Frost Factory

Ensure the Frost Factory has been unplugged from the power outlet.

Remove the bowl of shaved ice from the base platform.

Remove the motor body by lifting it in an upward position. Do not immerse in water.

Carefully remove the ice chamber by lifting it in an upward position.

Some small ice pieces may remain in the ice chamber; simply run the ice chamber under warm water so that all excess ice dissolves.

If extra cleaning is necessary, wash with warm soapy water and dry thoroughly with a clean cloth.

Do not use harsh abrasives or cleaners.

Dry all parts thoroughly.

⚠ Warning! Ice cubes must not be used in the ice chamber. Only use the ice which is formed in the freezer container.

NOTE! Do not place any of the removable parts in the dishwasher.

NOTE! Do not immerse the motor base, cord or power plug in water or any other liquid.

Cleaning the Motor Body

The Motor body can be cleaned with a soft, damp cloth (do not use abrasive agents or cloths which can damage the surface). Dry and polish with a soft, lint-free cloth.

Storage

Before storing, thoroughly wash and dry all removable parts.

Assemble the Frost Factory and store on the kitchen bench or in an easy to access cupboard.

Store out of reach of children.

Store the appliance upright.

Do not store anything on top of the appliance.

RECIPES:

FOR KIDS

Juicy treats

Add your favourite juice such as orange, apple, pineapple or tropical to the shaved ice.

Cordial treats

Add your favourite cordial to shaved ice and enjoy the icy treat. You can also add the cordial to the water before it is frozen to create a coloured snow effect.

Soft drink flavourings:

Use soft drinks to enjoy a different delicious icy flavour.

FOR ADULTS

Margarita

30ml Tequila

15ml fresh lime juice

30ml Triple sec or Cointreau

Shaved ice

Place all ingredients except ice into cocktail shaker and shake it well. Place shaved ice into glass with a salted rim. Pour cocktail mixture over the shaved ice and serve garnished with a lime slice.

Pina Colada

60ml pineapple juice

30ml coconut cream

30ml dark rum

Shaved ice

Place all ingredients except ice into cocktail shaker and shake it well. Place shaved ice into glass. Pour cocktail mixture over the shaved ice and serve garnished with pineapple leaves.

Fluffy duck

15ml white rum

15ml advocaat

60ml orange juice

15ml cream

Shaved ice

Place all ingredients except ice into cocktail shaker and shake it well. Place shaved ice into glass. Pour cocktail mixture over the shaved ice and serve garnished with a twisted orange slice.

Splice

30ml Midori

30ml Malibu

60ml pineapple juice

40ml cream

Shaved ice

Place all ingredients except ice into cocktail shaker and shake it well. Place shaved ice into glass. Pour cocktail mixture over the shaved ice and serve garnished with a slice of pineapple and a cocktail cherry.

Tip! Always refill the empty freezer containers with water and place in freezer, ready for next use.

Notes

Notes

Notes



Kambrook 12 Month Replacement Warranty

KAMBROOK warrants the purchaser against defects in workmanship and material, for a period of 12 months from the date of purchase (3 months commercial use).

Guarantee and purchase receipt for this product are to be retained as proof of purchase and must be presented if making a claim under the terms of the KAMBROOK guarantee.

KAMBROOK reserves the right to replace or repair the appliance within the warranty period.

Warranty does not apply to any defect, deterioration, loss, injury or damage occasioned by, or as a result of the misuse or abuse, negligent handling or if the product has not been used in accordance with the instructions. The guarantee excludes breakages and consumable items such as kneading blades.

This warranty is void if there is evidence of the product being tampered with by unauthorised persons.

If the product includes one or a number of accessories only the defective accessory or product will be replaced.

In the event of KAMBROOK choosing to replace the appliance, the guarantee will expire at the original date, ie. 12 months from the original purchase date.

In Australia, this KAMBROOK Guarantee is additional to the conditions and guarantees which are mandatory as implied by the Trade Practices Act 1974 and State and Territory legislation.

For service, spare parts or product information in Australia, please call KAMBROOK on the customer Service Line (free call) 1800 800 634.

For service, spare parts or product information in New Zealand, please call KAMBROOK New Zealand, Greenmount, Auckland Phone 09 271 3980 Fax 0800 288 513. For spare parts phone 09 271 3980.

If claiming under this guarantee the product must be returned to freight prepaid.

YOUR PURCHASE RECORD (Please complete)

Attach a copy of purchase receipt here.

DATE OF PURCHASE _____

MODEL NUMBER _____

SERIAL NUMBER (If applicable) _____

PURCHASED FROM _____

Please don't return purchase record until you are making a claim

KAMBROOK

Kambrook 461 Plummer Street, Port Melbourne 3207, Australia
Customer Service Line (free call) 1800 800 634 Customer Service Fax 1800 621 337
Kambrook New Zealand, Private Bag 94411, Greenmount, Auckland, New Zealand
Customer Service Line/Spare Parts 09 271 3980 Customer Service Fax 0800 288 513

