
Installation Instructions Flashguard LED Flasher Module To Flashguard Xtra

- 1. Straighten the two LEDs by gently bending them in to the upright position.
- 2. Peel the backing off the adhesive mounting brackets provided and attach them to the inside of the cover as shown below.




- 3. Connect the unit to a suitable 12V supply, observing polarity. The two LEDs will now flash alternately.
- 4. Slot the PCB into the mounting brackets with the LEDs pointing towards the lens. Bend the LEDs into position if required.
- 5. Fix the unit to the wall in the same way as an ordinary simulated unit.





Installation Instructions Flashguard LED Flasher Module To Flashguard XL PLus

- 1. Straighten the two LEDs by gently bending them in to the the upright position.
- Fix the board to the cut-out inside the cover using the self-ashesive pads provided. Screws can be used if desired.
- Connect the unit to a suitable 12V supply, observing polarity. The two LEDs will now flash alternately.
- Fix the unit to the wall in the same way as an ordinary simulated unit.



Part No. 102325

