

Contact BlueAnt:

Nth America

support@myblueant.com
1 866 891-3032

Australia

support@blueant.com.au
1300 669 049

New Zealand

support@blueant.com.au
0800 443 122

United Kingdom

UKsupport@myblueant.com
0844 477 2996

LED Indicator Chart

Power ON	Solid Blue for 5 Seconds
Power OFF	Red flash 3 times
Pairing Mode	Blue flashing
Reset	Blue flashing
Charging	Solid Red
Charging with Power ON	Solid Red with a Purple Flash
Charging Complete	Red indicator OFF
Low Battery	All LED's change to Red
Idle	Blue flash every 8 seconds
Standby	2 Blue flashes every 5 seconds
Ongoing call	NO LED's

QUICK START GUIDE



BlueAnt®



Z9 DUAL MIC
BLUETOOTH HEADSET
with Voice Isolation Technology®

Keep this in your wallet for quick reference

PAIRING


Before use, you must pair the headset with your cell phone. Pairing will create a stored connection in the Z9 and your Bluetooth cell phone. Pairing has to be done only once, when first connecting to a phone. The Z9 can store pairing information for three (3) different Bluetooth devices.

Pairing Procedure - This is an example procedure only.

These steps may differ from phone to phone, but the process will be the same.

1. First turn the phone OFF and then back ON again to refresh its memory.
2. Bring the mobile phone to about 30cm from the Z9 Dual Microphone.
3. Find the Bluetooth menu in your mobile phone. Turn Bluetooth ON. (Check your mobile phone user guide)
4. With the Z9 OFF, Press and Hold the MFB for about 6 seconds until the LED flashes Blue.
5. Your headset is now ready to be discovered by your Bluetooth mobile phone.
6. Perform Bluetooth a device discovery on your mobile phone to add a new device. It takes a few seconds to search for and find other Bluetooth devices around you.
7. When Bluetooth devices are found, the phone will display "BlueAnt Z9". Scroll to it and press OK to confirm that you want to pair with it.
8. Enter the Passkey "0000" when your phone prompts you. The phone will now pair with the BlueAnt Z9.
9. If your Bluetooth phone menu supports it "set as authorized" or "add to trusted devices"
10. Again select the BlueAnt Z9 to connect with it. OR, Press the MFB to connect with the phone.

BUTTON FUNCTION MATRIX



Note:

Standby Mode means connected to a device but not on a call.

Idle Mode means the Z9 is ON but not connected to any device

Multiple button presses mean click together

Z9 Function	Button	Time	Status
Power ON	MFB	3 Seconds	From OFF
Power OFF	MFB	3 Seconds	Idle/Standby
Enter Pairing Mode	MFB	6 Seconds	From OFF
Connect to Device 1	MFB	One Click	Idle
Connect to Device 2	MFB	Two Clicks	Idle
Connect to Device 3	MFB	Three Clicks	Idle
Answer Call	MFB	Click	Ringing
End Call	MFB	3 Seconds	Active Call
Reject Call	MFB	3 Seconds	Ringing
Redial Last Number	VOL	3 Seconds	Standby
Voice Dial Activate	MFB	Click	Standby
Disconnect/Transfer	&	Click	Connected
Call Conference	VOL	3 Seconds	Active Call
Call Waiting	&	3 seconds	Active Call
Volume Up	VOL	Click	Active Call
Volume Down	VOL	Click	Active Call
Mute	VOL	3 Seconds	Active Call
Turn LED's OFF	and	3 Seconds	Idle/Standby
Switch Voice Isolation between Standard and Max	MFB	Click	Active Call
Reset Device	MFB & &	Click	Idle