

#### motorola **H680**

#### **Quick Start Guide**

### **OU BEGIN**

#### I Legal Information pamphlet and follow its instructions.

niliarize yourself with your new H680 our headset, a charger case is provided for



# START HERE >

### **BEFORE Y**(

Before using this product, read the Important Safety and

Take a moment before you get started to fan Bluetooth Handsfree Headset. Along with yc both charging and storage.



## CHARGE

#### Your Headset's Battery

Important: Your headset must be turned off when charging. If you turned the headset on, see "Turning Headset On and Off" on reverse side for details on turning headset off.

- 1 Plug the Motorola charger into the port on the charger case.
- 2 Place headset into charger case ensuring that charging contacts on the headset and charging case connect.



The indicator light turns red when the battery is charging. It may take up to 1 minute for the indicator light to turn on. When the headset's battery is fully charged (about 2.5 hours), the indicator light turns off.

**3** Disconnect the charger. Note: Headset is not functional while charging



#### START BLUETOOTH **FEATURE**

#### **Your Phone**

Your phone's Bluetooth feature is off by default. To use your headset, you must turn on the Bluetooth feature in your phone.

For most Motorola phones (at the main menu):

- 1 Press (Menu) > Settings > Connection > Bluetooth Link > Setup.
- 2 Scroll to Power.
- 3 Select Change.
- Scroll to **On**.
- 5 Press **Select** to turn on the Bluetooth feature. The Bluetooth feature remains on until you turn the feature off.

Note: These steps are for most Motorola phones. For other phones, see your phone's user's guide.

Motorola, Inc. Consumer Advocacy Office 1307 East Algonquin Road Schaumburg, IL 60196

www.hellomoto.com 1-877-MOTOBLU 1-888-390-6456 (TTY/TDD United States for hearing impaired)

Guide Number: 6809510A87-0

Bluetooth ID: B012842

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. All other product or service names are the property of their respective owners



Before you can use your headset, you must pair (link) it with your phone.

PAIR

Your Headset

#### **Step A - ENSURE HEADSET IS IN PAIRING** MODE

Remove headset from charging base and power on by sliding Power switch to the On position (towards Power symbol on headset). The indicator light flashes to initiate easy pairing. After a few moments, the indicator light will be steadily lit in blue to indicate headset is in pairing mode.



Indicator Light (steadily blue for pairing mode)

If the headset does not enter pairing mode, see **TROUBLESHOOTING** for help.



PAIR CONTINUED **Your Phone** 

#### Step B - SET YOUR PHONE TO LOOK FOR YOUR HEADSET

For most Motorola phones:

1 On your Motorola phone, press 🔳 (Menu) > Settings > Connection > Bluetooth Link > Handsfree > Look for Devices.

The phone lists Bluetooth devices it finds.

- 2 Select Motorola H680.
- **3** Select **OK** or **Yes** to pair your headset with your phone.
- 4 Enter the passkey: 0000
- 5 Select OK.

When your headset successfully pairs and connects with your phone, the indicator light changes from steadily lit to flashing blue.

Note: These steps are for most Motorola phones. For other phones, see your phone's user's guide.



### **TEST AND USE**

Your phone and headset are now paired and ready to make and receive calls.

To make a call:

- Place the headset over your ear. See "Wearing the Headset" on the reverse side of this guide.
- 2 On the phone, dial the number you want to call and press **SEND** key on your phone.

If your phone and headset are successfully paired, you will hear ringing on the headset.

After you have successfully paired your phone and headset, you don't need to repeat these steps. For daily use, ensure that your headset is turned ON and that your phone's Bluetooth feature is ON.

### **USING YOUR H680**

See

Features and Functions Guide on the reverse side for information on using your H680



### TROUBLES

#### My headset will not charge.

Make sure your headset is turned off when charging. Your headset will not charge in the charger case while powered on.

#### My headset will not enter pairing mode.

Make sure that any devices previously paired with the headset are turned off. If the indicator light is not steadily lit in blue, turn off both the other device and headset, wait 10 seconds, then turn headset back on. Wait for the indicator light to become steadily lit in blue, indicating the headset is now in pairing mode.

#### My phone doesn't find my headset.

Make sure the indicator light on your headset is on (lit in blue) and steady when your phone is searching for devices (see step 3).

### HOOTING

## My headset worked before but now it's not working.

Make sure your phone is on and the Bluetooth feature is turned on in your phone (see step 2). If the Bluetooth feature was turned off or was turned on only temporarily, you may need to restart the Bluetooth feature (see step 2) and pair your phone and headset again (see step 3).

#### Support.


If you need more help, contact us at **1-877-MOTOBLU** or visit us at www.hellomoto.com/Bluetoothsupport

# Features and Functions Guide

IMPORTANT: Be sure to first follow the **Quick Start Guide** on the reverse side of this guide to complete initial setup of your H680.

### EARBUDS AND YOUR HEADSET

Your H680 headset is supplied with multiple earbuds. The earbud is fitted onto the end of your headset's earpiece speaker, and placed onto your ear when using your headset.




Your headset's performance is greatly dependent upon achieving a good fit on your ear. Therefore, we recommend trying all the supplied earbuds with your headset.

### TURNING HEADSET ON AND OFF


**To turn your headset on**, slide the Power switch on (towards Power symbol on headset). The indicator light is steadily purple for several seconds, then flashes blue (if paired and connected with another device) or is steadily blue (if ready to be paired).

To turn your headset off, slide the Power switch off. The indicator light will turn off.



### WEARING THE HEADSET

To wear your headset, flex the earhook and loop it over your ear as shown.



Be sure to position the ear bud into your ear canal for optimal audio performance and comfort.

### CHANGING FOR USE ON OTHER EAR

You can wear your H680 headset on your left or right ear. The headset comes ready for the right ear. To change the headset for the left ear:

1 Gently lift and pull the top of the earhook up and off speaker stem as shown.



- 2 Flip the headset over.
- **3** Attach the earhook to the speaker stem as shown.



#### STORING YOUR HEADSET

The charger case provided is used to charge and store your headset. When not using your headset, you should place it in the charger base. Be sure to turn the headset off before placing it into the charger case.

As shown, the charger cover can be placed on top of the charger case, or underneath it to provide support for desktop placement.



#### European Union Directives Conformance Statement



Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC.
- All other relevant EU Directives.



The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at www.motorola.com/rtte. To find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the web site.

### **MAKING CALLS**

Function	Action	
Receive a call	Tap the Call button	
Mute or unmute a call	Tap both Volume buttons	
Reject a call	Press and hold a Volume button until you hear two descending tones	
End a call	Tap the Call button	
Redial last call	Press and hold the Call button until you hear two ascending tones	
Make a voice dial call	Tap the Call button and speak the name after the tone	

Note: Your H680 supports both Handsfree and Headset Profiles. Accessing call functions depends upon which profile your phone supports. See your phone's user's guide for more information.

### MAKING CALLS CONTINUED

Function	Action
Answer a second incoming call	Tap the Call button
Disable the indicator light	First slide the switch toward charging plug (to turn headset off), then press and hold both Volume buttons AND slide the switch towards the microphone (to turn headset on)

Note: Some features are phone/network dependent.

# **INDICATOR LIGHTS**

With the Charger Plugged In

Headset Indicator	Headset Status
Steady red	Charging
Off	Charging complete

#### With No Charger Plugged In

Headset Status
Power off
Powering up
Pairing/connection mode
Connection successful
Standby (not on call)
Incoming call
Connected (on a call)
Connected (on a muted call)
Idle (not connected)
Low battery

Note: After 30 minutes of inactivity, the light stops flashing to conserve power, but the headset remains in standby mode.

### **AUDIO TONES**

Audio Tone	Headset Status
Ring tone	Incoming call
Single high tone	Phone network not available
High to low tone	End call
Single high tone when pressing volume button	Volume at minimum or maximum
Two ascending tones	Mute enabled
Two descending tones	Mute disabled
Low to high tone	Connection confirmation/voice activation
No audio indications; deteriorating quality	Out of range
Two tones repeated every 30 sec.	Low battery

