



vxii
blueparrott
BLUEPARROTT B200
Controls & Components



The headset battery charges continuously while the headset is in the base.



Installation A

For phones *without* headset ports



1. Remove handset cord from phone's base.
2. Plug short end of T-cord into now empty handset port on phone.
3. Plug longer end of T-cord into port on B200 base marked "Phone". Thread cord under hook.
4. Plug handset cord into port on T-cord.
5. Plug AC adapter into port on B200 base marked and then plug AC adapter into the wall electrical outlet.

Installation B

For phones *with* headset ports (Cisco phones see Installation C)



1. Leave handset plugged into your phone.
2. Plug short end of T-cord into headset port on phone.
3. Plug longer end of T-cord into port on B200 base marked "Phone". Thread cord under hook.
4. Plug AC adapter into port on B200 base marked and then plug AC adapter into the wall electrical outlet.

Installation C

For Cisco models 7940 or higher with a headset port




1. Leave handset plugged into your phone.
2. Plug the blue-banded end of the patch cord into the headset port on your phone.
3. Plug other end of the patch cord into port on the B200 base marked "Phone". Thread cord under hook.
4. Plug AC adapter into port on B200 base marked and then plug AC adapter into the wall electrical outlet.

BASIC OPERATION

Charge headset in base for 4 hours before first use. The multifunction button on the headset will turn green when fully charged. After use, this light will turn red. It is not necessary for the light to turn green to use the headset.

Microphone Adjustment: To ensure proper microphone performance, do the following.

1. The microphone has the word TALK or a dot printed or embossed on it (under the cushion). This mark must face your mouth.





2. For quality sound and effective background noise cancellation, position microphone a finger's width away from your face just below your bottom lip. The microphone is sensitive, minor adjustments may be needed to achieve optimum voice quality.

Standby/Talk Time Modes: The headset is in standby mode whenever you see a slow-flashing yellow light on the headset *and* the handset icon is lit on the front of the base. If the headset icon is lit, then the headset is active and Talk Time is being used (even if you are not on a call).




Make/End A Call (If yellow light is not flashing on the headset turn headset on - see User Guide pg 14)

1. Put the headset on and position the microphone properly.
2. Put the headset in Talk Time mode*: Firmly press and release the multifunction button on the headset for 1 second. The headset icon  will light up on the right side of the base (This may take 1-5 seconds).
3. Activate your phone by removing the handset from the cradle or by pressing the line or headset button. If the dial tone is too loud when you activate your phone, you can press the volume decrease button 1-3 times before activating the headset. Dial as usual.
4. To end the call, place the handset back in cradle, or press the line or headset button on the phone to end the call.
5. To end Talk Time, press the multifunction button for 1 second. The handset icon  will light up on the base within 1-5 seconds.


* If the headset icon is already showing on the front of the base, then the headset is already in Talk Time mode and you may proceed to step 3.

Adjust the Microphone Volume



The Microphone Volume Adjustment is located on the bottom of the B200 base . If the person on the other end of the call is having trouble hearing you, position the base as shown, and with a paperclip inserted in the slot of the knob, turn the knob clockwise to increase the volume. If they say your voice is too loud, turn the knob counterclockwise to decrease volume.

Answer/End A Call (If yellow light is not flashing on headset turn headset on - see User Guide pg 14)

1. Put the headset on and position the microphone properly.
 2. Put the headset in Talk Time mode*: Firmly press the multifunction button on headset for 1 second, then release. The headset icon  will light up on the right, front side of the base.
- * If the headset icon is already showing on the front of the base, then the headset is already in Talk Time mode and you may proceed to step 3.
3. Remove handset from cradle or press the line or headset button to be connected to the call.

4. To end the call, place the handset back in cradle, or press the line or headset button on the phone to end the call. Press multifunction button for 1 second to end Talk Time. The handset icon should will light up on the base within 1-5 seconds.

Adjust Speaker Volume

To adjust the volume in your earpiece, press the increase or decrease volume button for 1 second, then release. Repeat until volume is at desired level.

VISUAL AND AUDIO INDICATORS EXPLAINED

Headset Indicator Lights (While In Base)		Headset Indicator Lights (While Off Base)	
No lights	Headset not receiving charge	Yellow flashing every 4 sec. Yellow flashing every 1 sec.	Standby Mode Talk Time Mode
Green light	Full charge / Okay to use	Red and yellow lights flash alternately / then red stops	Pairing successful
Red light	Partial charge / Okay to use		
Headset Audio Indicators (While Off Base)		Base Unit Indicator Lights	
3 beeps that descend in tone	Headset turned off	Headset icon lit up on right, front side of base	Talk Time active. Calls will be directed to the headset.
3 beeps that ascend in tone	Headset turned on	Handset icon lit up on left, front side of base	Talk Time not active. Calls will be directed to the handset.
1 single beep	Follows press of multifunction button to activate headset. Also follows volume adjustments and mute/unmute activation	Yellow flashing every 4 sec. Yellow flashing every 1 sec.	Standby Mode Talk Time Mode
1 beep every few seconds	Headset microphone is muted	Red and yellow lights flash alternately / then red stops	Pairing successful
Multiple tones/beeps when user is not pressing buttons	Battery about to lose power (switch to handset if on a call)	No lights	Unit not receiving power



VXI A brand of VXI Corporation
 One Front Street. Rollinsford, NH 03869
 800-742-8588 | 603-742-2888
 PN201955B



B200 Wireless Headset for Office Phone Systems

