


KitchenAid®

OVEN PARTS

For Models: KEBS207SBL04, KEBS207SWH04, KEBS207SSS04
(Black) (White) (Stainless)

30" BUILT-IN ELECTRIC
DOUBLE OVEN
THERMAL CONVECTION



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: KEBS207SBL04, KEBS207SWH04, KEBS207SSS04
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	11	W10009940	Oven Light	28	8304452	Thermal Fuse 105C
	8304336	Installation			Assembly	29	W10131825	Sensor
		Instructions	12	W10169757	Bulb, Light	30	8303685	Vent, Center
	W10162180	Use & Care Guide	13	3400832	Screw (2)	31	8303516	Base, Chassis
		Tech Sheet	14	W10115861	Frame, Front	32	8304478	Retainer, Gasket
	W10220954	English	15	8304493	Gasket, Door	33	8303517	Cover, Back
	W10220955	French	16	3196176	Screw	34		Trim, Bottom Vent
	8304335	Easy Set Guide	17	4449040	Screw		8303705WH	White
		Safer Cooking Tips	18	4449154	Screw		8303705BL	Black
	9762761	English	19	4451478	Support, Insulation		W10216230	Stainless
	W10065852	French	21		Mounting Rail, Side	35	4448444	Grommet, Mounting
					Right			Rail
2	W10153090	Bracket, Base		8303677BL	Black	36	3400893	Screw
3		Hinge Receiver		8303677WH	White	37	W10169348	Bracket, Thermostat
	4455606	Right			Left			
	4455605	Left		8303678BL	Black			
4	W10105790	Bumper, Door (2)		8303678WH	White			
5	8303829	Exhaust, Vent Slope	22	W10195935	Latch, Mortorized	FOLLOWING PARTS NOT ILLUSTRATED		
6	W10181196	Divider, Center	23	4449743	Screw	INSULATION		
		Vent	24	4449748	Screw			
7	W10204470	Top Chassis	25	4455641	Side, Chassis		8303965	Insulation, Wrap
8	4449809	Screw	26	8304303	Back, Chassis		8303967	Insulation, Back
9	4452158	Tube, Vent	27		Liner, Oven			
10	W10169756	Lens, Light			(Not serviceable)			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KEBS207SBL04, KEBS207SWH04, KEBS207SSS04
(Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	8303716BL 8303716WH W10216219	Panel, Control Black White Stainless
2	8303687	Support, Appliance Manager
4	8304332	Control Panel, Glass Touch
5	W10172472	User Interface
6	8303719	Backer, Control
7	8303887	Bracket, Enclosure
8	4449154	Screw
9	3400832	Screw
10	W10119142	Appliance Manager
11	8304441	Resistor, Drop

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: KEBS207SBL04, KEBS207SWH04, KEBS207SSS04
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8303737BL	Door Liner
2	W10174285	Hinge, Door (2)
3	3196183	Screw
4	8304581BL	Vent, Door Top
5		Bracket, Door
	8304377	Right
	8304378	Left
6		Cover, Door Hinge
	W10137043	Right
	W10137044	Left
7	8303731	Glass, Inner
8	4449743	Screw
10	8304523	Seal


Illus. No.	Part No.	DESCRIPTION
11	8304360BL	Bracket, Handle
12		Door Glass, Assy
		Lower Includes #17
	8303995	White
	8303993	Black
	W10237354	Stainless
		Door Glass, Assy
		Upper No Nameplate
	8303996	White
	8303994	Black
	W10237351	Stainless

Illus. No.	Part No.	DESCRIPTION
13		Door Handle
	8303774WH	White
	8303774BL	Black
	8303774SS	Stainless
15	8303745BL	Frame-Door Side(2)
16	8303746	Door, Top Bracket
17		Badge, Lower Door
	8304603BL	Black
	8304603WH	White
	8304603SS	Stainless
18	8304522	Bumper, Glass

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KEBS207SBL04, KEBS207SWH04, KEBS207SSS04
(Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
3	8304602	Element, Broil Shield
5	8303841	Rack, Oven
6	W10208155	Oven Rack (Sliding)
7	9760768	Element, Bake
8	4455037	Tray, Bake
9	4449154	Screw
10	4450039	Cover, Bake Tray
11	4449809	Screw
12	8303962BU	Cover, Fan
13	9760769	Element Convection
14	9755543	Jack, Meat Probe
15	9755542	Probe, Meat
16	W10116351	Blade, Fan
17	W10116349	Nut
18	W10116228	Fan, Convection
19	9755547	Washer, Lock
20	9755546	Nut, Hidden

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KEBS207SBL04, KEBS207SWH04, KEBS207SSS04
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9752759	Relay (2)
2	8304643	Duct, Air Outlet
3	4449809	Screw
4	8303972	Blower, 60mm
5	4450118	Nut
6	8285593	Connector, Cover
7	W10111628	Transformer, Control
8	4450038	Screw
9	4449868	Block, Terminal
10	3400080	Screw
11	8303684	Vent, Control Panel
12	8303518	Side, Control Top Right
	8304255	Left
13	8303520	Back, Control
14	8304219	Cover, Top
15	112432	Nut (3)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KEBS207SBL04, KEBS207SWH04, KEBS207SSS04
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION
-------------------	-----------------	--------------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

WIRING HARNESS PARTS

W10143473 Harness, Latch
W10155291 Harness, Keyboard
W10171563 Harness, Main
8304051 Harness,
Communication
8304439 Conduit, Double
7103P027-60 Nut
98997 Clip
4450800 Screw, Ground
4452260 Spacer, Foam

Miscellaneous

4448950 Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST