


For Models: KEMS308SBL02, KEMS308SWH02, KEMS308SSS02
(Black) (White) (Stainless)

30" BUILT-IN ELECTRIC
COMBO OVEN
THERMAL CONVECTION



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KEMS308SBL02, KEMS308SWH02, KEMS308SSS02

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	7	W10204470	Top Chassis	26	8304303	Back, Chassis
	8304337	Installation	8	4449809	Screw	27		Liner, Oven
		Instructions	9	4452158	Tube, Vent			(Not serviceable)
		Use & Care Guide	10	W10169756	Lens, Light	28	8304452	Thermal Fuse
	W10162223	Combo, Lower	11	W10009940	Oven Light	29	W10131825	Sensor
	W10162181	Microwave			Assembly	30	8303685	Vent, Center
		Tech Sheet	12	W10169757	Bulb, Light	31	8303516	Base, Chassis
	W10185205	English	13	3400832	Screw (2)	32	8304478	Retainer, Gasket
	W10185206	French	14	8304627	Frame, Front	33	8303517	Cover, Back
		Easy Set Guide	15	8304493	Gasket, Door	34		Trim, Bottom Vent
	8304338	Oven	16	3196176	Screw		8303705BL	Black
	8304375	Microwave	17	4449040	Screw		8303705WH	White
		Safer Cooking Tips	18	3400893	Screw		W10165443	Stainless
	9762761	English	19	4451478	Support, Insulation	35	4448444	Grommet,
	W10065852	French	20	4450038	Screw (2)			Mounting Rail
			21		Mounting Rail, Side	36	W10169348	Bracket,
					Right			Thermostat
2	W10153090	Bracket, Base		8303679BL	Black	FOLLOWING PARTS		
3		Hinge Receiver		8303679WH	White	NOT ILLUSTRATED		
	4455606	Right		8303680BL	Black	INSULATION		
	4455605	Left		8303680WH	White		8303965	Insulation, Wrap
4	W10105790	Bumper, Door (2)	22	8303692	Latch, Motorized		8303967	Insulation, Back
5	8303829	Exhaust, Vent Slope	23	4449743	Screw			
6	W10181196	Divider,	24	4449748	Screw			
		Center Vent	25	4455641	Side, Chassis			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


CONTROL PANEL PARTS

For Models: KEMS308SBL02, KEMS308SWH02, KEMS308SSS02

(Black)

(White)

(Stainless)




Illus. No.	Part No.	DESCRIPTION
1	8303716BL	Panel, Control Black
	8303716WH	White
	W10165445	Stainless
2	8304441	Resistor, Drop
3	8303797	Bracket, Glass Touch
4	8303882	Keyboard, Glass Touch
5	W10118734	User Interface, Oven
6	8303719	Backer, Control
7	8303887	Bracket, Enclosure
8	4449154	Screw
9	3400832	Screw
10	W10119143	Appliance Manager
11	W10118735	User Interface, Microwave

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: KEMS308SBL02, KEMS308SWH02, KEMS308SSS02
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8303737BL	Door Liner
2	W10174285	Hinge, Door (2)
3	3196183	Screw
4	8304581BL	Vent, Door Top
5		Bracket, Door
	8304377	Right
	8304378	Left
6		Cover, Hinge
	W10137044	Right
	W10137043	Left

Illus. No.	Part No.	DESCRIPTION
7	8303731	Glass, Inner
8	4449154	Screw
10	8304523	Seal
11	8304360BL	Bracket, Handle
12		Door Glass, Assembly
		Lower Includes #17
	8303993	Black
	8303995	White
	8303991	Stainless

Illus. No.	Part No.	DESCRIPTION
13		Door Handle
	8303774BL	Black
	8303774WH	White
	8303774SS	Stainless
15	8303745BL	Frame, Door Side
16	8303746	Door, Top Bracket
17		Badge
	8304603BL	Black
	8304603WH	White
	8304603SS	Stainless
18	8304522	Bumper, Glass

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


INTERNAL OVEN PARTS

For Models: KEMS308SBL02, KEMS308SWH02, KEMS308SSS02

(Black)

(White)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	8304602	Shield, Broil Element
5	8303841	Rack, Oven
6	8303839	Oven Rack (Sliding)
7	9760768	Element, Bake
8	4455037	Tray, Bake
9	4449154	Screw
10	4450039	Cover, Bake Tray
11	4449809	Screw
12	8303962BU	Cover, Fan
13	9760769	Element Convection
14	9755543	Jack, Meat Probe
15	9755542	Probe, Meat
16	W10116351	Blade, Fan
17	W10116349	Nut
18	W10196895	Motor, Convection Fan
19	9755547	Washer, Lock
20	9755546	Nut, Hidden

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


TOP VENTING PARTS

For Models: KEMS308SBL02, KEMS308SWH02, KEMS308SSS02

(Black)

(White)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4449154	Screw
2	4454949	Holder, Fuse
3	4449809	Screw
4	8303972	Blower
6	8304643	Duct, Air Outlet
7	9762053	Transformer, Control
8	8285593	Cover, Connector
9	4449868	Block, Terminal
10	W10017410	Fuse
11	8304509	Chassis, Back Combo
12	8304546	Right Side, Combo
	8303539	Left Side, Combo
13	8303537	Back, Control
14	8303519	Cover, Top Rear
15	7103P027-60	Nut, Terminal Block
16	8304569	Support, Microwave Module
17	3400080	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


CABINET AND STIRRER PARTS

For Models: KEMS308SBL02, KEMS308SWH02, KEMS308SSS02

(Black)

(White)

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: KEMS308SBL02, KEMS308SWH02, KEMS308SSS02

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10120227	Control, Electric	23	W10130895	Plate, Air	46	8205707	Support
2	8205669	Support	24	4375319	Spring, Lamp	47	W10120478	Hinge, Door
3	W10130892	Plate, Air	25	8205685	Spring	48	W10130903	Cover, Plate
4	W10130901	Insulation, Side Left	26	8205658	Housing, Lamp	49	W10130904	Cover, Rear
5	W10120471	Cover, Side Left	27	4375348	Lamp	50	8205680	Cover, Side Right
6	W10120223	Thermostat	28	W10120222	Thermostat	51	W10120221	Convection, Motor Assmely
7	W10120224	Element, Convection	29	W10131248	Switch	52	8205721	Blower Assembly
8	4375418	Fan	30	8205683	Holder, Switch	53	W10130907	Cover, Inverter
9	W10120233	Nut, Speed	31	4375320	Reflector	54	W10120229	Inverter
10	W10130891	Holder	32	4375318	Lens, Lamp	55	W10130906	Holder, Inverter
11	W10120220	Noise Filter	33	W10120231	Clip. Spring	56	W10130890	Screw
12	W10120228	Control, Electric Converter	34	W10120477	Top Vent	57	W10130908	Baffle, Air
13	W10130909	Bracket, Support	36	W10120473	Right	58	W10130899	Plate, Air
14	W10131249	Screw		W10120475	Left	59	W10120235	Rod, Release
15	8205692	Transformer	37	W10120469	Bushing	60	W10120225	Sensor
16	4375427	Actuator	38	W10130905	Bracket, Support	61	8205685	Spring
17	4375321	Fuse	39	8205708	Bracket, Support	64	8205683	Interlock
18	4375231	Block, Fuse	40	8205682	Shaft, Turntable	65	W10130900	Insulation
19	W10130897	Bracket, Support			Turntable	66	8205704	Spring
20	8205653	Filter, Noise	41	8205681	Cover, Motor	67	W10130902	Insulation
21	8205654	Thermostat			Turntable	68	8205689	Spring
22	W10120113	Magnetron	42	W10120234	Cover	69	8205688	Arm
			43	4375252	Gasket, Shaft	70	8205686	Support
			44	8205655	Motor, Turntable	71	W10120236	Arm
			45	4375202	Screw	72	W10120470	Pin, Damper
						73	8205690	Sensor
						74	W10130898	Duct, Magnetron

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


INTERNAL MICROWAVE PARTS

For Models: KEMS308SBL02, KEMS308SWH02, KEMS308SSS02

(Black)

(White)

(Stainless)




Illus. No.	Part No.	DESCRIPTION
1	W10120480	Crisp Plate
2	W10120484	Steamer
4	W10120486	Plate, Baking
5	W10120483	Rack
6	8205676	Turntable
7	8205678	Ring
8	8205677	Drive, Turn Table
9	W10120481	Handle, Pan
10	W10120226	Grill Heater
11	W10120230	Cover, Plates (2)
12	W10120232	Bracket, Mounting

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE DOOR PARTS

For Models: KEMS308SBL02, KEMS308SWH02, KEMS308SSS02
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8304588BL	Cap, Screw
2	4449809	Screw
3	W10120487	Door, Microwave
4	4449154	Screw (4)
5	8303033	Bracket, Door
6		Glass Assembly
	8304027	Black
	8304028	White
	8304026	Stainless
7		Handle, Door
	8303774BL	Black
	8303774WH	White
	8303774SS	Stainless
8	W10143304	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KEMS308SBL02, KEMS308SWH02, KEMS308SSS02
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION
-------------------	-----------------	--------------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

FOLLOWING PARTS NOT ILLUSTRATED

WIRING HARNESS PARTS

W10143473 Harness,
Door Latch
8304052 Harness,
Communication
4452400 Lead, Ground
4449809 Screw
W10171567 Harness, Main
4450800 Screw, Ground
4449809 Screw
8304440 Conduit, Combo

Miscellaneous

4448950 Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST