


KitchenAid® COOKTOP PARTS

For Models: KERS807SBL00, KERS807SWW00, KERS807SBB00, KERS807SSS00
(Black) (Pure White) (Pure Biscuit) (S.Steel)

30" FREE STANDING
ELECTRIC OVEN
CONVECTION



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	9763461	Installation Instructions
	9763458	Use & Care Guide
	9762786	Tech Sheet
	9757680	Anti-Tip Instruct.
	3191638	Safe Cooking Tips
	9759133	Safe Cooking Tips (French)
	9763467	Guide, Easy Set
2	9761801	Central, Appliance
3	9761784	Bracket, Mounting
4		Cooktop
	9762791BB	Biscuit
	9762791WW	White
	9762791BL	Black
6		Trim-CkTop, SI
	9761739WH	White RH
	9761739BT	Biscuit RH
	9761739BL	Black RH
	9761739SS	S.Steel RH
	9761738WH	White LH
	9761738BT	Biscuit LH
	9761738BL	Black LH
	9761738SS	S.Steel LH


Illus. No.	Part No.	DESCRIPTION
7	W10054430	Gasket, Cooktop
9		Support
	9757686	L.Hand
	9757687	R.Hand
10	9756821	Support, Wiring
11	4449809	Screw (2)
12		Element, Surface
	8203525	1800/1000W
	8523696	1800W RR
	4453909	2500/1200W (2)
13	9761423	Bracket, Front
		Support
14	9761577	Cover, Backsplash
		Rear
15		Backsplash
	W10109750	Black
	W10109760	Biscuit
	W10109740	White
	W10109770	Nickel Plated
		Gasket
	9763483BL	Black
	9763483GY	Gray

Illus. No.	Part No.	DESCRIPTION
16	9759944	Thrmstat, 60c SPST
17	9758799	Bracket, Ind. Lamp
18	3196160	Screw (2)
19	9759094	Spring, Locator
20	9761783	Bracket, Rear Sprt
21		Rail, Element (2)
	9763517	Side (3)
	9757825	Center (1)
22	246119	Screw
23	9761724	Cover, Cktp Rear
24	8523739	Indicator Lamp, Hot Surface
25	3196537	Screw
26	9762768	Clip, Retainer
27		Glass, Backsplash
	9761749BL	Black
	9761749WH	White
	9761749BT	Biscuit
28	W10050270	Grommet (19mm)
29	W10050280	Grommet (38mm)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KERS807SBL00, KERS807SWW00, KERS807SBB00, KERS807SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9761551WH	Control Panel White	9	9761780WH	Knob (RF) White	11	9763761	Switch, Infinite RF
	9761551BT	Biscuit		9761780BT	Biscuit		9763762	LF,RR,LR
	9761551BL	Black		9761780BL	Black	12	9757778	Bushing
	9761551NP	Nickel Plated		9761780NP	Nickel Plated (LF,RR,LR)	14	3196537	Screw
2	9761566	Switch, Membrane (Touchsensor Glas)		9762764WH	White			
3	9761799	Control, Interface		9762764BT	Biscuit			
4	9763485	Shield, Console		9762764BL	Black			
5	3196068	Lens, Ind. (2)		9762764NP	Nickel Plated			
6	9761745	Brkt, Touchsensor						
7	3196160	Screw						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KERS807SBL00, KERS807SWW00, KERS807SBB00, KERS807SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: KERS807SBL00, KERS807SWW00, KERS807SBB00, KERS807SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)	17	4452152	Bracket, Mounting	36	4449040	Screw
	9761572WH	White	18	9757685	Guide, Side Pnl (2)	37	9759242	Thermostat (TOD) Manager, 130c (Temp.) SPST
	9761572BT	Biscuit	19	4451478	Support, Insulation			
	9761572BL	Black	20		Body, Side	38	4449154	Screw
	9761572SS	S.Steel (Left Hand)		9760723PB	Black	43	9759713	Base, Chassis
	9761571WH	White		9760723PC	Biscuit	49	4448933	Retainer, Gasket
	9761571BT	Biscuit		9760723PW	White	50	9758583	Cover, Back
	9761571BL	Black	21	3196537	Screw	54		Vent, Bottom Upper
	9761571SS	S.Steel	22	9760888	Latch, Motorized		9756481WH	White
2	3400832	Screw	23	341196	Thermostat SPST (205)		9756481BT	Biscuit
3		Hinge Receiver	24	9759890	Clip, Side Panel		9756481BL	Black
	4455605	Left Hand	25	4455641	Side, Chassis (R.H. & L.H.)		9756481SS	S.Steel
	4455606	Right Hand	26	9759761	Back, Chassis	55		Trim, Btm Vent
4	9760749	Bumper, Door	27		Liner, Oven (Not serviceable)		9756485WH	White
5	9757461	Bracket, Side Panel					9756485BT	Biscuit
6	9757811	Brace, Side Panel	28	9759945	Cover, Rear Standoff		9756485BL	Black
7	8303099	Top Chassis					9756485SS	S.Steel
8	4449809	Screw	29	4455636	Sensor	FOLLOWING PARTS NOT ILLUSTRATED		
9	4452158	Tube, Vent	30	9756454	Bracket, GOC	INSULATION		
10	4452165	Lens, Light	31	W10083460	Slide, GOC		9756817	Insulation, Wrap
11	4452368	Oven Light Assy	32	3196160	Screw		9756470	Insulation, Back
12	4452166	Bulb, Light	33	9757717	Insulation, Bottom Vent			
14	9760756	Frame, Front	34	4449743	Screw			
15	W10074200	Gasket, Door	35	3196176	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: KERS807SBL00, KERS807SWW00, KERS807SBB00, KERS807SSS00
(Black) (Pure White) (Pure Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models: KERS807SBL00, KERS807SWW00, KERS807SBB00, KERS807SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Nameplate	10		Hinge, Door	25		Bracket, Handle
	9763444BL	Black		9760579	R.Side (Orange)		9763497	R.Hand
	9763444BT	Biscuit		9760580	L.Side (Orange)		9763496	L.Hand
	9763444WH	White	11	9761935	Foot, Rear	26		Handle, Drawer
	9763444SS	S.Steel	12	9759229	Bracket, Side		9761573WH	White
2	3400832	Screw	13	8274149	Sensor		9761573BT	Biscuit
3	3400805	Screw	14	8054056	Element, Warming		9761573BL	Black
4	4457132	Retainer, Glass	15	9757706	Glass, Inner		9761573SS	S.Steel
5		Glass, Door Front	16	4457114	Shield, Heat Btm	27	8533988	Screw
	9762766BL	Black	17	9759225	Glass, Inner (2)	28	4449809	Screw
	9762766WH	White	18	4451722	Insulation, Door	29		Side, Base
	9762766BT	Biscuit	19	9759413	Liner, Door		9759953	R.Side
	9762766SS	S.Steel	20	9757805	Drawer Assy		9759954	L.Side
6	W10045140	Cover, Terminal	21	3196037	Foot, Front	30	4449743	Screw
7	3196176	Screw	22	9763456	Panel, Drawer	31	3196537	Screw
8		Handle, Door	23	9758676	Support, Element	32		Guide, Roller
	8303774BL	Black	24		Front, Drawer		4453719	R.Hand
	8303774WH	White		9761747WH	White		4453718	L.Hand
	8303774BT	Biscuit		9761747BL	Black	33	4457103	Shield, Heat Top
	8303774SS	S.Steel		9761747BT	Biscuit			
9	9759230	Bracket, Central		9761747SS	S.Steel			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KERS807SBL00, KERS807SWW00, KERS807SBB00, KERS807SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	8301514	Element, Broil
2	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	4452155	Element, Bake
8	9755542	Probe, Meat
9	4452157	Element, Convect.
10	9756690	Cover, Fan
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	4451583	Motor, Convection
14	4452227	Nut
15	4452226	Blade, Fan
16	9755543	Jack, Meat Probe
17	9755547	Lock Washer
18	9755546	Hex Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KERS807SBL00, KERS807SWW00, KERS807SBB00, KERS807SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower 45mm
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	9759938	Bracket, Term.Box

Illus. No.	Part No.	DESCRIPTION
7	4449809	Screw
8	9757404	Box, Terminal
9	9759721	Insulator, Term Box
10	9761958	Block, Terminal
11	4449868	Block, Terminal
12	9757405	Cover, Term Box

Illus. No.	Part No.	DESCRIPTION
14	9757829	Bracket, Transfrm
15	9760212	Transformer
16	4449040	Screw
17	3400080	Screw
18	3196160	Screw
20	9759884	Insulation
21	4455352	Bracket, Blower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KERS807SBL00, KERS807SWW00, KERS807SBB00, KERS807SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<p><u>PAINT, TOUCH-UP (1/2oz.)</u></p> <p>72017 White 261869 Cord Brown 72032 Black</p> <p><u>PAINT, SPRAY</u></p> <p>350930 White 261900 Citrine White 830864 Black</p> <p><u>ADHESIVE</u></p> <p>591014 Adhesive Loctite (1/3 oz.) 482338 Sealer, Silastic (3 oz.)</p>	<p><u>SPLICING WIRES--25FT.</u></p> <p><u>LENGTH</u></p> <p>242828 Wire (12 Ga. 150 c Black) 242820 Wire (14 Ga. 150 c Black) 242821 Wire (14 Ga. 150 c Blue) 242822 Wire (14 Ga. 150 c Brown) 242830 Wire (14 Ga. 200 c Brown) 242823 Wire (14 Ga. 150 c Green) 242824 Wire (14 Ga. 150 c Orange) 242829 Wire (12 Ga. 150 c Red) 242825 Wire (14 Ga. 150 c Red) 242831 Wire (14 Ga. 200 c Red) 242826 Wire (14 Ga. 150 c White) 242827 Wire (14 Ga. 150 c Yellow) 242832 Wire (14 Ga. 200 c Yellow)</p>	<p><u>WIRING HARNESS PARTS</u></p> <p>9761567 Harness, Wire (Main) 9762909 Harness, Wire (Switch, Elec) 9762921 Harness, Wire W10109280 Harness, Cktp (Elec. Sw.) 9762426 Harness, Wire (Connector Cable) 9763481 Harness, Ground Strap 9759715 Conduit 313660 Clip, Ground Wire 4448664 Clamp 4449809 Screw 112432 Nut 4450800 Screw, Ground 4452222 Spacer, Harness 3400015 Screw, Ground</p> <p><u>Miscellaneous</u></p> <p>814381 Hinge Pin Kit 4448950 Screw, Install (4) 9782676 Anit-Tip Assy</p>

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST