


KitchenAid® COOKTOP PARTS

For Models: KESS907SBL00, KESS907SWW00, KESS907SBB00, KESS907SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)

30" Built-In
 ELECTRIC OVEN




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	9		Support	18	3196160	Screw (2)
	9763461	Installation Instructions		9757686	L.Hand	19	9759094	Spring, Locator
	9763458	Use & Care Guide		9757687	R.Hand	20	9761768	Bracket, Rear Sprt
	9762786	Tech Sheet	10	9756821	Support, Wiring	21		Rail, Element (2)
	9757680	Anti-Tip Instruct.	11	4449809	Screw (2)		9763517	Side (3)
	3191638	Safe Cooking Tips	12		Element, Surface		9757825	Center (1)
	9759133	Safe Cooking Tips (French)		8203525	1800/1000W	22	246119	Screw
	9763467	Guide, Easy Set		8523696	1800W RR	23	9761724	Cover, Cktp Rear
2	9761801	Central, Appliance		4453909	2500/1200W (2)	24	8523739	Indicator Lamp, Hot Surface
3	9761422	Bracket, Mounting	13	9761423	Bracket, Front Support	25	3196537	Screw
4		Cooktop	16	9759944	Thrmstat, 60c SPST	28	W10050270	Grommet (19mm)
	9762789BB	Biscuit	17	9758799	Bracket, Ind. Lamp	29	W10050280	Grommet (38mm)
	9762789WW	White						
	9762789BL	Black						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KESS907SBL00, KESS907SWW00, KESS907SBB00, KESS907SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9761550WH	Control Panel White	9		Knob (RF)	11		Switch, Infinite
	9761550BT	Biscuit		9761780WH	White		9763761	RF
	9761550BL	Black		9761780BT	Biscuit		9763762	LF,RR,LR
	9761550NP	Nickel Plated		9761780BL	Black	12	9757778	Bushing
2	9761566	Switch, Membrane (Touchsensor Glas)		9761780NP	Nickel Plated (LF,RR,LR)	14	3196537	Screw
3	9761799	Control, Interface		9762764WH	White			
4	9763485	Shield, Console		9762764BT	Biscuit			
5	3196068	Lens, Ind. (2)		9762764BL	Black			
6	9761745	Brkt, Touchsensor		9762764NP	Nickel Plated			
7	3196160	Screw						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KESS907SBL00, KESS907SWW00, KESS907SBB00, KESS907SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: KESS907SBL00, KESS907SWW00, KESS907SBB00, KESS907SSS00
(Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)	19	4451478	Support, Insulation Body, Side	36	4449040	Screw
	9761572WH	White	20			37	9759242	Thermostat (TOD) Manager, 130c (Temp.) SPST
	9761572BT	Biscuit		9760723PB	Black			
	9761572BL	Black		9760723PC	Biscuit			
	9761572SS	S.Steel		9760723PW	White	38	4449154	Screw
		(Left Hand)	21	3196537	Screw	43	9759713	Base, Chassis
	9761571WH	White	22	9760888	Latch, Motorized	49	4448933	Retainer, Gasket
	9761571BT	Biscuit	23	341196	Thermostat SPST (205)	50	9758583	Cover, Back
	9761571BL	Black				54		Vent, Bottom Upper
	9761571SS	S.Steel	24	9759890	Clip, Side Panel		9756481WH	White
2	3400832	Screw	25	4455641	Side, Chassis (R.H. & L.H.)		9756481BT	Biscuit
3		Hinge Receiver	26	9759761	Back, Chassis		9756481BL	Black
	4455605	Left Hand	27		Liner, Oven (Not serviceable)	55	9756481SS	S.Steel
	4455606	Right Hand						Trim, Btm Vent
4	9760749	Bumper, Door	28	9759945	Cover, Rear Standoff		9756485WH	White
5	9757461	Bracket, Side Panel					9756485BT	Biscuit
6	9757811	Brace, Side Panel	29	4455636	Sensor		9756485BL	Black
7	8303099	Top Chassis	30	9756454	Bracket, GOC		9756485SS	S.Steel
8	4449809	Screw	31	W10083460	Slide, GOC	FOLLOWING PARTS NOT ILLUSTRATED		
9	4452158	Tube, Vent	32	3196160	Screw	INSULATION		
10	w10067870	Lens, Light	33	9757717	Insulation, Bottom Vent			
11	w10009930	Oven Light Assy	34	4449743	Screw		9756817	Insulation, Wrap
12	4452166	Bulb, Light	35	3196176	Screw		9756470	Insulation, Back
14	9760756	Frame, Front						
15	W10074200	Gasket, Door						
17	4452152	Bracket, Mounting						
18	9757685	Guide, Side Pnl (2)						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: KESS907SBL00, KESS907SWW00, KESS907SBB00, KESS907SSS00
(Black) (Pure White) (Pure Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models: KESS907SBL00, KESS907SWW00, KESS907SBB00, KESS907SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Nameplate	10		Hinge, Door	25		Bracket, Handle
	9763444BL	Black		9760579	R.Side (Orange)		9763497	R.Hand
	9763444BT	Biscuit		9760580	L.Side (Orange)		9763496	L.Hand
	9763444WH	White	11	9761935	Foot, Rear	26		Handle, Drawer
	9763444SS	S.Steel	12	9759229	Bracket, Side		9761573WH	White
2	3400832	Screw	13	8274149	Sensor		9761573BT	Biscuit
3	3400805	Screw	14	8054056	Element, Warming		9761573BL	Black
4	4457132	Retainer, Glass	15	9757706	Glass, Inner		9761573SS	S.Steel
5		Glass, Door Front	16	4457114	Shield, Heat Btm	27	8533988	Screw
	9762766BL	Black	17	9759225	Glass, Inner (2)	28	4449809	Screw
	9762766WH	White	18	4451722	Insulation, Door	29		Side, Base
	9762766BT	Biscuit	19	9759413	Liner, Door		9759953	R.Side
	9762766SS	S.Steel	20	9757805	Drawer Assy		9759954	L.Side
6	W10045140	Cover, Terminal	21	3196037	Foot, Front	30	4449743	Screw
7	3196176	Screw	22	9763456	Panel, Drawer	31	3196537	Screw
8		Handle, Door	23	9758676	Support, Element	32		Guide, Roller
	8303774BL	Black	24		Front, Drawer		4453719	R.Hand
	8303774WH	White		9761747WH	White		4453718	L.Hand
	8303774BT	Biscuit		9761747BL	Black	33	4457103	Shield, Heat Top
	8303774SS	S.Steel		9761747BT	Biscuit			
9	9759230	Bracket, Central		9761747SS	S.Steel			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KESS907SBL00, KESS907SWW00, KESS907SBB00, KESS907SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	8301514	Element, Broil
2	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	4452155	Element, Bake
8	9755542	Probe, Meat
9	4452157	Element, Convect.
10	9756690	Cover, Fan
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	4451583	Motor, Convection
14	4452227	Nut
15	4452226	Blade, Fan
16	9755543	Jack, Meat Probe
17	9755547	Lock Washer
18	9755546	Hex Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KESS907SBL00, KESS907SWW00, KESS907SBB00, KESS907SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust	7	4449809	Screw	14	9757829	Bracket, Transfrm
2	4455178	Elbow, Vent Top	8	9757404	Box, Terminal	15	9760212	Transformer
3	9759320	Blower	9	9759721	Insulator, Term Box	16	4449040	Screw
	4451758	45mm	10	9761958	Block, Terminal	17	3400080	Screw
4	4451757	Block, Foam	11	4449868	Block, Terminal	18	3196160	Screw
5	4455177	Elbow, Vent Bottom	12	9757405	Cover, Term Box	20	9759884	Insulation
6	9759938	Bracket, Term.Box				21	4455352	Bracket, Blower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KESS907SBL00, KESS907SWW00, KESS907SBB00, KESS907SSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	261869	Cord Brown
	72032	Black
<u>PAINT, SPRAY</u>		
	350930	White
	261900	Citrine White
	830864	Black
<u>ADHESIVE</u>		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
<u>SPLICING WIRES--25FT.</u>		
<u>LENGTH</u>		
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
<u>WIRING HARNESS PARTS</u>		
	9761567	Harness, Wire (Main)
	9762909	Harness, Wire (Switch, Elec)
	9762921	Harness, Wire
	W10112276	Harness, Cktp (Elec. Sw.)
	9762781	Harness, Wire (Connector Cable)
	9763481	Harness, Ground Strap
	9759715	Conduit
	313660	Clip, Ground Wire
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	4452222	Spacer, Harness
	3400015	Screw, Ground
<u>Miscellaneous</u>		
	814381	Hinge Pin Kit
	4448950	Screw, Install (4)
	9782676	Anit-Tip Assy

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST