



**KitchenAid®** **COOKTOP PARTS**  
 For Models: KESK901SBL06, KESK901SWH06, KESK901SSS06  
 (Black) (White) (Stainless)

30" SLIDE-IN  
 ELECTRIC OVEN  
 THERMAL OVEN



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP PARTS

For Models: KESK901SBL06, KESK901SWH06, KESK901SSS06  
 (Black)                      (White)                      (Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10118260	Installation Instructions
	W10190622	Use & Care Guide
	W10189732	Tech Sheet
	9763467	Easy Set Guide
	9757680	Anti-Tip Instructions
	9762761	Safe Cooking Tips English
	W10065852	French
3	9761422	Frame, Cooktop Side
4		Cooktop
	W10109850	Black/Stainless
	W10109860	White
7	W10076030	Gasket (2)
8	8523739	Light, Indicator
9	9759944	Thermostat
10	9756821	Support, Wiring
12		Element, Surface
	8523697	LR
	8523696	RF
	8523694	RR
	4453909	LF
13	9761423	Frame, Cooktop Front
14	3196537	Screw
15	341196	Thermostat
16	3196160	Screw
17	9758799	Bracket, Indicator Lamp
19	9759094	Spring, Locator
20	9761768	Frame, Cooktop Rear
21	9763517	Rail, Element (3)
22	246119	Screw
23	9761724	Cover, Cooktop Rear


# OVEN PARTS

For Models: KESK901SBL06, KESK901SWH06, KESK901SSS06

(Black)

(White)

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models: KESK901SBL06, KESK901SWH06, KESK901SSS06

(Black)

(White)


(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side Right	18	9757685	Guide, Side Panel	43	3400080	Screw
	W10109540	Black	19	4451478	Support, Insulation Body, Side	44	W10165135	Box, Terminal
	W10109570	White	20			45	9757405	Cover, Terminal Box
	W10140548	Stainless		9760723PB	Black/Stainless	46	9759721	Insulator, Terminal Box
		Left		9760723PW	White	47	9761958	Block, Terminal
	W10109490	Black	21	9757461	Bracket, Side Panel	48	W10181438	Appliance, Manager
	W10109520	White	22	9760888	Latch, Motorized	49	W10083460	Slide, GOC
	W10140547	Stainless	23	9759242	Thermostat	50	9756454	Bracket, Appliance Manager
2	3400832	Screw	24	9757811	Brace, Side Panel	51	9759884	Insulation
3		Hinge Receiver	25	4455641	Side, Chassis	52	9759722	Insulation, Body Side
	4455606	Right	26	9759761	Back, Chassis	53	9760481	Washer
	4455605	Left	27		Liner, Oven (Not Serviceable)	54	9758583	Cover, Back
4	W10105790	Bumper, Door (2)	28	9759890	Clip, Side Panel	55	9759885	Pad, Insulation(2)
5	3196537	Screw	29	W10131825	Sensor	56	9759945	Standoff, Rear
6	3196160	Screw	31	3196176	Screw	<b>FOLLOWING PARTS NOT ILLUSTRATED</b>		
7	8303099	Top Chassis	33	9759713	Base, Chassis	<b>INSULATION</b>		
8	4449809	Screw	34	4448933	Retainer, Gasket		9756817	Insulation, Wrap
9	4452158	Tube, Vent	35	4448444	Grommet, Mounting Rail		9756470	Insulation, Back
10	W10067870	Lens, Light (2)			Vent, Bottom Upper			
11	W10009930	Oven Light, Assembly (2)	36					
12	4452166	Bulb, Light (2)		W10116899	Black			
13	4449154	Screw		W10116897	White			
14	W10115831	Frame, Front		W10160347	Stainless			
15	W10074200	Gasket, Door	37		Vent, Bottom Lower			
16	9757829	Bracket, Transformer		W10153486	Black			
17	4452152	Bracket, Mounting		W10153488	White			
				W10154789	Stainless			
			38	4449743	Screw			
			41	W10111628	Transformer, Control			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: KESK901SBL06, KESK901SWH06, KESK901SSS06  
(Black) (White) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: KESK901SBL06, KESK901SWH06, KESK901SSS06

(Black)


(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	9759413	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760580	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457104	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	9763497	Right
	9763496	Left
13		Badge
	8304603BL	Black
	8304603WH	White
	8304603SS	Stainless
14		Assembly, Door Kit
	W10131888	Black
	W10131889	White
	W10155557	Stainless
15		Handle, Door
	8303774BL	Black
	8303774WH	White
	8303774SS	Stainless
16	3196184	Screw
19	4448520	Bumper, Door

# DRAWER PARTS

For Models: KESK901SBL06, KESK901SWH06, KESK901SSS06  
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left


Illus. No.	Part No.	DESCRIPTION
4	9759943	Brace, Base Front
5		Side, Base
	9759953	Right
	9759954	Left
6	W10058460	Foot
8	3196037	Foot Assembly
9	9756673	Guide, Roller (2)
10	9757806	Drawer
11		Drawer Slide
	9756836	Right
	9756838	Left

Illus. No.	Part No.	DESCRIPTION
12	9760592	Panel, Drawer
13		Front, Drawer
	W10203760	Black
	W10203762	White
	W10203763	Stainless
14		Handle, Drawer
	9761573BL	Black
	9761573WH	White
	9761573SS	Stainless
15	3196537	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: KESK901SBL06, KESK901SWH06, KESK901SSS06  
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	W10190660	Black
	W10190661	White
	W10190662	Stainless
2		Switch, Infinite
	4454539	LR
	4454540	RF
	4454541	RR
	4456027	LF
3	W10206374	Control, Electric

Illus. No.	Part No.	DESCRIPTION
4	W10105370	Shield, Console Vent
5	3196068	Lens, Indicator (2)
6	3196160	Screw
7	9761745	Bracket, Thermostat (2)
8	W10116195	Gasket, Vent Shield


Illus. No.	Part No.	DESCRIPTION
9		Knob
		RF
	W10193267	Black
	W10193265	White
	W10156263	Stainless
		LR,LF,RR
	W10193271	Black
	W10193269	White
	W10156264	Stainless
10	3196537	Screw
11	9780271	Screw
13	9761565	Membrane, Switch
14	W10110246	Gasket, Console
15	W10117524	Bracket, Gasket

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# INTERNAL OVEN PARTS

For Models: KESK901SBL06, KESK901SWH06, KESK901SSS06  
 (Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4449154	Screw
3	W10179152	Rack, Oven
4	9760768	Element, Bake
5	4455037	Tray, Hidden Bake
6	4450039	Cover, Bake Tray

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP VENTING PARTS

For Models: KESK901SBL06, KESK901SWH06, KESK901SSS06  
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	W10143041	Bracket, Terminal Box
7	4449809	Screw (2)
10	4449040	Screw
11	4455352	Bracket, Blower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: KESK901SBL06, KESK901SWH06, KESK901SSS06  
 (Black) (White) (Stainless)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<p><b>OPTIONAL PARTS NOT INCLUDED</b></p> <p><b><u>PAINT, TOUCH-UP (1/2oz.)</u></b></p> <p>72017 White            261869 Cord Brown            72032 Black</p> <p><b><u>PAINT, SPRAY</u></b></p> <p>350930 White            261900 Citrine White            830864 Black</p>	<p><b><u>ADHESIVE</u></b></p> <p>591014 Adhesive            Loctite (1/3 oz.)            482338 Sealer, Silastic            (3 oz.)</p> <p><b><u>WIRING HARNESS PARTS</u></b></p> <p>W10137679 Harness, Main            W10118727 Harness, Switch            9762921 Harness,            Communication            9763481 Harness, Ground            Strap            W10190434 Cooktop, Electric            Switch            313660 Clip, Ground Wire            W10127413 Proctector, Edge            9757778 Bushing,            Snap Split            W10177363 Grommet, Flex            4449809 Screw            W10155291 Connector, Flex            7103P027-60 Nut,            Terminal Block            4450800 Screw, Ground            3400015 Screw, Ground</p>	<p><b><u>Miscellaneous</u></b></p> <p>9782676 Anti-Tip Assembly            Filler, Counter            Top            W10113902A Black            W10113903A White            W10113901A Stainless</p>

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST