


# KitchenAid® COOKTOP PARTS

For Models: KESS908SPB04, KESS908SPW04, KESS908SPS04  
(Black) (White) (Stainless)

30" SLIDE-IN  
ELECTRIC OVEN  
SELF CLEAN



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP PARTS

For Models: KESS908SPB04, KESS908SPW04, KESS908SPS04  
 (Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10118260	Installation Instructions
	W10190622	Use & Care Guide
	W10112131	Tech Sheet
	9763467	Easy Set Guide
	9757680	Anti-Tip Instructions
	9762761	Safe Cooking Tips English
	W10065852	French
2	W10181438	Module, Appliance Manager
3	9761422	Frame, Cooktop Side
4		Cooktop
	W10110273	Black/Stainless
	W10110272	White
5	9757824	Rail, Element Side
6	9761638	Box, Tap Touch
7	W10076030	Gasket (2)
8	4449745	Screw
9	9759944	Thermostat
10	9756821	Support, Wiring
11	9757825	Rail, Element Center (1)
12		Element, Surface
	W10203295	LR/1000W
	4453907	RF/1500W
	4453910	RR/1900W
	4453908	LF/2300W
13	9761423	Frame, Cooktop Front
14	3196537	Screw
15	341196	Thermostat
16	3196160	Screw
17	9761663	Seal, Heat
18	9757815	Support, Module
19	9759094	Spring, Locator
20	9761768	Frame, Cooktop Rear
21	9763517	Rail, Element (2)
22	246119	Screw
23	9761723	Cover, Cooktop Rear
24	9757063	Module, Tap Touch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# OVEN PARTS

For Models: KESS908SPB04, KESS908SPW04, KESS908SPS04

(Black)

(White)

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models: KESS908SPB04, KESS908SPW04, KESS908SPS04

(Black)

(White)


(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side Right	18	9757685	Guide, Side Panel	41	W10111628	Transformer, Control
	W10109540	Black	19	4451478	Support, Insulation Body, Side	43	3400080	Screw
	W10109570	White	20	9760723PB	Black/Stainless	44	W10165135	Box, Terminal
	W10140548	Stainless		9760723PW	White	45	9757405	Cover, Terminal Box
		Left	21	9757461	Bracket, Side Panel	46	9759721	Insulator, Terminal Box
	W10109490	Black	22	W10195934	Latch, Motorized	47	9761958	Block, Terminal
	W10109520	White	23	9759242	Thermostat	48	8285348	Appliance, Manager
	W10140547	Stainless	24	9757811	Brace, Side Panel	49	W10083460	Slide, GOC
2	3400832	Screw	25	4455641	Side, Chassis	50	9756454	Bracket, Appliance Manager
3		Hinge Receiver	26	9759761	Back, Chassis	51	9759884	Insulation
	4455606	Right	27		Liner, Oven (Not Serviceable)	52	9759722	Insulation, Body Side
	4455605	Left	28	9759890	Clip, Side Panel	53	9760481	Washer
4	W10105790	Bumper, Door (2)	29	W10131825	Sensor	54	9758583	Cover, Back
5	3196537	Screw	31	3196176	Screw	55	9759885	Pad, Insulation(2)
6	3196160	Screw	33	9759713	Base, Chassis	56	9759945	Standoff, Rear
7	8303099	Top Chassis	34	4448933	Retainer, Gasket	<b>FOLLOWING PARTS NOT ILLUSTRATED</b>		
8	4449809	Screw	35	4448444	Grommet, Mounting Rail	<b>INSULATION</b>		
9	4452158	Tube, Vent			Vent, Bottom Upper	9756817		Insulation, Wrap
10	W10067870	Lens, Light (2)	36	W10116899	Black	9756470		Insulation, Back
11	W10009930	Oven Light, Assembly (2)		W10116897	White			
12	4452166	Bulb, Light (2)		W10140533	Stainless			
13	4449154	Screw	37	W10153486	Black			
14	W10115831	Frame, Front		W10153488	White			
15	W10074200	Gasket, Door		W10160347	Stainless			
16	9757829	Bracket, Transformer	38	4449743	Screw			
17	4452152	Bracket, Mounting						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: KESS908SPB04, KESS908SPW04, KESS908SPS04  
(Black) (White) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# DOOR PARTS

For Models: KESS908SPB04, KESS908SPW04, KESS908SPS04  
 (Black) (White) (Stainless)

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1	W10110704	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760580	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457104	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	9763497	Right
	9763496	Left
13		Badge
	8304603BL	Black
	8304603WH	White
	8304603SS	Stainless
14		Assembly, Door Kit
	W10131888	Black
	W10131889	White
	W10155557	Stainless
15		Handle, Door
	8303774BL	Black
	8303774WH	White
	8303774SS	Stainless
16	3196184	Screw
19	4448520	Bumper, Door

# DRAWER PARTS

For Models: KESS908SPB04, KESS908SPW04, KESS908SPS04  
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left
5		Side, Base
	9759953	Right
	9759954	Left


Illus. No.	Part No.	DESCRIPTION
6	W10058460	Foot
7	8274149	Thermistor
8	3196037	Foot Assembly
10	W10164163	Drawer
11		Drawer Slide
	W10155633	Right
	W10155632	Left
12	W10144431	Panel, Drawer
13		Front, Drawer
	W10203760	Black
	W10203762	White
	W10203763	Stainless

Illus. No.	Part No.	DESCRIPTION
14		Handle, Drawer
	9761573BL	Black
	9761573WH	White
	9761573SS	Stainless
15	3196537	Screw
16	W10153100	Cover, Terminal
17	9758676	Support, Element
18	9760775	Element, Warming
		Drawer
19	9763518	Enclosure, Warming
		Drawer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: KESS908SPB04, KESS908SPW04, KESS908SPS04  
 (Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	W10117033	Black
	W10117034	White
	W10156272	Stainless
2	W10110246	Gasket, Console
3	W10181439	Control, Electric
4	W10105370	Shield, Console Vent
5	W10117524	Bracket, Console
6	3179559	Screw
7	9761745	Bracket, Thermostat (2)
8	W10116195	Gasket, Vent Shield
9	3196537	Screw
10	9780271	Screw
11	9761566	Membrane, Switch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# INTERNAL OVEN PARTS

For Models: KESS908SPB04, KESS908SPW04, KESS908SPS04  
 (Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4449154	Screw
6	W10179152	Rack, Oven
7	9760768	Element, Bake
8	9755542	Probe, Meat
9	9760769	Element, Convection
10	9756690	Cover, Fan
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	W10116228	Motor, Convection
14	W10116349	Nut
15	W10116351	Blade, Fan
16	9755543	Jack, Meat Probe
17	9755547	Lock Washer
18	9755546	Hex Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP VENTING PARTS

For Models: KESS908SPB04, KESS908SPW04, KESS908SPS04  
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	W10143041	Bracket, Terminal Box
7	4449809	Screw (2)
10	4449040	Screw
11	4455352	Bracket, Blower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: KESS908SPB04, KESS908SPW04, KESS908SPS04  
(Black) (White) (Stainless)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<p><b>OPTIONAL PARTS NOT INCLUDED</b></p> <p><b><u>PAINT, TOUCH-UP (1/2oz.)</u></b></p> <p style="padding-left: 20px;">72017 White 261869 Cord Brown 72032 Black</p> <p><b><u>PAINT, SPRAY</u></b></p> <p style="padding-left: 20px;">350930 White 261900 Citrine White 830864 Black</p> <p><b><u>ADHESIVE</u></b></p> <p style="padding-left: 20px;">591014 Adhesive Loctite (1/3 oz.) 482338 Sealer, Silastic (3 oz.)</p>	<p><b><u>WIRING HARNESS PARTS</u></b></p> <p style="padding-left: 20px;">W10137680 Harness, Main W10155097 Cable, Board Connection W10157935 Harness, Switch 9762921 Harness, Communication 9763481 Harness, Ground Strap W10137678 Harness, Cooktop Tap Touch 313660 Clip, Ground Wire Grommet, Flexible 9756675 77mm W10177363 60mm 9757778 Bushing, Snap, Split 1" W10076020 Gasket 4449809 Screw 7103P027-60 Nut 4454842 Tie, Cable 4450800 Screw, Ground 3400015 Screw, Ground</p>	<p><b><u>Miscellaneous</u></b></p> <p style="padding-left: 20px;">9782676 Anti-Tip Assembly Filler, Counter Top W10113902A Black W10113903A White W10113901A Stainless</p>

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST