


# KitchenAid® 27" and 30" Electric Warming Oven

## PRODUCT MODEL NUMBERS

KEWD105H  
KEWD175H  
KEWV105M


**Electrical:** 120-volt, 60-Hz, AC-only, 15- or 20-amp. electrical supply. Use copper wire only. A time-delay fuse or circuit breaker and separate circuit is recommended.

## OVERALL DIMENSIONS



Oven Size	A Overall Width	B Recessed Width
27"	26-3/4"	25-1/4"
30"	29-3/4"	28-1/4"

## CABINET OPENING DIMENSIONS



Oven Size	A	B
27"	25-1/2"	27"
30"	28-1/2"	30"

Warming oven can be installed as a single or double installation or installed under a single oven. Two warming ovens under a single oven are shown.