




LOWER OVEN PARTS

For Models: GBD307PRQ01, GBD307PRB01, GBD307PRS01, GBD307PRY01

(Designer White) (Black) (S.Steel) (U. Silver)

30" BUILT-IN ELECTRIC
DOUBLE OVEN
CONVECTION-UPPER
SELF-CLEAN (GOLD LINE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS

For Models: GBD307PRQ01, GBD307PRB01, GBD307PRS01, GBD307PRY01


(Designer White) (Black) (S.Steel) (U. Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8303647	Literature Parts Installation Instructions Owners Manual (Sgl/DbI Oven)	7	8303099	Top, Chassis	27	4452337	Insulation, Bottom Vent
	8304075	English	8	8281236	Black	28	9760677	Deflector (Btm)
	8304076	French		3400805	Silver	29	9759242	Thermostat (TOD) (Temp.) SPST
	8302068	Tech Sheet (Oven)	9	4452158	Tube, Vent	30	9759713	Base, Chassis
	3191638	Safer Cooking Tips	10	4452165	Lens, Light	31	4448933	Retainer, Gasket
	9759133	Safer Cooking Tips	11	4452368	Oven Light Assy	32	4451747	Cover, Back
2		Trim, Side	12	4452166	Bulb, Light	33		Trim, Bottom
	8302919	RH White	13	4449809	Screw		8302948	White
	8302920	LH White	14	9759060	Frame, Front		8302947	Black
	8302917	RH Black	15	4455382	Gasket, Door	34	8302950	S.Steel
	8302918	LH Black	16	4449040	Screw		4449845	Support, Bracket
	8303209	LH S.Steel	17	4450118	Nut	FOLLOWING PARTS NOT ILLUSTRATED		
	8303210	RH S.Steel	18	4452152	Bracket, Mounting	INSULATION		
	8281236	Screw	19	4451478	Support, Insulation		4449316	Insulation, Wrap
3		Hinge Receiver	20	3196176	Screw		4450365	Insulation, Back
	4455605	Left Hand	21	4449154	Screw			
	4455606	Right Hand	22	3400832	Screw			
4	4448520	Bumper, Door	23	4455641	Side, Chassis (R.H. & L.H.)			
5	4452490	Spacer, Foam	24	4452234	Back, Chassis			
6	8302349	Divider, Vent	25		Liner, Oven (Not serviceable)			
			26	4455636	Sensor			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models: GBD307PRQ01, GBD307PRB01, GBD307PRS01, GBD307PRY01
(Designer White) (Black) (S.Steel) (U. Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models:GBD307PRQ01, GBD307PRB01, GBD307PRS01, GBD307PRY01
(Designer White) (Black) (S.Steel) (U. Silver)

Illus. No.	Part No.	DESCRIPTION
1	4449809	Screw
2	4449154	Screw
3		Hinge Receiver
	4455605	Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
5	3196176	Screw
6	8302349	Divider, Vent
7	8303099	Top, Chassis
8	4448444	Grommet
9	4452158	Tube, Vent
10	4452165	Lens, Light
11	4452368	Oven Light Assy
12	4452166	Bulb, Light
14	9759060	Frame, Front
15	4455382	Gasket, Door
16	4449040	Screw
17	4450118	Nut
18	3400832	Screw
19	4451478	Support, Insulation
21		Rail, Side
	8302793	Right Side
	8302794	Left Side
22	4455641	Side, Chassis (R.H. & L.H.)
23	4452234	Back, Chassis
24		Liner, Oven (Not serviceable)
25	4455636	Sensor
26	4452267	Vent, Center
27	9759242	Thermostat (TOD) (Temp.) SPST
28	4448933	Retainer, Gasket
29	4451747	Cover, Back
30	4449845	Support, Bracket


FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449316 Insulation, Wrap
4450365 Insulation, Back

OVEN DOOR PARTS

For Models:GBD307PRQ01, GBD307PRB01, GBD307PRS01, GBD307PRY01
(Designer White) (Black) (S.Steel) (U. Silver)



Illus. No.	Part No.	DESCRIPTION
1	8303700	Door Liner
2	9760577	Hinge, Door R.Hand (Yellow)
	9760578	L.Hand (Yellow)
3	4449259	Glass, Inner
4	8303810	Nameplate
5	8303878	Seal – Door
6	8302947	Trim, Bottom
7	9759225	Glass, Inner
8	4449743	Screw
9	4451040	Screw
10	4449809	Screw


Illus. No.	Part No.	DESCRIPTION
12		Door Glass Assy (Upper)
	8303306	White
	8303300	Black
	8303288	S.Steel
	8304177	Silver
	8303307	White
	8303301	Black
	8303289	S.Steel
	8304178	Silver

Illus. No.	Part No.	DESCRIPTION
13		Door Handle
	8302814	White
	8302813	Black
	8303164	S.Steel
14	8303167	Bracket, Handle
15	9759229	Bracket(2nd Glass)
16	9759230	Bracket(3rd Glass)
18	4451722	Insulation, door
19	4457103	Shield, Heat
20	4457132	Retainer, Glass
22	4457114	Shield, Heat

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LATCH PARTS

For Models:GBD307PRQ01, GBD307PRB01, GBD307PRS01, GBD307PRY01
(Designer White) (Black) (S.Steel) (U. Silver)




Illus. No.	Part No.	DESCRIPTION
1	9759525	Latch, Motorized

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: GBD307PRQ01, GBD307PRB01, GBD307PRS01, GBD307PRY01
 (Designer White) (Black) (S.Steel) (U. Silver)




Illus. No.	Part No.	DESCRIPTION
1	4448988	Cover, Fan
2	4456103	Element, Broil
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	4452153	Element, Bake
8	4449154	Screw
9	4451583	Fan, Convection
10	4452226	Blade, Fan
12	4452227	Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GBD307PRQ01, GBD307PRB01, GBD307PRS01, GBD307PRY01
 (Designer White) (Black) (S.Steel) (U. Silver)




Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	8302849	White
	8302848	Black
	8304153	Apollo Gray
2		Assy, Switch
	8303182	Black
	8303224	White
	8304151	Silver
3	8303883	Assy, Control
	4449745	Screw
	8301848	Latch, Sister Board
4	8304161	Control, Basket
5	4449745	Screw
6	8301848	Latch, Sister Board
7	8302877	Trim-Panel (Use on S.Steel model only)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: GBD307PRQ01, GBD307PRB01, GBD307PRS01, GBD307PRY01
 (Designer White) (Black) (S.Steel) (U. Silver)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Assembly, Vent
2	4455178	Elbow, Vent Top
3	4455177	Elbow, Vent Btm
4		Blower
	6610168	45MM Lower Oven
	4457289	65MM Upper Oven
	4455191	Bracket
5	4451758	Foam, Block
6	8300642	Transformer, Control

Illus. No.	Part No.	DESCRIPTION
7	8302390	Bracket, Support (Air Stop)
8	3400080	Screw
9	4450038	Screw
10	4449809	Screw
11	4449868	Block, Terminal
12	4449154	Screw
13	8303497	Vent, (Control Panel)

Illus. No.	Part No.	DESCRIPTION
14		Side, Control Top
	4451597	Right
	4451598	Left
15	9759135	Back, Control
16	4450551	Cover, Top Rear
17	4448664	Clamp
18	4452367	Cover, Top Front
19	9759243	Thermostat, Oven
20	8302143	Suppressor

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: GBD307PRQ01, GBD307PRB01, GBD307PRS01, GBD307PRY01
 (Designer White) (Black) (S.Steel) (U. Silver)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
 261869 Cord Brown
 72032 Black

PAINT, SPRAY

350930 White
 261900 Citrine White
 830864 Black

ADHESIVE

591014 Adhesive
 Loctite (1/3 oz.)
 482338 Sealer, Silastic
 (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828 Wire (12 Ga.
 150 c Black)
 242820 Wire (14 Ga.
 150 c Black)
 242821 Wire (14 Ga.
 150 c Blue)
 242822 Wire (14 Ga.
 150 c Brown)
 242830 Wire (14 Ga.
 200 c Brown)
 242823 Wire (14 Ga.
 150 c Green)
 242824 Wire (14 Ga.
 150 c Orange)
 242825 Wire (14 Ga.
 150 c Red)
 242831 Wire (14 Ga.
 200 c Red)
 242827 Wire (14 Ga.
 150 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

8301909 Harness, Wire
 (Latch, Lower)
 4449809 Screw
 8301777 Harness, Wire
 (Main)
 4450953 Conduit, Double
 4452400 Lead - Grnd Wire
 4450800 Screw
 4448664 Clamp
 4449809 Screw
 112432 Nut
 4452222 Spacer, Harness
 4454835 Tie, Cable
 4451761 Support, Wiring
 4454842 Tie, Cable

Miscellaneous

814381 Pin Hinge Kit
 4448950 Screw, Install (4)