




LOWER OVEN PARTS

For Models: GBD307PRS02
(Stainless)

30" BUILT-IN ELECTRIC
DOUBLE OVEN
CONVECTION-UPPER
SELF-CLEAN (GOLD LINE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS

For Models: GBD307PRS02

(Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8303647	Installation Instructions
		Owners Manual
	8304075	English
	8304076	French
	8302068	Tech Sheet (Oven)
		Safer Cooking Tips
	3191638	English
	9759133	French
2		Trim, Side
	W10145003	Right
	W10145002	Left
3		Hinge Receiver
	4455606	Right
	4455605	Left
4	W10105790	Bumper, Door
5	4452490	Spacer, Foam
6	8302349	Divider, Vent

Illus. No.	Part No.	DESCRIPTION
7	8303099	Top, Chassis
8		Screw
9	4452158	Tube, Vent
10	W10067870	Lens, Light
11	W10009930	Assembly, Oven Light
12	4452166	Bulb, Light
13	4449809	Screw
14	W10130368	Frame, Front
15	4455382	Gasket, Door
16	4449040	Screw
17	4450118	Nut
18	4452152	Bracket, Mounting
19	4451478	Support, Insulation
20	3196176	Screw
21	4449154	Screw
22	3400832	Screw
23	4455641	Side, Chassis
24	4452234	Back, Chassis

Illus. No.	Part No.	DESCRIPTION
25		Liner, Oven (Not serviceable)
26	4455636	Sensor
27	9760888	Latch, Motorized
28	9760677	Deflector, Bottom
29	9759242	Thermostat
30	9759713	Base, Chassis
31	4448933	Retainer, Gasket
32	4451747	Cover, Back
33	W10145001	Trim, Bottom Vent
34	4449845	Support, Bracket

FOLLOWING PARTS NOT ILLUSTRATED


INSULATION

4449316	Insulation, Wrap
4450365	Insulation, Back

UPPER OVEN PARTS

For Models: GBD307PRS02

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models: GBD307PRS02

(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	4449809	Screw
2	4449154	Screw
3		Hinge Receiver
	4455606	Right
	4455605	Left
4	W10105790	Bumper, Door
5	3196176	Screw
6	8302349	Divider, Vent
7	8303099	Top, Chassis
8	4448444	Grommet
9	4452158	Tube, Vent
10	W10067870	Lens, Light
11	W10009930	Assembly, Oven Light
12	4452166	Bulb, Light
13	9760888	Latch, Motorized
14	W10130368	Frame, Front
15	4455382	Gasket, Door
16	4449040	Screw
17	4450118	Nut
18	3400832	Screw
19	4451478	Support, Insulation
21		Rail, Side
	8302793	Right
	8302794	Left
22	4455641	Side, Chassis
23	4452234	Back, Chassis
24		Liner, Oven (Not serviceable)
25	4455636	Sensor
26	4452267	Vent, Center
27	9759242	Thermostat
28	4448933	Retainer, Gasket
29	4451747	Cover, Back
30	4449845	Support, Bracket


FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449316 Insulation, Wrap
4450365 Insulation, Back

OVEN DOOR PARTS

For Models: GBD307PRS02
(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9759413	Panel, Door
2		Hinge, Door
	9760577	Right
	9760578	Left
3	4449259	Glass, Inner Door
4	8303810	Nameplate
5	8303878	Seal, Foam
7	9759225	Glass, Inner Door

Illus. No.	Part No.	DESCRIPTION
8	4449743	Screw
9	4451040	Screw
10	4449809	Screw
11	9759228	Glass, Inner Door
12		Assembly
	W10151079	Upper
	W10151080	Lower
13	8303164	Door Handle


Illus. No.	Part No.	DESCRIPTION
14	W10136473	Bracket, Handle
15	9759229	Bracket(2nd Glass)
16	9759230	Bracket(3rd Glass)
17	4448520	Bumper, Door
18	4451722	Insulation, Door
19	4457103	Shield, Heat
20	4457132	Retainer, Glass
22	4457114	Shield, Heat

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: GBD307PRS02

(Stainless)




Illus. No.	Part No.	DESCRIPTION
1	4448988	Cover, Fan
2	9760771	Element, Broil
3	4448717	Rack, Oven
4	9760766	Element, Bake Convection
5	4449154	Screw
6	4451583	Fan, Convection
7	4452226	Blade, Fan
8	4452227	Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GBD307PRS02
(Stainless)




Illus. No.	Part No.	DESCRIPTION
1	8302848	Control Panel
2	W10112115	Assembly, Switch
3	8303883	Assembly, Control
4	W10153086	Backer, Control Panel
5	4449745	Screw
6	8301848	Latch, Sister Board
7	W10144998	Trim, Cooktop

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: GBD307PRS02

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Assembly, Vent
2	4455178	Elbow, Vent Top
3	4455177	Elbow, Vent Bottom
4		Blower
	W10016550	45MM Lower Oven
	4457289	65MM Upper Oven
	4455191	Bracket
5	4451758	Foam, Block

Illus. No.	Part No.	DESCRIPTION
6	8300642	Transformer, Control
7	8302390	Bracket, Support Air Stop
8	3400080	Screw
9	4450038	Screw
10	4449809	Screw
11	4449868	Block, Terminal
12	4449154	Screw
13	8303497	Vent, Control Panel

Illus. No.	Part No.	DESCRIPTION
14		Side, Control Top
	4451597	Right
	4451598	Left
15	9759135	Back, Control
16	4450551	Cover, Top Rear
17	4448664	Clamp
18	4452367	Cover, Top Front
19	9759243	Thermostat, Oven
20	8302143	Suppressor

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: GBD307PRS02

(Stainless)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	261869	Cord Brown
	72032	Black
<u>PAINT, SPRAY</u>		
	350930	White
	261900	Citrine White
	830864	Black
<u>ADHESIVE</u>		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
<u>SPLICING WIRES--25FT. LENGTH</u>		
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242827	Wire (14 Ga. 150 c Yellow)

Illus. No.	Part No.	DESCRIPTION
<u>WIRING HARNESS PARTS</u>		
	8301909	Harness, Wire (Latch, Lower)
	4449809	Screw
	8301777	Harness, Main
	4450953	Conduit, Double
	4452400	Lead, Ground Wire
	4450800	Screw
	4448664	Clamp
	4449809	Screw
	112432	Nut
	98997	Clip
	4452260	Spacer, Foam
	4454835	Tie, Cable
	4451761	Support, Wiring
	4454842	Tie, Cable
<u>Miscellaneous</u>		
	4448950	Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST