




# COOKTOP PARTS

For Models: GW395LEPB00, GW395LEPQ00, GW395LEPT00, GW395LEPS00  
(Black) (White) (Biscuit) (S.Steel)

30" Slide-In  
GAS OVEN  
NON-CONV




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9757447	Literature Parts	6	4453875WH	Trim-CkTop, SI White LH	17	9757766BL	Vent, Center Black
	9757455	Installation Instructions		4453875BT	Biscuit LH		9757766WH	White
	9757688	Use & Care Guide		4453875BL	Black LH		9757766BT	Biscuit
	9757680	Tech Sheet		4453875SS	S.Steel LH	18	4453865WH	Trim, Extension White
	3191638	Anti-Tip Instruct.		4453870WH	White RH		4453865BT	Biscuit
2	9759896	Safe Cooking Tips		4453870BT	Biscuit RH		4453865BL	Black
3	4454023	Burner Box		4453870BL	Black RH		4453865SS	S.Steel
	3179776	Bracket, Mounting Screw		4453870SS	S.Steel RH		3196160	Screw
4	9757830BT	Cooktop Biscuit	9	3192811	Bracket, Burner	19	9753939GB	Cap, Burner 14K (LF) Black
	9757830WH	White		3400843	Screw		9753939EP	Espresso
	9757830BL	Black	10	9756821	Support, Wiring		9753939GS	Mouse Grey
5	9756781BL	Wall, Side Cktp Black		4449809	Screw (2)		3191904	Black
	9756781WH	White	11	9756505BL	Dome Cap, Vent		3191905	Mouse Grey
	9756781BT	Biscuit	12	9759756BL	Grate, Burner Black (RH)		8273345	Espresso 6K (RF, LR)
	3179776	Screw		9759756EP	Espresso (RH)		3191898	Black
				9759756MG	Mouse Grey (RH)		3191899	Mouse Grey
				9759755BL	Black (LH)		8273343	Espresso
				9759755EP	Espresso (LH)		9759629	Cover, Cktp Rear
				9759755MG	Mouse Grey (LH)	23	3179776	Screw (4)
			16	9751984	Bi-Metal			
				3196160	Screw (2)			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: GW395LEPB00, GW395LEPQ00, GW395LEPT00, GW395LEPS00  
 (Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	8191141	White
	8191142	Biscuit
	8191143	Black
	8191144	S.Steel
3	9757264	Control, Migration
	9780271	Screw
4	9757119	Bracket, Console
	3179776	Screw (3)


Illus. No.	Part No.	DESCRIPTION
6	9759731	Bracket, Control
	3179776	Screw
8		Endcap
	9756614BT	Biscuit LH
	9756614WH	White LH
	9756614BL	Black LH
	9756611BT	Biscuit RH
	9756611WH	White RH
	9756611BL	Black RH
	3196172	Screw

Illus. No.	Part No.	DESCRIPTION
9		Knob
	9759732BL	Black
	9759732WH	White
	9759732BT	Biscuit
10	9758080	Module, Spark

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models: GW395LEPB00, GW395LEPQ00, GW395LEPT00, GW395LEPS00  
(Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS


For Models: GW395LEPB00, GW395LEPQ00, GW395LEPT00, GW395LEPS00  
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)	13	9757732	Shield, Heat	30	9756454	Bracket, GOC
	9757735WH	White		4449743	Screw (4)	31	9756453	Slide, GOC
	9757735BT	Biscuit	14	4455612	Frame, Front	37	8300802	Thermostat (TOD) (Temp.) SPST
	9757735BL	Black		4449040	Screw	43	4453981	Base, Chassis
	9757735SS	S.Steel (Left Hand)		4450118	Nut		9756637	Gasket
	9757734WH	White	15	4455382	Gasket, Door	49	4448933	Retainer, Gasket
	9757734BT	Biscuit	16	4453951	Deflector, Vent Bottom		4449154	Screw
	9757734BL	Black	17	4452152	Bracket, Mounting	50	4451747	Cover, Back
	9757734SS	S.Steel	18	9757685	Guide, Side Panel		4449809	Screw
	3400832	Screw	20		Oven, Side Panel	54		Vent, Bottom Upper
3		Hinge Receiver		9781907PB	Black		9756481WH	White
	4455605	Left Hand		9781907PW	White		9756481BT	Biscuit
	4455606	Right Hand		9781907PC	Biscuit		9756481BL	Black
4	4448520	Bumper, Door	22	8302474	Latch, Motorized		9756481SS	S.Steel
7	4455865	Top Chassis		4449154	Screw	55		Trim, Btm Vent
	4449809	Screw	23	9757807	Thermostat SPST (230)		9756485WH	White
8	4453761	Bracket, Vent Sprt					9756485BT	Biscuit
9	4453759	Tube, Vent	25	4455641	Side, Chassis (R.H. & L.H.)		9756485BL	Black
	3196176	Screw		4449809	Screw		9756485SS	S.Steel
10	4452165	Lens, Light	26	9759762	Back, Chassis	<b>FOLLOWING PARTS NOT ILLUSTRATED</b>		
11	4452368	Oven Light Assy		4449809	Screw	<b>INSULATION</b>		
12	4452166	Bulb, Light	27		Liner, Oven (Not serviceable)		9756817	Insulation, Wrap
			29	4455636	Sensor		9756470	Insulation, Back
				4449154	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR AND DRAWER PARTS

For Models: GW395LEPB00, GW395LEPQ00, GW395LEPT00, GW395LEPS00  
(Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# DOOR AND DRAWER PARTS

For Models: GW395LEPB00, GW395LEPQ00, GW395LEPT00, GW395LEPS00  
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
5		Glass, Door Front
	9759641	Black
	9759639	White
	9759640	Biscuit
8	9759642	S.Steel
		Handle, Door
	4448854	Black
	4448855	White
9	4448856	Biscuit
	8302094	Bracket, Central
		Hinge, Door
10	8300571	White RH
	8300572	White LH
11	312701	Foot, Rear
12	8302092	Bracket, Side
13	9757798	Panel, Drawer
15	9757706	Glass, Inner
16	4457114	Shield, Heat Btm
17	4449263	Glass, Inner (2)
18	4451722	Insulation, Door
19	4455618	Liner, Door
20	9757806	Drawer & Roller
21	3196037	Foot, Front
	4449743	Screw
22	422604	Roller, Drawer
23	9759743	Retainer, Door
24		Front, Drawer
	4453921WH	White
	4453921BL	Black
	4453921BT	Biscuit
	4453921SS	S.Steel
25		Bracket, Handle
	9763497	R. Hand
	9763496	L. Hand
	4451040	Screw
26		Handle, Drawer
	9756674WH	White
	9756674BT	Biscuit
	9756674BL	Black
28	4450863	Retainer, Clip
32	9756673	Guide, Roller
33	9757707	Shield, Heat Top

# TOP VENTING PARTS

For Models: GW395LEPB00, GW395LEPQ00, GW395LEPT00, GW395LEPS00  
 (Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
1	9758810	Front, Air Duct
	4449040	Screw, 8-18 x 3/8
2		Top, Air Duct
	9757827	L.Hand
	9757828	R.Hand
3	8300223	Blower
	4455352	Bracket
	4449809	Screw (4)
4	4451758	Block, Foam
5		Corner, Air Duct
	9756639	R.Hand
	9756638	L.Hand
6	9757117BL	Vent, (Control Panel)
	4450038	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERNAL OVEN PARTS

For Models: GW395LEPB00, GW395LEPQ00, GW395LEPT00, GW395LEPS00  
(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	9752980	Shield, Flame
	3196176	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	9757779	Fitting, Broiler
	3196176	Screw
6	4448717	Rack, Oven
8	4453957	Pan Support, Bake

Illus. No.	Part No.	DESCRIPTION
9	4454048	Electrode, Bake
	3196385	Screw
10	4454047	Burner, Bake Log
	3196176	Screw
11	9752737	Shield, Oven
	3196176	Screw
12	4453984	Shield, Bake Flame
	3196176	Screw


Illus. No.	Part No.	DESCRIPTION
13	4453999	Valve, Assy
	3400080	Screw
14	9756831	Tube, Broil
15	9757700	Burner, Broil
16	8054129	Ignitor, Broil
	3196385	Screw
17	4454009	Cover, Ignitor
	3196176	Screw
18	4453920	Pan, Oven Bottom

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# COOKTOP BURNER PARTS

For Models: GW395LEPB00, GW395LEPQ00, GW395LEPT00, GW395LEPS00  
 (Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Burner Base w/Orifice
	9782447	Small (2)
	9782448	Large
	9782449	Turbi
2	9756827	Tubing, Burner(RF)
3	9756828	Tubing, Burner(RR)
4	9759759	Tubing, Burner(LF)
5	9756829	Tubing, Burner(LR)

Illus. No.	Part No.	DESCRIPTION
6	4456818	Valve, Turbi
7	4456816	Valve, Burner Small (2)
8	4456817	Valve, Burner Large
9	9756822	Spark Switch & Harness Assembly
10	4454028	Tube, Manifold

Illus. No.	Part No.	DESCRIPTION
11	9756803	Manifold
	3179776	Screw
14	8523704	Bolt, Valve (4)
18	4453754	Tubing GDS to Manifold
21		Head, Burner
	9759894	Small
	4455981	Large
	4455849	Turbi
22	3368921	Screw, 7-18 x .750

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: GW395LEPB00, GW395LEPQ00, GW395LEPT00, GW395LEPS00  
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**PAINT, TOUCH-UP (1/2oz.)**

72017 White  
 261869 Cord Brown  
 72032 Black

**PAINT, SPRAY**

350930 White  
 261900 Citrine White  
 830864 Black

**ADHESIVE**

591014 Adhesive  
 Loctite (1/3 oz.)  
 482338 Sealer, Silastic  
 (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**SPLICING WIRES--25FT.**

**LENGTH**

242828 Wire (12 Ga.  
 150 c Black)  
 242820 Wire (14 Ga.  
 150 c Black)  
 242821 Wire (14 Ga.  
 150 c Blue)  
 242822 Wire (14 Ga.  
 150 c Brown)  
 242830 Wire (14 Ga.  
 200 c Brown)  
 242823 Wire (14 Ga.  
 150 c Green)  
 242824 Wire (14 Ga.  
 150 c Orange)  
 242829 Wire (12 Ga.  
 150 c Red)  
 242825 Wire (14 Ga.  
 150 c Red)  
 242831 Wire (14 Ga.  
 200 c Red)  
 242826 Wire (14 Ga.  
 150 c White)  
 242827 Wire (14 Ga.  
 150 c Yellow)  
 242832 Wire (14 Ga.  
 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**WIRING HARNESS PARTS**

9759900 Harness, Wire  
 (Main)  
 9756892 Harness, Wire  
 (Cooktop Power)  
 9756920 Harness, Wire  
 Bake/Broil Ignit.  
 9757727 Harness, Wire  
 (Cooktop Right)  
 313660 Clip, Ground Wire  
 4448664 Clamp  
 4449809 Screw  
 112432 Nut  
 4450800 Screw, Ground  
 4452222 Spacer, Harness  
 3400015 Screw, Ground

**Miscellaneous**

814381 Hinge Pin Kit  
 4448950 Screw, Install (4)  
 9782676 Anit-Tip Assy  
 9757427 Kit, Orific (LP)  
 Filler,Counter Top  
 9757785WH White  
 9757785BL Black  
 9757785BT Biscuit  
 9758677 Cord, Power