

COOKTOP PARTS

For Models: GW395LEPB02, GW395LEPQ02, GW395LEPT02, GW395LEPS02


(Black)

(White)

(Biscuit)

(S.Steel)

30" Slide-In
GAS OVEN
NON-CONV



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	9761413	Installation Instructions
	9762258	Use & Care Guide
	9761386	Tech Sheet
	9757680	Anti-Tip Instruct.
	3191638	Safe Cooking Tips
	9759133	Safe Cooking Tips
2	9759523	Burner Box
3	4454023	Bracket, Mounting
4		Cooktop
	9760428BT	Biscuit
	9760428WH	White
	9760428BL	Black
5	3400843	Screw
6		Trim-CkTop, SI
	9759531WH	White LH
	9759531BT	Biscuit LH
	9759531BL	Black LH
	9759531SS	S.Steel LH
	9759530WH	White RH
	9759530BT	Biscuit RH
	9759530BL	Black RH
	9759530SS	S.Steel RH

Illus. No.	Part No.	DESCRIPTION
7	3196537	Screw
8	4453989	Shield, Heat
9	3192811	Bracket, Burner
10	9756821	Support, Wiring
11	9756505BL	Dome Cap, Vent
12		Grate, Burner
	9759756BL	Black (RH)
	9759756EP	Espresso (RH)
	9759756MG	Mouse Grey (RH)
	9759755BL	Black (LH)
	9759755EP	Espresso (LH)
	9759755MG	Mouse Grey (LH)
13	4449809	Screw
14	3196160	Screw
16	9759944	Thermostat (60c)
17		Vent, Center
	9760224BL	Black
	9760224WH	White
	9760224BT	Biscuit

Illus. No.	Part No.	DESCRIPTION
18		Trim, Extension
	9760520WH	White
	9760520BT	Biscuit
	9760520BL	Black
	9760520SS	S.Steel
19		Cap, Burner
		14K (LF)
	9753939GB	Black
	9753939EP	Espresso
	9753939GS	Mouse Grey
		12.5K (RR)
	3191904	Black
	3191905	Mouse Grey
	8273345	Espresso
		6K (RF, LR)
	3191898	Black
	3191899	Mouse Grey
	8273343	Espresso
23	9759629	Cover, Cktp Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS


For Models: GW395LEPB02, GW395LEPQ02, GW395LEPT02, GW395LEPS02

(Black)

(White)

(Biscuit)

(S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	9756506WH	White
	9756506BT	Biscuit
	9756506BL	Black
	9756506SS	S.Steel
3	9760013	Control, Migration
4	9757119	Bracket, Console
5	3196537	Screw
6	9759731	Bracket, Control

Illus. No.	Part No.	DESCRIPTION
7	9757409	Support, Gas Valve
8		Endcap
	9756614BT	Biscuit LH
	9756614WH	White LH
	9756614BL	Black LH
	9756611BT	Biscuit RH
	9756611WH	White RH
	9756611BL	Black RH

Illus. No.	Part No.	DESCRIPTION
9		Knob
	9759941BL	Black
	9759941WH	White
	9759941BT	Biscuit
10	9758080	Module, Spark
11	9780271	Screw
12	3196172	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: GW395LEPB02, GW395LEPQ02, GW395LEPT02, GW395LEPS02

(Black)

(White)

(Biscuit)

(S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: GW395LEPB02, GW395LEPQ02, GW395LEPT02, GW395LEPS02

(Black)

(White)

(Biscuit)

(S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)	15	4455382	Gasket, Door	37	8300802	Thermostat (TOD) (Temp.) SPST
	9757735WH	White	16	4453951	Deflector, Vent Bottom	39	9757070	Plate, Relectance
	9757735BT	Biscuit	17	4452152	Bracket, Mounting	43	4453981	Base, Chassis
	9757735BL	Black	18	9757685	Guide, Side Panel		9756637	Gasket
	9757735SS	S.Steel (Left Hand)	19	9757811	Brace, SidePanel	49	4448933	Retainer, Gasket
	9757734WH	White	20		Oven, Side Panel	50	4451747	Cover, Back
	9757734BT	Biscuit		9760723PB	Black	51	4449809	Screw
	9757734BL	Black		9760723PW	White	54		Vent, Bottom Upper
	9757734SS	S.Steel		9760723PC	Biscuit		9756481WH	White
2	3400832	Screw	22	9760888	Latch, Motorized		9756481BT	Biscuit
3		Hinge Receiver	23	9757807	Thermostat SPST (230)		9756481BL	Black
	4455605	Left Hand	24	8053971	Brace, Main Back		9756481SS	S.Steel
	4455606	Right Hand	25	4455641	Side, Chassis (R.H. & L.H.)	55		Trim, Btm Vent
4	4448520	Bumper, Door					9756485WH	White
5	3196160	Screw	26	9759762	Back, Chassis		9756485BT	Biscuit
6	9757461	Bracket, Side Panel	27		Liner, Oven (Not serviceable)		9756485BL	Black
7	8303099	Top Chassis					9756485SS	S.Steel
8	9759469	Bracket, Vent Sprt	29	4455636	Sensor	FOLLOWING PARTS NOT ILLUSTRATED		
9	9761062	Tube, Vent	30	9756454	Bracket, GOC	INSULATION		
10	4452165	Lens, Light	31	9760223	Slide, GOC		9756817	Insulation, Wrap
11	4452368	Oven Light Assy	32	3196537	Screw		9756470	Insulation, Back
12	4452166	Bulb, Light	33	9759890	Clip, Side Panel			
13	9757732	Shield, Heat	34	9757717	Insulation			
14	9759060	Frame, Front						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models: GW395LEPB02, GW395LEPQ02, GW395LEPT02, GW395LEPS02

(Black)

(White)

(Biscuit)

(S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: GW395LEPB02, GW395LEPQ02, GW395LEPT02, GW395LEPS02

(Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	
5		Glass, Door Front	
	9759641	Black	
	9759639	White	
	9759640	Biscuit	
6	9759642	S.Steel	
	3196537	Screw	
	7	9759635	Spacer, Glass
		8	
4448854	Black		
4448855	White		
9	4448856	Biscuit	
	8302094	Bracket, Central	
	10		Hinge, Door
9760571		White RH	
9760572		White LH	
11	9761935	Foot, Rear	
12	8302092	Bracket, Side	
13	9760592	Panel, Drawer	
15	9757706	Glass, Inner	
16	4457114	Shield, Heat Btm	
17	4449263	Glass, Inner (2)	
18	4451722	Insulation, Door	
19	9759413	Liner, Door	
20	9757806	Drawer & Roller	
21	3196037	Foot, Front	
22	422604	Roller, Drawer	
23	4457132	Retainer, Glass	
24		Front, Drawer	
	4453921WH	White	
	4453921BL	Black	
	4453921BT	Biscuit	
	4453921SS	S.Steel	
25		Bracket, Handle	
	9763497	R. Hand	
	9763496	L. Hand	
	4451040	Screw	
26		Handle, Drawer	
	9756674WH	White	
	9756674BT	Biscuit	
28	9756674BL	Black	
	4450863	Retainer, Clip	
29		Track, Drawer	
	9756837	R.Side	
	9756839	L.Side	
30		Side, Base	
	9759953	R.Side	
	9759954	L.Side	
31	4449743	Screw	
32	9756673	Guide, Roller	
33	9757707	Shield, Heat Top	
34	4451040	Screw	
35	4449809	Screw	

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS


For Models: GW395LEPB02, GW395LEPQ02, GW395LEPT02, GW395LEPS02

(Black)

(White)

(Biscuit)

(S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	9758810	Front, Air Duct
2		Top, Air Duct
	9757827	L.Hand
	9757828	R.Hand
3	9759320	Blower
4	4451758	Block, Foam
5		Corner, Air Duct
	9756639	R.Hand
	9756638	L.Hand
6	9757117BL	Vent, (Control Panel)
7	4450038	Screw
8	4449809	Screw
9	4449040	Screw
10	4455352	Bracket, Blower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS


For Models: GW395LEPB02, GW395LEPQ02, GW395LEPT02, GW395LEPS02

(Black)

(White)

(Biscuit)

(S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	9752980	Shield, Flame
2	3196176	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	9757779	Fitting, Broiler
6	3196176	Screw

Illus. No.	Part No.	DESCRIPTION
7	4448717	Rack, Oven
8	4453957	Pan Support, Bake
9	9760229	Electrode, Bake
10	9760228	Burner, Bake Log
11	9752737	Shield, Oven
12	4453984	Shield, Bake Flame

Illus. No.	Part No.	DESCRIPTION
13	9763716	Valve, Assy
14	9756831	Tube, Broil
15	9757700	Burner, Broil
16	8054129	Ignitor, Broil
17	4454009	Cover, Ignitor
18	4453920	Pan, Oven Bottom
19	3196385	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP BURNER PARTS


For Models: GW395LEPB02, GW395LEPQ02, GW395LEPT02, GW395LEPS02

(Black)

(White)

(Biscuit)

(S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Burner Base w/Orifice
	9782447	Small (2)
	9782448	Large
	9782449	Turbi
2	9756827	Tubing, Burner(RF)
3	9756828	Tubing, Burner(RR)
4	9759759	Tubing, Burner(LF)
5	9756829	Tubing, Burner(LR)
6	4456818	Valve, Turbi

Illus. No.	Part No.	DESCRIPTION
7	4456816	Valve, Burner Small (2)
8	4456817	Valve, Burner Large
9	9756822	Spark Switch & Harness Assembly
10	4453755	Tube, Manifold
11	9756803	Manifold
12	3196537	Screw

Illus. No.	Part No.	DESCRIPTION
14	8523704	Bolt, Valve (4)
18	4453754	Tubing GDS to Manifold
21		Head, Burner
	9759894	Small (2)
	4455981	Large (1)
	4455849	Turbi (1)
22	3368921	Screw, 7-18 x .750

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: GW395LEPB02, GW395LEPQ02, GW395LEPT02, GW395LEPS02

(Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828 Wire (12 Ga.
150 c Black)
242820 Wire (14 Ga.
150 c Black)
242821 Wire (14 Ga.
150 c Blue)
242822 Wire (14 Ga.
150 c Brown)
242830 Wire (14 Ga.
200 c Brown)
242823 Wire (14 Ga.
150 c Green)
242824 Wire (14 Ga.
150 c Orange)
242829 Wire (12 Ga.
150 c Red)
242825 Wire (14 Ga.
150 c Red)
242831 Wire (14 Ga.
200 c Red)
242826 Wire (14 Ga.
150 c White)
242827 Wire (14 Ga.
150 c Yellow)
242832 Wire (14 Ga.
200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

9760533 Harness, Wire
(Main)
9756892 Harness, Wire
(Cooktop Power)
9756920 Harness, Wire
Bake/Broil Ignit.
313660 Clip, Ground Wire
4448664 Clamp
4449809 Screw
112432 Nut
4450800 Screw, Ground
4452222 Spacer, Harness
3400015 Screw, Ground

Miscellaneous

814381 Hinge Pin Kit
4448950 Screw, Install (4)
9756609 Gasket, 19 x 388
9758677 Power Cord
9782676 Anit-Tip Assy
9757427 Kit, Orific (LP)
Filler,Counter Top
9757785WH White
9757785BL Black
9757785BT Biscuit