




COOKTOP PARTS

For Models: GW395LEPB03, GW395LEPQ03, GW395LEPT03, GW395LEPS03
 (Black) (White) (Biscuit) (S.Steel)

30" Slide-In
 GAS OVEN
 NON-CONV



Illus. No.	Part No.	DESCRIPTION
1	9761413	Literature Parts Installation Instructions
	W10086240	Use & Care Guide
	9761386	Tech Sheet
	9757680	Anti-Tip Instruct.
	3191638	Safe Cooking Tips
	9759133	Safe Cooking Tips
2	9759523	Burner Box
3	4454023	Bracket, Mounting
4		Cooktop
	9760428BT	Biscuit
	9760428WH	White
	9760428BL	Black
5	3400843	Screw
6		Trim-CkTop, SI
	9759531WH	White LH
	9759531BT	Biscuit LH
	9759531BL	Black LH
	9759531SS	S.Steel LH
	9759530WH	White RH
	9759530BT	Biscuit RH
	9759530BL	Black RH
	9759530SS	S.Steel RH


Illus. No.	Part No.	DESCRIPTION
7	3196537	Screw
8	4453989	Shield, Heat
9	3192811	Bracket, Burner
10	9756821	Support, Wiring
11	9756505BL	Dome Cap, Vent
12		Grate, Burner
	9759756BL	Black (RH)
	9759756EP	Espresso (RH)
	9759756MG	Mouse Grey (RH)
	9759755BL	Black (LH)
	9759755EP	Espresso (LH)
	9759755MG	Mouse Grey (LH)
13	4449809	Screw
14	3196160	Screw
16	9759944	Thermostat (60c)
17		Vent, Center
	9760224BL	Black
	9760224WH	White
	9760224BT	Biscuit

Illus. No.	Part No.	DESCRIPTION
18		Trim, Extension
	9760520WH	White
	9760520BT	Biscuit
	9760520BL	Black
	9760520SS	S.Steel
19		Cap, Burner
		14K (LF)
	9753939GB	Black
	9753939EP	Espresso
	9753939GS	Mouse Grey
		12.5K (RR)
	3191904	Black
	3191905	Mouse Grey
	8273345	Espresso
		6K (RF, LR)
	3191898	Black
	3191899	Mouse Grey
	8273343	Espresso
23	9759629	Cover, Cktp Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GW395LEPB03, GW395LEPQ03, GW395LEPT03, GW395LEPS03
(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	9756506WH	White
	9756506BT	Biscuit
	9756506BL	Black
	9756506SS	S.Steel
3	9760013	Control, Migration
4	9757119	Bracket, Console
5	3196537	Screw
6	9759731	Bracket, Control


Illus. No.	Part No.	DESCRIPTION
7	9757409	Support, Gas Valve
8		Endcap
	9756614BT	Biscuit LH
	9756614WH	White LH
	9756614BL	Black LH
	9756611BT	Biscuit RH
	9756611WH	White RH
	9756611BL	Black RH

Illus. No.	Part No.	DESCRIPTION
9		Knob
	9759941BL	Black
	9759941WH	White
	9759941BT	Biscuit
10	9758080	Module, Spark
11	9780271	Screw
12	3196172	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: GW395LEPB03, GW395LEPQ03, GW395LEPT03, GW395LEPS03
 (Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: GW395LEPB03, GW395LEPQ03, GW395LEPT03, GW395LEPS03
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)	15	4455382	Gasket, Door	39	9757070	Plate, Relectance
	9757735WH	White	16	4453951	Deflector, Vent Bottom	43	4453981	Base, Chassis
	9757735BT	Biscuit					9756637	Gasket
	9757735BL	Black	17	4452152	Bracket, Mounting	49	4448933	Retainer, Gasket
	9757735SS	S.Steel (Left Hand)	18	9757685	Guide, Side Panel	50	4451747	Cover, Back
	9757734WH	White	19	9757811	Brace, SidePanel	51	4449809	Screw
	9757734BT	Biscuit	20		Oven, Side Panel	54		Vent, Bottom Upper
	9757734BL	Black		9760723PB	Black		9756481WH	White
	9757734SS	S.Steel		9760723PW	White		9756481BT	Biscuit
2	3400832	Screw		9760723PC	Biscuit		9756481BL	Black
3		Hinge Receiver	22	9760888	Latch, Motorized		9756481SS	S.Steel
	4455605	Left Hand	23	9757807	Thermostat SPST (230)	55		Trim, Btm Vent
	4455606	Right Hand	24	8053971	Brace, Main Back		9756485WH	White
4	9760749	Bumper, Door	25	4455641	Side, Chassis (R.H. & L.H.)		9756485BT	Biscuit
5	3196160	Screw	26	9759762	Back, Chassis		9756485BL	Black
6	9757461	Bracket, Side Panel	27		Liner, Oven (Not serviceable)		9756485SS	S.Steel
7	8303099	Top Chassis	29	4455636	Sensor	FOLLOWING PARTS NOT ILLUSTRATED		
8	9759469	Bracket, Vent Sprt	30	9756454	Bracket, GOC	INSULATION		
9	9761062	Tube, Vent	31	9760223	Slide, GOC		9756817	Insulation, Wrap
10	W10067870	Lens, Light	32	3196537	Screw		9756470	Insulation, Back
11	W10009930	Oven Light Assy	33	9759890	Clip, Side Panel			
12	4452166	Bulb, Light	34	9757717	Insulation			
13	9757732	Shield, Heat	37	8300802	Thermostat (TOD) (Temp.) SPST			
14	9760756	Frame, Front						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: GW395LEPB03, GW395LEPQ03, GW395LEPT03, GW395LEPS03
(Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models: GW395LEPB03, GW395LEPQ03, GW395LEPT03, GW395LEPS03
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
5	9759641	Glass, Door Front Black
	9759639	White
	9759640	Biscuit
	9759642	S.Steel
6	3196537	Screw
7	9759635	Spacer, Glass
8		Handle, Door
	4448854	Black
	4448855	White
	4448856	Biscuit
9	9759230	Bracket, Central
10		Hinge, Door
	9760571	White RH
	9760572	White LH
11	9761935	Foot, Rear
12	9759229	Bracket, Side
13	9760592	Panel, Drawer
15	9757706	Glass, Inner
16	4457114	Shield, Heat Btm
17	9759225	Glass, Inner (2)
18	4451722	Insulation, Door
19	9759413	Liner, Door
20	9757806	Drawer & Roller
21	3196037	Foot, Front
22	422604	Roller, Drawer
23	4457132	Retainer, Glass
24		Front, Drawer
	4453921WH	White
	4453921BL	Black
	4453921BT	Biscuit
	4453921SS	S.Steel
25		Bracket, Handle
	9763497	R. Hand
	9763496	L. Hand
	4451040	Screw
26		Handle, Drawer
	9756674WH	White
	9756674BT	Biscuit
	9756674BL	Black
28	4450863	Retainer, Clip
29		Track, Drawer
	9756837	R.Side
	9756839	L.Side
30		Side, Base
	9759953	R.Side
	9759954	L.Side
31	4449743	Screw
32	9756673	Guide, Roller
33	4457103	Shield, Heat Top
34	4451040	Screw
35	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: GW395LEPB03, GW395LEPQ03, GW395LEPT03, GW395LEPS03
 (Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
1	9758810	Front, Air Duct
2		Top, Air Duct
	9757827	L.Hand
	9757828	R.Hand
3	9759320	Blower
4	4451758	Block, Foam
5		Corner, Air Duct
	9756639	R.Hand
	9756638	L.Hand
6	9757117BL	Vent, (Control Panel)
7	4450038	Screw
8	4449809	Screw
9	4449040	Screw
10	4455352	Bracket, Blower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: GW395LEPB03, GW395LEPQ03, GW395LEPT03, GW395LEPS03
 (Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	9752980	Shield, Flame
2	3196176	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	9757779	Fitting, Broiler
6	3196176	Screw
7	4448717	Rack, Oven
8	4453957	Pan Support, Bake


Illus. No.	Part No.	DESCRIPTION
9	9760229	Electrode, Bake
10	9760228	Burner, Bake Log
11	9752737	Shield, Oven
12	4453984	Shield, Bake Flame
13	9763716	Valve, Assy

Illus. No.	Part No.	DESCRIPTION
14	9756831	Tube, Broil
15	9757700	Burner, Broil
16	8054129	Ignitor, Broil
17	4454009	Cover, Ignitor
18	4453920	Pan, Oven Bottom
19	3196385	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP BURNER PARTS

For Models: GW395LEPB03, GW395LEPQ03, GW395LEPT03, GW395LEPS03
 (Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Burner Base w/Orifice
	9782447	Small (2)
	9782448	Large
	9782449	Turbi
2	9756827	Tubing, Burner(RF)
3	9756828	Tubing, Burner(RR)
4	9759759	Tubing, Burner(LF)
5	9756829	Tubing, Burner(LR)
6	4456818	Valve, Turbi

Illus. No.	Part No.	DESCRIPTION
7	4456816	Valve, Burner Small (2)
8	4456817	Valve, Burner Large
9	9756822	Spark Switch & Harness Assembly
10	4453755	Tube, Manifold
11	9756803	Manifold

Illus. No.	Part No.	DESCRIPTION
12	3196537	Screw
14	8523704	Bolt, Valve (4)
18	4453754	Tubing GDS to Manifold
21		Head, Burner
	9759894	Small (2)
	4455981	Large (1)
	4455849	Turbi (1)
	3368921	Screw, 7-18 x .750

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: GW395LEPB03, GW395LEPQ03, GW395LEPT03, GW395LEPS03
 (Black) (White) (Biscuit) (S.Steel)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<p><u>PAINT, TOUCH-UP (1/2oz.)</u></p> <p>72017 White 261869 Cord Brown 72032 Black</p> <p><u>PAINT, SPRAY</u></p> <p>350930 White 261900 Citrine White 830864 Black</p> <p><u>ADHESIVE</u></p> <p>591014 Adhesive Loctite (1/3 oz.) 482338 Sealer, Silastic (3 oz.)</p>	<p><u>SPLICING WIRES--25FT.</u></p> <p><u>LENGTH</u></p> <p>242828 Wire (12 Ga. 150 c Black) 242820 Wire (14 Ga. 150 c Black) 242821 Wire (14 Ga. 150 c Blue) 242822 Wire (14 Ga. 150 c Brown) 242830 Wire (14 Ga. 200 c Brown) 242823 Wire (14 Ga. 150 c Green) 242824 Wire (14 Ga. 150 c Orange) 242829 Wire (12 Ga. 150 c Red) 242825 Wire (14 Ga. 150 c Red) 242831 Wire (14 Ga. 200 c Red) 242826 Wire (14 Ga. 150 c White) 242827 Wire (14 Ga. 150 c Yellow) 242832 Wire (14 Ga. 200 c Yellow)</p>	<p><u>WIRING HARNESS PARTS</u></p> <p>9760533 Harness, Wire (Main) 9756892 Harness, Wire (Cooktop Power) 9756920 Harness, Wire Bake/Broil Ignit. 313660 Clip, Ground Wire 4448664 Clamp 4449809 Screw 112432 Nut 4450800 Screw, Ground 4452222 Spacer, Harness 3400015 Screw, Ground</p> <p><u>Miscellaneous</u></p> <p>814381 Hinge Pin Kit 4448950 Screw, Install (4) 9756609 Gasket, 19 x 388 9758677 Power Cord 9782676 Anit-Tip Assy 9757427 Kit, Orific (LP) Filler,Counter Top 9757785WH White 9757785BL Black 9757785BT Biscuit</p>

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST