




COOKTOP PARTS

For Models: GY396LXPB02, GY396LXPQ02, GY396LXPT02, GY396LXPS02
 (Black) (White) (Biscuit) (S.Steel)

30" Slide-In
 ELECTRIC OVEN
 SELF CLEAN




Illus. No.	Part No.	DESCRIPTION
1	9762035	Literature Parts Installation Instructions
	9762257	Use & Care Guide
	9761388	Tech Sheet
	9757680	Anti-Tip Instruct.
	3191638	Safe Cooking Tips
	9759133	Safe Cooking Tips
3	4454023	Bracket, Mounting
4		Cooktop
	9756788BT	Biscuit
	9756788WH	White
	9762069BL	Black
5	4453764	Clip, Ceran (2)
6		Trim-CkTop, SI
	9759531WH	White LH
	9759531BT	Biscuit LH
	9759531BL	Black LH
	9759531SS	S.Steel LH
	9759530WH	White RH
	9759530BT	Biscuit RH
	9759530BL	Black RH
	9759530SS	S.Steel RH
7		Switch, Infinite
	9750638	LR, RF
	9750639	RR
	9750641	LF
8	8523739	Light, Indicator
9	9759243	Thermostat (120c)
10	9756821	Support, Wiring
11	4449809	Screw (2)
12		Element, Surface
	8523698	1200W LR,RF
	8523696	1800W RR
	8523692	2500W LF
13	9757800	Bracket, Front Support
14	3196537	Screw
15	9759944	Thermostat (60c)
16	3196160	Screw (2)
17	9758799	Bracket, Ind. Lamp
18		Trim, Extension
	9760520WH	White
	9760520BT	Biscuit
	9760520BL	Black
	9760520SS	S.Steel
19	9759094	Spring, Locator
20	9759963	Bracket, Rear Sprt
21	8285962	Rail, Element (2)
22	246119	Screw
23	9759628	Cover, Cktp Rear
24	9756450	Gasket

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GY396LXPB02, GY396LXPQ02, GY396LXPT02, GY396LXPS02
 (Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Control Panel	8		Endcap	9		Knob
	8191145	White		9756614BT	Biscuit LH		9756659BL	Black
	8191146	Biscuit		9756614WH	White LH		9756659WH	White
	8191147	Black		9756614BL	Black LH		9756659BT	Biscuit
	8191148	S.Steel		9756611BT	Biscuit RH	10	3196537	Screw
3	9757476	Control, Migration		9756611WH	White RH	11	9780271	Screw
4	9757119	Bracket, Console		9756611BL	Black RH	12	311865	Screw
5	3196068	Lens, Ind. (2)		3196172	Screw			
6	9757410	Bracket, Control						
7	8523265	Housing, Ind. Lt.						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: GY396LXPB02, GY396LXPQ02, GY396LXPT02, GY396LXPS02
(Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: GY396LXPB02, GY396LXPQ02, GY396LXPT02, GY396LXPS02
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)	15	W10074200	Gasket, Door	43	9759713	Base, Chassis
	9757735WH	White	16	4453951	Deflector, Vent Bottom	49	4448933	Retainer, Gasket
	9757735BT	Biscuit	17	4452152	Bracket, Mounting	50	4451747	Cover, Back
	9757735BL	Black	18	9757685	Guide, Side Panel	54		Vent, Bottom Upper
	9757735SS	S.Steel (Left Hand)	19	4451478	Support, Insulation		9756481WH	White
	9757734WH	White	20		Body, Side		9756481BT	Biscuit
	9757734BT	Biscuit		9760723PB	Black		9756481BL	Black
	9757734BL	Black		9760723PW	White	55	9756481SS	S.Steel
	9757734SS	S.Steel		9760723PC	Biscuit			Trim, Btm Vent
2	3400832	Screw	21	9757461	Bracket, Side Panel		9756485WH	White
3		Hinge Receiver	22	9760888	Latch, Motorized		9756485BT	Biscuit
	4455605	Left Hand	23	341196	Thermostat SPST (205)		9756485BL	Black
	4455606	Right Hand	24	9757811	Brace, Side Panel		9756485SS	S.Steel
4	9760749	Bumper, Door	25	4455641	Side, Chassis (R.H. & L.H.)	FOLLOWING PARTS NOT ILLUSTRATED		
5	3196537	Screw	26	4452234	Back, Chassis	INSULATION		
6	3196160	Screw	27		Liner, Oven (Not serviceable)		9756817	Insulation, Wrap
7	8303099	Top Chassis	28	9759890	Clip, Side Panel		9756470	Insulation, Back
8	4449809	Screw	29	4455636	Sensor			
9	4452158	Tube, Vent	30	9757717	Insulation			
10	W10067870	Lens, Light	31	3196176	Screw			
11	W10009930	Oven Light Assy						
12	4452166	Bulb, Light						
14	9760756	Frame, Front						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: GY396LXPB02, GY396LXPQ02, GY396LXPT02, GY396LXPS02
(Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models: GY396LXPB02, GY396LXPQ02, GY396LXPT02, GY396LXPS02
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
5		Glass, Door Front
	9759641	Black
	9759639	White
	9759640	Biscuit
	9759642	S.Steel
6	3400805	Screw
7	9759635	Spacer, Glass
8		Handle, Door
	4448854	Black
	4448855	White
	4448856	Biscuit
9	9759230	Bracket, Central
10		Hinge, Door
	9760571	White RH
	9760572	White LH
11	9761935	Foot, Rear
12	9759229	Bracket, Side
13	9760592	Panel, Drawer
14	4451040	Screw
15	9757706	Glass, Inner
16	4457114	Shield, Heat Btm
17	9759225	Glass, Inner (2)
18	4451722	Insulation, Door
19	9759413	Liner, Door
20	9757806	Drawer & Roller
21	3196037	Foot, Front
22	422604	Roller, Drawer
23	4457132	Retainer, Glass
24		Front, Drawer
	4453921WH	White
	4453921BL	Black
	4453921BT	Biscuit
	4453921SS	S.Steel
25	4450813	Bracket, Handle
26		Handle, Drawer
	9756674WH	White
	9756674BT	Biscuit
	9756674BL	Black
27		Side, Base
	9759953	R.Side
	9759954	L.Side
28	4450863	Retainer, Clip
29		Track, Drawer
	9756837	R.Side
	9756839	L.Side
30	4449809	Screw
32	9756673	Guide, Roller
33	4457103	Shield, Heat Top

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: GY396LXPB02, GY396LXPQ02, GY396LXPT02, GY396LXPS02
 (Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
1	9760771	Element, Broil
2	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
6	4448717	Rack, Oven
7	9760766	Element, Bake

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: GY396LXPB02, GY396LXPQ02, GY396LXPT02, GY396LXPS02
 (Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust	8	9757404	Box, Terminal	13	9757118BL	Vent, (Control Panel)
2	4455178	Elbow, Vent Top	9	9759721	Insulator, Term Box	14	3400080	Screw
3	9759320	Blower	10	9761958	Block, Terminal	15	3196160	Screw
4	4451758	Block, Foam	11	4449868	Block, Terminal	16	4450038	Screw
5	4455177	Elbow, Vent Bottom	12	9757405	Cover, Term Box	17	4449040	Screw
6	9759938	Bracket, Term.Box				18	4455352	Bracket, Blower
7	4449809	Screw (2)						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: GY396LXPB02, GY396LXPQ02, GY396LXPT02, GY396LXPS02
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>			<u>SPLICING WIRES--25FT. LENGTH</u>			<u>WIRING HARNESS PARTS</u>		
	72017	White		242828	Wire (12 Ga. 150 c Black)		9759537	Harness, Wire (Main)
	261869	Cord Brown		242820	Wire (14 Ga. 150 c Black)		9759702	Harness, Wire (Cooktop Power)
	72032	Black		242821	Wire (14 Ga. 150 c Blue)		9759701	Harness, Wire (Cooktop Left)
<u>PAINT, SPRAY</u>				242822	Wire (14 Ga. 150 c Brown)		9759703	Harness, Wire (Cooktop Right)
	350930	White		242822	Wire (14 Ga. 150 c Brown)		9759715	Conduit
	261900	Citrine White		242830	Wire (14 Ga. 200 c Brown)		3196173	Screw (Conduit)
	830864	Black		242823	Wire (14 Ga. 150 c Green)		313660	Clip, Ground Wire
<u>ADHESIVE</u>				242824	Wire (14 Ga. 150 c Orange)		4448664	Clamp
	591014	Adhesive Loctite (1/3 oz.)		242824	Wire (14 Ga. 150 c Orange)		4449809	Screw
	482338	Sealer, Silastic (3 oz.)		242829	Wire (12 Ga. 150 c Red)		112432	Nut
				242825	Wire (14 Ga. 150 c Red)		4450800	Screw, Ground
				242831	Wire (14 Ga. 200 c Red)		4452222	Spacer, Harness
				242826	Wire (14 Ga. 150 c White)		3400015	Screw, Ground
				242827	Wire (14 Ga. 150 c Yellow)		<u>Miscellaneous</u>	
				242832	Wire (14 Ga. 200 c Yellow)		814381	Hinge Pin Kit
							4448950	Screw, Install (4)
							9782676	Anit-Tip Assy Filler,Counter Top
							9757784WH	White
							9757784BL	Black
							9757784BT	Biscuit
							9757784SS	S.Steel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST