




COOKTOP PARTS

For Models: GY398LXPB00, GY398LXPQ00, GY398LXPT00, GY398LXPS00
(Black) (White) (Biscuit) (S.Steel)

30" Slide-In
ELECTRIC OVEN
SELF CLEAN




Illus. No.	Part No.	DESCRIPTION
1	9757446	Literature Parts
		Installation Instructions
		Use & Care Guide
		Tech Sheet
		Anti-Tip Instruct.
		Safe Cooking Tips
2	3192459	Burner Box
3	4454023	Bracket, Mounting
		Screw
4		Cooktop
	9756788BT	Biscuit
	9756788WH	White
	9756788BL	Black
	9756450	Gasket
5	4453764	Clip, Ceran (2)
		Screw
6		Trim-CkTop, SI
	4453875WH	White LH
	4453875BT	Biscuit LH
	4453875BL	Black LH
	4453875SS	S.Steel LH
	4453870WH	White RH
	4453870BT	Biscuit RH
	4453870BL	Black RH
	4453870SS	S.Steel RH
	3400805	Screw
7		Switch, Infinite
	9750638	LR, RF
	9750639	RR
	9750641	LF
8	8523739	Light, Indicator
10	9756821	Support, Wiring
		Screw (2)
12		Element, Surface
	8523698	1200W LR,RF
	8523696	1800W RR
	8523692	2500W LF
13	9757800	Bracket, Front
		Support
	3179776	Screw (4)
16	9751984	Bi-Metal
	3196160	Screw (2)
17	9758799	Bracket, Ind. Lamp
	3196160	Screw (2)
18		Trim, Extension
	4453865WH	White
	4453865BT	Biscuit
	4453865BL	Black
	4453865SS	S.Steel
	3196160	Screw
19	3191791	Spring, Locator
20	9757802	Bracket, Rear Sprt
	3179776	Screw (4)
21	9756813	Rail, Element (2)
	3179776	Screw (4)
22	486754	Screw
23	9759628	Cover, Cktp Rear
	3179776	Screw (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GY398LXPB00, GY398LXPQ00, GY398LXPT00, GY398LXPS00
 (Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	8191149	White
	8191150	Biscuit
	8191151	Black
	8191152	S.Steel
3	9757475	Control, Migration
	9780271	Screw
4	9757119	Bracket, Console
	3179776	Screw (3)


Illus. No.	Part No.	DESCRIPTION
5	3196068	Lens, Ind. (2)
6	9757410	Bracket, Control
	486579	Screw
7	8523265	Housing, Ind. Lt.

Illus. No.	Part No.	DESCRIPTION
8		Endcap
	9756614BT	Biscuit LH
	9756614WH	White LH
	9756614BL	Black LH
	9756611BT	Biscuit RH
	9756611WH	White RH
	9756611BL	Black RH
	3196172	Screw
9		Knob
	9756659BL	Black
	9756659WH	White
	9756659BT	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: GY398LXPB00, GY398LXPQ00, GY398LXPT00, GY398LXPS00
(Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: GY398LXPB00, GY398LXPQ00, GY398LXPT00, GY398LXPS00
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)	9	4452158	Tube, Vent	29	4455636	Sensor
	9757735WH	White		3196176	Screw		4449154	Screw
	9757735BT	Biscuit	10	4452165	Lens, Light	37	4451442	Thermostat (TOD) (Temp.) SPST
	9757735BL	Black	11	4452368	Oven Light Assy	43	9759713	Base, Chassis
	9757735SS	S.Steel (Left Hand)	12	4452166	Bulb, Light	49	4448933	Retainer, Gasket
	9757734WH	White	14	4455612	Frame, Front		4449154	Screw
	9757734BT	Biscuit		4449040	Screw	50	4451747	Cover, Back
	9757734BL	Black	15	4455382	Gasket, Door		4449809	Screw
	9757734SS	S.Steel	16	4453951	Deflector, Vent Bottom	54		Vent, Bottom Upper
	3400832	Screw	17	4452152	Bracket, Mounting		9756481WH	White
3		Hinge Receiver	19	4451478	Support, Insulation		9756481BT	Biscuit
	4455605	Left Hand		4449809	Screw		9756481BL	Black
	4455606	Right Hand	22	8302474	Latch, Motorized		9756481SS	S.Steel
4	4448520	Bumper, Door		4449154	Screw	55		Trim, Btm Vent
7	4455865	Top Chassis	23	341196	Thermostat SPST (205)		9756485WH	White
	4449809	Screw	25	4455641	Side, Chassis (R.H. & L.H.)		9756485BT	Biscuit
8		Oven, Side Panel		4449809	Screw		9756485BL	Black
	9781907PB	Black	26	9759761	Back, Chassis		9756485SS	S.Steel
	9781907PW	White		4449809	Screw	FOLLOWING PARTS NOT ILLUSTRATED		
	9781907PT	Biscuit	27		Liner, Oven (Not serviceable)	INSULATION		
							9756817	Insulation, Wrap
							9756470	Insulation, Back

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: GY398LXPB00, GY398LXPQ00, GY398LXPT00, GY398LXPS00
(Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DOOR AND DRAWER PARTS

For Models: GY398LXPB00, GY398LXPQ00, GY398LXPT00, GY398LXPS00
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
5		Glass, Door Front
	9759641	Black
	9759639	White
	9759640	Biscuit
	9759642	S.Steel
8		Handle, Door
	4448854	Black
	4448855	White
	4448856	Biscuit
9	8302094	Bracket, Central
10		Hinge, Door
	8300571	White RH
	8300572	White LH
	8300573	Lt.Blue RH
	8300574	Lt.Blue LH
	4449743	Screw
	11	312701
12	8302092	Bracket, Side
13	9757798	Panel, Drawer
15	9757706	Glass, Inner
16	4457114	Shield, Heat Btm
17	4449263	Glass, Inner (2)
18	4451722	Insulation, Door
19	4455618	Liner, Door
20	9757806	Drawer & Roller
21	3196037	Foot, Front
	4449743	Screw
	22	422604
23	9759743	Retainer, Door
	24	Front, Drawer
	4453921WH	White
	4453921BL	Black
	4453921BT	Biscuit
25	4453921SS	S.Steel
	4450813	Bracket, Handle
	4451040	Screw
26		Handle, Drawer
	9756674WH	White
	9756674BT	Biscuit
	9756674BL	Black
28	4450863	Retainer, Clip
32	9756673	Guide, Roller
33	9757707	Shield, Heat Top

INTERNAL OVEN PARTS

For Models: GY398LXPB00, GY398LXPQ00, GY398LXPT00, GY398LXPS00
 (Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
1	4448988	Cover, Fan
	4449154	Screw
2	4456103	Element, Broil
	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw
8	4451583	Motor, Convection Fan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: GY398LXPB00, GY398LXPQ00, GY398LXPT00, GY398LXPS00
 (Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust	4	4451758	Block, Foam	10	9757136	Block, Terminal
	4449040	Screw, 8-18 x 3/8	5	4455177	Elbow, Vent Bottom	11	4449868	Block, Terminal
2	4455178	Elbow, Vent Top	7	9759749	Bracket, Term.Box		3400080	Screw
3	8300223	Blower		4449809	Screw (2)	12	9757405	Cover, Term Box
	4455352	Bracket	8	9757404	Box, Terminal		3196160	Screw (2)
	4449809	Screw (4)	9	9759721	Insulator, Term Box	13	9757118BL	Vent, (Control Panel)
							4450038	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: GY398LXPB00, GY398LXPQ00, GY398LXPT00, GY398LXPS00
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	261869	Cord Brown
	72032	Black
<u>PAINT, SPRAY</u>		
	350930	White
	261900	Citrine White
	830864	Black
<u>ADHESIVE</u>		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
<u>SPLICING WIRES--25FT.</u>		
<u>LENGTH</u>		
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
<u>WIRING HARNESS PARTS</u>		
	9759840	Harness, Wire (Main)
	9759702	Harness, Wire (Cooktop Power)
	9759701	Harness, Wire (Cooktop Left)
	9759703	Harness, Wire (Cooktop Right)
	9759715	Conduit
	3196173	Screw (Conduit)
	313660	Clip, Ground Wire
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	4452222	Spacer, Harness
	3400015	Screw, Ground
<u>Miscellaneous</u>		
	814381	Hinge Pin Kit
	4448950	Screw, Install (4)
	9782676	Anit-Tip Assy Filler,Counter Top
	9757784WH	White
	9757784BL	Black
	9757784BT	Biscuit
	9757784SS	S.Steel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST