


LOWER OVEN PARTS

For Models: RBD245PRB00, RBD245PRQ00, RBD245PRT00, RBD245PRS00

(Black) (Designer White) (Biscuit) (Stainless Steel)



24" BUILT-IN ELECTRIC
DOUBLE OVEN
STD-CLEAN LOWER
SELF-CLEAN UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS


For Models: RBD245PRB00, RBD245PRQ00, RBD245PRT00, RBD245PRS00
(Black) (Designer White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	8	4452490	Spacer, Foam	28	3196176	Screw
	8303871	Installation Instructions	9	4452159	Tube, Vent	29	4455636	Sensor
	8303870	Use & Care Guide (Oven)	10	4452165	Lens, Light	33	9760675	Deflector, Vent
	8302068	Tech Sheet	11	4452368	Oven Light Assy	37	4451354	Fuse-Thermal
	3191638	Safer Cooking Tips	12	4452166	Bulb, Light	43	4450525	Base, Chassis
2		Trim, Side	13	8300825	Insulation, Bottom Vent	49	4448933	Retainer, Gasket
	8302917	RH Black	14	4455610	Frame, Front	50	4451747	Cover, Back
	8302919	RH White	15	4450491	Gasket, Door	51		Trim, Bottom
	8302921	RH Biscuit	16	4449809	Screw		8302942	Black
	8302918	LH Black	17	4449040	Screw		8302943	White Model
	8302920	LH White	18	4452152	Bracket, Mounting (Bottom Vent)		8302944	Biscuit Model
	8302922	LH Biscuit	19	4451476	Support, Insulation	53	4449845	Support, Bracket
4	4448520	Bumper, Door	20	4450935	Plug, Door	FOLLOWING PARTS NOT ILLUSTRATED		
5		Screw	22	W10016550	Fan & Bracket Assy	INSULATION		
	3400832	Black	23	4449154	Screw		4449314	Insulation, Wrap
	3400805	Zinc	24	4449743	Screw		4450363	Insulation, Back
6		Receiver, Hinge	25	4455641	Side, Chassis (R.H. & L.H.)			
	4455605	Left Hand	26	4452232	Back, Chassis			
	4455606	Right Hand	27		Liner, Oven (Not serviceable)			
7	4455863	Top Chassis						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models: RBD245PRB00, RBD245PRQ00, RBD245PRT00, RBD245PRS00
(Black) (Designer White) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models:RBD245PRB00, RBD245PRQ00, RBD245PRT00,RBD245PRS00
(Black) (Designer White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Receiver, Hinge
	4455605	Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
5	4449743	Screw
6	3196176	Screw
7	4455863	Top Chassis
9	4452158	Tube, Vent
10	4452165	Lens, Light
11	4452368	Oven Light Assy
12	4452166	Bulb, Light
14	4455610	Frame, Front
15	4455380	Gasket, Door
16	4449809	Screw
17	4449040	Screw
19	4451476	Support, Insulation
	4449809	Screw
21		Rail, Side
	8302793	Right Side
	8302794	Left Side
	4448444	Grommet
23	4449154	Screw
24	9759525	Latch Assy
25	4455641	Side, Chassis (R.H. & L.H.)
26	4452232	Back, Chassis
27		Liner, Oven (Not serviceable)
29	4455636	Sensor
34	4452265	Vent, Center
37	9759243	Thermostat (TOD) (Temp.) SPST
49	4448933	Retainer, Gasket
50	4451747	Cover, Back
53	4449845	Support, Bracket


FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449314 Insulation, Wrap
4450363 Insulation, Back

LOWER OVEN DOOR PARTS

For Models: RBD245PRB00, RBD245PRQ00, RBD245PRT00, RBD245PRS00
 (Black) (Designer White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	8303698	Liner, Door
3	4449247	Glass, Inner
5	4457130	Retainer, Glass
6		Hinge, Door
	9760563	Right Side
	9760564	Left Side

Illus. No.	Part No.	DESCRIPTION
12		Door Glass, Assy
	8303328	Black
	8303337	White
	8303340	Biscuit
	8303312	Stainless
13		Door Handle
	8302807	Black
	8302808	White
	8302809	Biscuit


Illus. No.	Part No.	DESCRIPTION
14	8303165	Bracket, Handle
18		Retainer, Door
	8303387BL	Black
	8303387WH	White
	8303387BT	Biscuit
20	4451040	Screw
21	8303876	Seal, Door
23	4451432	Retainer, Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN DOOR PARTS

For Models: RBD245PRB00, RBD245PRQ00, RBD245PRT00, RBD245PRS00

(Black) (Designer White) (Biscuit) (Stainless Steel)







Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8303698	Liner, Door	12		Door Glass, Assy	16	9759230	Bracket(3rd Glass)
2		Hinge, Door		8303328	Black	17	8303811	Nameplate
	9760567	Right Side		8303337	White	18		Retainer, Door
	9760568	Left Side		8303340	Biscuit		8303387BL	Black
3	4449247	Glass, Inner		8303312	Stainless		8303387WH	White
4	4451720	Insulation, Door	13		Door Handle		8303387BT	Biscuit
5	4457130	Retainer, Glass		8302807	Black	19	4457101	Shield, Heat
	4449809	Screw		8302808	White	20	4451040	Screw
7	9759223	Glass, Inner		8302809	Biscuit	21	8303876	Seal, Door
11	3400832	Screw	14	8303165	Bracket, Handle	22	4457112	Shield, Heat (Btm)
			15	9759229	Bracket(2nd Glass)	23	4451432	Retainer, Clip
						24	9759226	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: RBD245PRB00, RBD245PRQ00, RBD245PRT00, RBD245PRS00
(Black) (Designer White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
2	4456103	Element, Broil
	4449154	Screw
6	4448716	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RBD245PRB00, RBD245PRQ00, RBD245PRT00, RBD245PRS00
 (Black) (Designer White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Control Panel Assy.
	8302840	Black
	8302841	White
	8302842	Biscuit
2		Membrane Switch
	8304245	Black
	8304246	White
	8304247	Biscuit
3	8303883	Microcomputer
4	8304163	Bracket, Control
5	8301848	Board, Mtrzd Latch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RBD245PRB00, RBD245PRQ00, RBD245PRT00, RBD245PRS00
 (Black) (Designer White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust	9	4450038	Screw	15	9759135	Back, Control
2	4457289	Blower	11	4449868	Block, Terminal	16	4450549	Cover, Top Rear
3	4451758	Foam, Block	13	8303499	Vent, (Control Panel)	17	4448664	Clamp
4	4455178	Elbow, Vent-Top	14		Side, Control Top	18	4452365	Cover, Top Front
5	4455177	Elbow, Vent-Bottom		4451597	Right	19	4454943	Plate, Fan
6	4449809	Screw		4451598	Left	20	8302143	Suppressor
7	4449040	Screw				21	8300642	Transformer, Single Control
8	3400080	Screw						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:RBD245PRB00, RBD245PRQ00, RBD245PRT00,RBD245PRS00

(Black) (Designer White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828 Wire (12 Ga.
150 c Black)
242820 Wire (14 Ga.
150 c Black)
242821 Wire (14 Ga.
150 c Blue)
242822 Wire (14 Ga.
150 c Brown)
242830 Wire (14 Ga.
200 c Brown)
242823 Wire (14 Ga.
150 c Green)
242824 Wire (14 Ga.
150 c Orange)
242825 Wire (14 Ga.
150 c Red)
242831 Wire (14 Ga.
200 c Red)
242827 Wire (14 Ga.
150 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

8302154 Harness, Wire STD
(Main)
8301878 Stainless Model
4450953 Conduit, Double
4450800 Screw
4448664 Clamp
4449809 Screw
112432 Nut
4454835 Tie, Cable
4451761 Support, Wiring
4454842 Tie, Cable

Miscellaneous

4448950 Screw, Install.
8-14 x 1" (4)
814381 Pin Hinge Kit
4396923 Broiler Pan Assy