




# LOWER OVEN PARTS

For Models: RBD275PRB00, RBD275PRQ00, RBD275PRT00, RBD275PRS00  
(Black) (Designer White) (Biscuit) (Stainless Steel)

24" BUILT-IN ELECTRIC  
DOUBLE OVEN  
STD-CLEAN LOWER  
SELF-CLEAN UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LOWER OVEN PARTS


For Models: RBD275PRB00, RBD275PRQ00, RBD275PRT00, RBD275PRS00  
(Black) (Designer White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	7	4455864	Top Chassis	27		Liner, Oven
	8303648	Installation Instructions	8	4452490	Spacer, Foam			(Not serviceable)
	8303870	Use & Care Guide (Oven)	9	4452159	Tube, Vent	29	4455636	Sensor
	8302068	Tech Sheet	10	4452165	Lens, Light	33	9760676	Deflector, Vent
		Safer Cooking Tips	11	4452368	Oven Light Assy	37	4451354	Fuse-Thermal
	3191638	English	12	4452166	Bulb, Light	43	4455529	Base, Chassis
	9759133	French	13	4452336	Insulation, Bottom Vent	49	4448933	Retainer, Gasket
2		Trim, Side	14	4455611	Frame, Front	50	4451747	Cover, Back
	8302917	RH Black	15	4450492	Gasket, Door	51		Trim, Bottom
	8302919	RH White	16	4449809	Screw		8302937	Black
	8302921	RH Biscuit	17	4449040	Screw		8302938	White
	8303210	RH Stainless	18	4452152	Bracket, Mounting (Bottom Vent)		8302939	Biscuit
	8302918	LH Black	19	4451477	Support, Insulation		8302940	Stainless
	8302920	LH White	20	4450935	Plug, Door	53	4449845	Support, Bracket
	8302922	LH Biscuit	22	4451664	Fan & Bracket Assy	<b>FOLLOWING PARTS NOT ILLUSTRATED</b>		
	8303209	LH Stainless	23	4449154	Screw	<b>INSULATION</b>		
4	4448520	Bumper, Door	24	4449743	Screw		4449315	Insulation, Wrap
5		Screw	25	4455641	Side, Chassis (R.H. & L.H.)		4450364	Insulation, Back
	3400832	Black	28	3196176	Screw			
	3400805	Zinc	26	4452233	Back, Chassis			
6		Receiver, Hinge						
	4455605	Left Hand						
	4455606	Right Hand						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER OVEN PARTS

For Models: RBD275PRB00, RBD275PRQ00, RBD275PRT00, RBD275PRS00  
(Black) (Designer White) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER OVEN PARTS

For Models:RBD275PRB00, RBD275PRQ00, RBD275PRT00,RBD275PRS00  
(Black) (Designer White) (Biscuit) (Stainless Steel)

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1		Receiver, Hinge
	4455605	Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
5	4449743	Screw
6	3196176	Screw
7	4455864	Top Chassis
9	4452158	Tube, Vent
10	4452165	Lens, Light
11	4452368	Oven Light Assy
12	4452166	Bulb, Light
14	4455611	Frame, Front
15	4455381	Gasket, Door
16	4449809	Screw
17	4449040	Screw
19	4451477	Support, Insulation
21		Rail, Side
	8302793	Right Side
	8302794	Left Side
	4448444	Grommet
23	4449154	Screw
24	9759525	Latch Assy
25	4455641	Side, Chassis (R.H. & L.H.)
26	4452233	Back, Chassis
27		Liner, Oven (Not serviceable)
29	4455636	Sensor
34	4452266	Vent, Center
37	9759243	Thermostat (TOD) (Temp.) SPST
49	4448933	Retainer, Gasket
50	4451747	Cover, Back
53	4449845	Support, Bracket

---

## FOLLOWING PARTS NOT ILLUSTRATED


---

### INSULATION

4449315 Insulation, Wrap  
4450364 Insulation, Back

# LOWER OVEN DOOR PARTS

For Models: RBD275PRB00, RBD275PRQ00, RBD275PRT00, RBD275PRS00  
 (Black) (Designer White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	8303699	Liner, Door
3	4449253	Glass, Inner
5	4457131	Retainer, Glass
6	9760563	Right Side
	9760564	Left Side
	9760565	(SS Model Only)
	9760565	Left side
	9760566	Right side


Illus. No.	Part No.	DESCRIPTION
12	8303320	Door Glass, Assy
	8303338	Black
	8303341	White
	8303313	Biscuit
	8303313	Stainless
13	8302810	Door Handle
	8302810	Black
	8302811	White
	8302812	Biscuit

Illus. No.	Part No.	DESCRIPTION
14	8303166	Bracket, Handle
18	8303388BL	Retainer, Door
	8303388BL	Black
	8303388WH	White
	8303388BT	Biscuit
20	4451040	Screw
21	8303877	Seal, Door
23	4450863	Retainer, Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER OVEN DOOR PARTS

For Models: RBD275PRB00, RBD275PRQ00, RBD275PRT00, RBD275PRS00  
 (Black) (Designer White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	8303699	Liner, Door
2	4451721	Hinge, Door
	9760569	Right Side
	9760570	Left Side
		(SS Model Only)
	9760572	Left Side
	9760571	Right Side
3	4449253	Glass, Inner
4	4451721	Insulation, Door
5	4457131	Retainer, Glass
7	9759224	Glass, Inner
11	3400832	Screw


Illus. No.	Part No.	DESCRIPTION
12		Door Glass, Assy
	8303320	Black
	8303338	White
	8303341	Biscuit
	8303313	Stainless
13		Door Handle
	8302810	Black
	8302811	White
	8302812	Biscuit
14	8303166	Bracket, Handle
15	9759229	Bracket(2nd Glass)

Illus. No.	Part No.	DESCRIPTION
16	9759230	Bracket(3rd Glass)
17	8303811	Nameplate
18		Retainer, Door
	8303388BL	Black
	8303388WH	White
	8303388BT	Biscuit
19	4457102	Shield, Heat
20	4451040	Screw
21	8303877	Seal, Door
22	4457113	Shield, Heat (Btm)
23	4451432	Retainer, Clip
24	9759227	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERNAL OVEN PARTS

For Models: RBD275PRB00, RBD275PRQ00, RBD275PRT00, RBD275PRS00  
 (Black) (Designer White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
2	4456103	Element, Broil
	4449154	Screw
6	4448715	Rack, Oven (4)
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: RBD275PRB00, RBD275PRQ00, RBD275PRT00, RBD275PRS00  
 (Black) (Designer White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Control Panel Assy.
	8302844	Black
	8302845	White
	8302846	Biscuit
2		Membrane Switch
	8304248	Black
	8304249	White
	8304250	Biscuit
3	8303883	Microcomputer
4	8304162	Bracket, Control
5	8301848	Board, Mtrzd Latch
6	4449745	Screw
7	8302878	Trim-Panel (Use on S.Steel model only)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# TOP VENTING PARTS

For Models: RBD275PRB00, RBD275PRQ00, RBD275PRT00, RBD275PRS00  
 (Black) (Designer White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4457289	Blower
3	4451758	Foam, Block
4	4455178	Elbow, Vent-Top
5	4455177	Elbow, Vent-Bottom
6	4449809	Screw
7	4449040	Screw
8	3400080	Screw

Illus. No.	Part No.	DESCRIPTION
9	4450038	Screw
11	4449868	Block, Terminal
13	8303498	Vent, (Control Panel)
14	4451597	Right Side, Control Top
	4451598	Left
15	9759135	Back, Control

Illus. No.	Part No.	DESCRIPTION
16	4450550	Cover, Top Rear
17	4448664	Clamp
18	4452366	Cover, Top Front
19	4454943	Plate, Fan
20	8302143	Suppressor
21	8300642	Transformer, Single Control

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models:RBD275PRB00, RBD275PRQ00, RBD275PRT00,RBD275PRS00  
(Black) (Designer White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b><u>PAINT, TOUCH-UP (1/2oz.)</u></b>			<b><u>SPLICING WIRES--25FT. LENGTH</u></b>			<b><u>WIRING HARNESS PARTS</u></b>		
	72017	White		242828	Wire (12 Ga. 150 c Black)		8302154	Harness, Wire STD (Main)
	261869	Cord Brown		242820	Wire (14 Ga. 150 c Black)		8301878	Stainless Model
	72032	Black		242821	Wire (14 Ga. 150 c Blue)		4450953	Conduit, Double
<b><u>PAINT, SPRAY</u></b>				242822	Wire (14 Ga. 150 c Brown)		4450800	Screw
	350930	White		242830	Wire (14 Ga. 200 c Brown)		4448664	Clamp
	261900	Citrine White		242823	Wire (14 Ga. 150 c Green)		4449809	Screw
	830864	Black		242824	Wire (14 Ga. 150 c Orange)		112432	Nut
<b><u>ADHESIVE</u></b>				242825	Wire (14 Ga. 150 c Red)		4454835	Tie, Cable
	591014	Adhesive Loctite (1/3 oz.)		242831	Wire (14 Ga. 200 c Red)		4451761	Support, Wiring
	482338	Sealer, Silastic (3 oz.)		242827	Wire (14 Ga. 150 c Yellow)		4454842	Tie, Cable
						<b><u>Miscellaneous</u></b>		
							4448950	Screw, Install. 8-14 x 1" (4)
							814381	Pin Hinge Kit
							4396923	Broiler Pan Assy

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST