


LOWER OVEN PARTS

For Models: RBD305PRB00, RBD305PRQ00, RBD305PRT00, RBD305PRS00
 (Black) (Designer White) (Biscuit) (Stainless Steel)



24" BUILT-IN ELECTRIC
 DOUBLE OVEN
 STD-CLEAN LOWER
 SELF-CLEAN UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS


For Models: RBD305PRB00, RBD305PRQ00, RBD305PRT00, RBD305PRS00
(Black) (Designer White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	7	8303099	Top Chassis	28	3196176	Screw
	8303647	Installation Instructions	8	4452490	Spacer, Foam	29	4455636	Sensor
	8303870	Use & Care Guide (Oven)	9	4452159	Tube, Vent	33	9760677	Deflector, Vent
	8302068	Tech Sheet	10	4452165	Lens, Light	37	4451354	Fuse-Thermal
	3191638	English	11	4452368	Oven Light Assy	43	9759713	Base, Chassis
	9759133	French	12	4452166	Bulb, Light	49	4448933	Retainer, Gasket
2		Trim, Side	13	4452337	Insulation, Bottom Vent	50	4451747	Cover, Back
	8302917	RH Black	14	9759060	Frame, Front	51		Trim, Bottom
	8302919	RH White	15	4450493	Gasket, Door		8302947	Black
	8302921	RH Biscuit	16	4449809	Screw		8302948	White
	8303209	LH Stainless	17	4449040	Screw		8302949	Biscuit
	8302918	LH Black	18	4452152	Bracket, Mounting (Bottom Vent)	53	4449845	Support, Bracket
	8302920	LH White	19	4451478	Support, Insulation	FOLLOWING PARTS NOT ILLUSTRATED		
	8302922	LH Biscuit	20	4450935	Plug, Door	INSULATION		
	8303210	RH Stainless	22	4451664	Fan & Bracket Assy		4449315	Insulation, Wrap
4	4448520	Bumper, Door	23	4449154	Screw		4450364	Insulation, Back
5		Screw	24	4449743	Screw			
	3400832	Black	25	4455641	Side, Chassis (R.H. & L.H.)			
	3400805	Zinc	26	4452234	Back, Chassis			
6		Receiver, Hinge	27		Liner, Oven (Not serviceable)			
	4455605	Left Hand						
	4455606	Right Hand						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models: RBD305PRB00, RBD305PRQ00, RBD305PRT00, RBD305PRS00
(Black) (Designer White) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models:RBD305PRB00, RBD305PRQ00, RBD305PRT00,RBD305PRS00
(Black) (Designer White) (Biscuit) (Stainless Steel)

<u>Illus. No.</u>	<u>Part No.</u>	<u>DESCRIPTION</u>
1		Receiver, Hinge
	4455605	Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
5	4449743	Screw
6	3196176	Screw
7	4455864	Top Chassis
9	4452158	Tube, Vent
10	4452165	Lens, Light
11	4452368	Oven Light Assy
12	4452166	Bulb, Light
14	4455611	Frame, Front
15	4455381	Gasket, Door
16	4449809	Screw
17	4449040	Screw
19	4451477	Support, Insulation
21		Rail, Side
	8302793	Right Side
	8302794	Left Side
	4448444	Grommet
23	4449154	Screw
24	9759525	Latch Assy
25	4455641	Side, Chassis (R.H. & L.H.)
26	4452233	Back, Chassis
27		Liner, Oven (Not serviceable)
29	4452267	Sensor
34	4452266	Vent, Center
37	9759243	Thermostat (TOD) (Temp.) SPST
49	4448933	Retainer, Gasket
50	4451747	Cover, Back
53	4449845	Support, Bracket


FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4459316 Insulation, Wrap
4450365 Insulation, Back

LOWER OVEN DOOR PARTS

For Models: RBD305PRB00, RBD305PRQ00, RBD305PRT00, RBD305PRS00
 (Black) (Designer White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	8303700	Liner, Door
3	4449259	Glass, Inner
5	9759743	Retainer, Glass
6		Hinge, Door
	9760565	Right Side
	9760566	Left Side
	9760567	Right Side (SS Model Only)
	9760568	Left Side


Illus. No.	Part No.	DESCRIPTION
12		Door Glass, Assy
	8303330	Black
	8303339	White
	8303342	Biscuit
	8303314	Stainless
13		Door Handle
	8302813	Black
	8302814	White
	8302815	Biscuit

Illus. No.	Part No.	DESCRIPTION
14	8303167	Bracket, Handle
18		Retainer, Door
	8303389BL	Black
	8303389WH	White
	8303389BT	Biscuit
20	4451040	Screw
21	8303878	Seal, Door
23	4451432	Retainer, Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN DOOR PARTS

For Models: RBD305PRB00, RBD305PRQ00, RBD305PRT00, RBD305PRS00
 (Black) (Designer White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8303700	Liner, Door	12		Door Glass, Assy	17	8303811	Nameplate
2		Hinge, Door		8303330	Black	18		Retainer, Door
	9760571	Right Side		8303339	White		8303389BL	Black
	9760572	Left Side		8303342	Biscuit		8303389WH	White
		(SS Model Only)		8303314	Stainless		8303389BT	Biscuit
	9760573	Right Side	13		Door Handle	19	4457103	Shield, Heat
	9760574	Left Side		8302813	Black	20	4451040	Screw
3	4449259	Glass, Inner		8302814	White	21	8303878	Seal, Door
4	4451722	Insulation, Door		8302815	Biscuit	22	4457114	Shield, Heat (Btm)
5	4457132	Retainer, Glass	14	8303167	Bracket, Handle	23	4451432	Retainer, Clip
7	9759225	Glass, Inner	15	9759229	Bracket(2nd Glass)	24	9759228	Glass, Inner
11	3400832	Screw	16	9759230	Bracket(3rd Glass)			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: RBD305PRB00, RBD305PRQ00, RBD305PRT00, RBD305PRS00
 (Black) (Designer White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
2	4456103	Element, Broil
	4449154	Screw
6	4448717	Rack, Oven (4)
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RBD305PRB00, RBD305PRQ00, RBD305PRT00, RBD305PRS00
 (Black) (Designer White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	8302848	Control Panel Assy. Black
	8302849	White
	8302850	Biscuit
2	8304248	Membrane Switch Black
	8304249	White
	8304250	Biscuit
3	8303883	Microcomputer
4	8304161	Bracket, Control
5	8301848	Board, Mtrzd Latch
6	4449745	Screw
7	8302877	Cover, Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RBD305PRB00, RBD305PRQ00, RBD305PRT00, RBD305PRS00
 (Black) (Designer White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4457289	Blower
	4457289	65mm (Upper)
	w10016550	45mm (lower)
3	4451758	Foam, Block
4	4455178	Elbow, Vent-Top
5	4455177	Elbow, Vent-Bottom
6	4449809	Screw
7	4449040	Screw
8	3400080	Screw

Illus. No.	Part No.	DESCRIPTION
9	4450038	Screw
11	4449868	Block, Terminal
13	8303497	Vent, (Control Panel)
14	4451597	Right Side, Control Top
	4451598	Left
15	9759135	Back, Control

Illus. No.	Part No.	DESCRIPTION
16	4450551	Cover, Top Rear
17	4448664	Clamp
18	4452367	Cover, Top Front
19	4454943	Plate, Fan
20	8302143	Suppressor
21	8300642	Transformer, Single Control

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:RBD305PRB00, RBD305PRQ00, RBD305PRT00,RBD305PRS00
(Black) (Designer White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>			<u>SPLICING WIRES--25FT.</u>			<u>WIRING HARNESS PARTS</u>		
	72017	White	<u>LENGTH</u>				8302154	Harness, Wire STD (Main)
	261869	Cord Brown	242828	Wire (12 Ga.		8301878	Stainless Model	
	72032	Black		150 c Black)		4450953	Conduit, Double	
<u>PAINT, SPRAY</u>			242820	Wire (14 Ga.		4450800	Screw	
	350930	White		150 c Black)		4448664	Clamp	
	261900	Citrine White	242821	Wire (14 Ga.		4449809	Screw	
	830864	Black		150 c Blue)		112432	Nut	
<u>ADHESIVE</u>			242822	Wire (14 Ga.		4454835	Tie, Cable	
	591014	Adhesive		150 c Brown)		4451761	Support, Wiring	
		Loctite (1/3 oz.)	242830	Wire (14 Ga.		4454842	Tie, Cable	
	482338	Sealer, Silastic		200 c Brown)		<u>Miscellaneous</u>		
		(3 oz.)	242823	Wire (14 Ga.		4448950	Screw, Install.	
				150 c Green)			8-14 x 1" (4)	
			242824	Wire (14 Ga.		814381	Pin Hinge Kit	
				150 c Orange)		4396923	Broiler Pan Assy	
			242825	Wire (14 Ga.				
				150 c Red)				
			242831	Wire (14 Ga.				
				200 c Red)				
			242827	Wire (14 Ga.				
				150 c Yellow)				

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST