




# LOWER OVEN PARTS

For Models: RBD305PRB02, RBD305PRQ02, RBD305PRT02, RBD305PRS02  
(Black) (Designer White) (Biscuit) (Stainless)

30" BUILT-IN ELECTRIC  
DOUBLE OVEN  
STD-CLEAN LOWER  
SELF-CLEAN UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LOWER OVEN PARTS

For Models: RBD305PRB02, RBD305PRQ02, RBD305PRT02, RBD305PRS02  
(Black) (Designer White) (Biscuit) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8303647	Literature Parts Installation Instructions	6	4455606	Receiver, Hinge Right	27		Liner, Oven (Not serviceable)
	W10162170	Use & Care Guide		4455605	Left	28	3196176	Screw
	8302068	Tech Sheet	7	8303099	Top Chassis	29	W10131825	Sensor
		Safer Cooking Tips	9	4452159	Tube, Vent	30	9760677	Deflector, Vent
	9762761	English	10	W10067870	Lens, Light	31	4451354	Fuse, Thermal
	W10065852	French	11	W10009930	Assembly, Light	32	9759713	Base, Chassis
2		Trim, Side Right	12	4452166	Bulb, Light	33	4448933	Retainer, Gasket
	W10136098	Black	14	W10130368	Frame, Front	34	4451747	Cover, Back
	W10136100	White	15	4450493	Gasket, Door	35		Trim, Bottom
	W10136102	Biscuit	16	4449809	Screw		8303583	Black
	W10166949	Stainless Left	17	4449040	Screw		8303584	White
	W10136099	Black	18	4452152	Bracket, Bottom Vent Mounting		8303585	Biscuit
	W10136101	White	19	4451478	Support, Insulation	36	4449845	Support, Bracket
	W10136103	Biscuit	20	4450935	Plug, Door			
	W10166948	Stainless	22	4451664	Assembly, Fan & Bracket			
4	W10105790	Bumper, Door	23	4449154	Screw			
5		Screw	24	4449743	Screw			
	3400832	Black	25	4455641	Side, Chassis			
	3400805	Zinc	26	W10161110	Back, Chassis			


**FOLLOWING PARTS  
NOT ILLUSTRATED**

**INSULATION**

4449316 Insulation, Wrap  
4450365 Insulation, Back

# UPPER OVEN PARTS

For Models: RBD305PRB02, RBD305PRQ02, RBD305PRT02, RBD305PRS02  
(Black) (Designer White) (Biscuit) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER OVEN PARTS

For Models:RBD305PRB02, RBD305PRQ02, RBD305PRT02, RBD305PRS02  
(Black) (Designer White) (Biscuit) (Stainless)

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1		Receiver, Hinge
	4455606	Right
	4455605	Left
2	4448444	Grommet, Mounting Rail
4	W10105790	Bumper, Door
5	4449743	Screw
6	3196176	Screw
7	8303099	Top Chassis
9	4452158	Tube, Vent
10	W10067870	Lens, Light
11	W10009930	Assembly, Light
12	4452166	Bulb, Light
14	W10130368	Frame, Front
15	4455382	Gasket, Door
16	4449809	Screw
17	4449040	Screw
19	4451478	Support, Insulation
21		Rail, Side
	8302793	Right
	8302794	Left
23	4449154	Screw
24	9760888	Assembly, Latch
25	4455641	Side, Chassis
26	4452233	Back, Chassis
27		Liner, Oven (Not serviceable)
28	W10131825	Sensor
29	4452267	Vent, Center
30	9759243	Thermostat
31	4448933	Retainer, Gasket
32	4451747	Cover, Back
33	4449845	Support, Bracket

---

## FOLLOWING PARTS NOT ILLUSTRATED


---

### INSULATION

4449316 Insulation, Wrap  
4450365 Insulation, Back

# LOWER OVEN DOOR PARTS

For Models: RBD305PRB02, RBD305PRQ02, RBD305PRT02, RBD305PRS02  
 (Black) (Designer White) (Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8303700	Liner, Door
2	4449259	Glass, Inner
3	9759743	Retainer, Glass
4	9760565	Right
	9760566	Left
	9760567	Right
	9760568	Left


Illus. No.	Part No.	DESCRIPTION
5		Assembly, Door Glass
	8303330	Black
	8303339	White
	8303342	Biscuit
	8303314	Stainless
6		Door Handle
	8302813	Black
	8302814	White
	8302815	Biscuit

Illus. No.	Part No.	DESCRIPTION
7	W10136473	Bracket, Handle
8		Retainer, Door
	8303389BL	Black
	8303389WH	White
	8303389BT	Biscuit
9	4451040	Screw
10	8303878	Seal, Door
11	4451432	Retainer, Clip
12	4448520	Bumper, Door

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER OVEN DOOR PARTS

For Models: RBD305PRB02, RBD305PRQ02, RBD305PRT02, RBD305PRS02  
 (Black) (Designer White) (Biscuit) (Stainless)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8303700	Liner, Door	11	3400832	Screw	15	9759229	Bracket(2nd Glass)
2		Hinge, Door	12		Assembly, Door	16	9759230	Bracket(3rd Glass)
	9760571	Right		8303330	Black	17	8303811	Nameplate
	9760572	Left		8303339	White	18		Retainer, Door
		(SS Model Only)		8303342	Biscuit		8303389BL	Black
	9760573	Right		8303314	Stainless		8303389WH	White
	9760574	Left	13		Door Handle		8303389BT	Biscuit
3	4449259	Glass, Inner		8302813	Black	19	4457103	Shield, Heat
4	4451722	Insulation, Door		8302814	White	20	4451040	Screw
5	4457132	Retainer, Glass		8302815	Biscuit	21	8303878	Seal, Door
6	4448520	Bumper, Door	14	W10136473	Bracket, Handle	22	4457114	Shield, Heat (Btm)
7	9759225	Glass, Inner				23	4451432	Retainer, Clip
						24	9759228	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERNAL OVEN PARTS

For Models: RBD305PRB02, RBD305PRQ02, RBD305PRT02, RBD305PRS02  
 (Black) (Designer White) (Biscuit) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	9760771	Element, Broil
2	4448717	Rack, Oven
3	9760766	Element, Conventional Bake
4	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: RBD305PRB02, RBD305PRQ02, RBD305PRT02, RBD305PRS02  
 (Black) (Designer White) (Biscuit) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	8302848	Control Panel Black
	8302849	Control Panel White
	8302850	Control Panel Biscuit
2	8304275	Membrane Switch Black
	8304276	Membrane Switch White
	8304277	Membrane Switch Biscuit
3	8303883	Microcomputer
4	W10153086	Backer, Control Panel
5	8301848	Board, Latch
6	4449745	Screw
7	W10166944	Trim, Control Panel (Stainless Model Only)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# TOP VENTING PARTS

For Models: RBD305PRB02, RBD305PRQ02, RBD305PRT02, RBD305PRS02  
 (Black) (Designer White) (Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust	7	4449040	Screw	15	9759135	Back, Control
2	4457289	Blower	8	3400080	Screw	16	4450551	Cover, Top Rear
	W10016550	65mm (Upper) 45mm (Lower)	9	4450038	Screw	17	4448664	Clamp
3	4451758	Foam, Block	11	4449868	Block, Terminal	18	4452367	Cover, Top Front
4	4455178	Elbow, Vent Top	13	8303497	Vent, Control Panel	19	4454943	Plate, Fan
5	4455177	Elbow, Vent Bottom	14	4451597	Right	20	8302143	Suppressor
6	4449809	Screw		4451598	Left	21	9760587	Transformer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: RBD305PRB02, RBD305PRQ02, RBD305PRT02, RBD305PRS02  
 (Black) (Designer White) (Biscuit) (Stainless)

Illus. No.	Part No.	DESCRIPTION
<b><u>PAINT, TOUCH-UP (1/2oz.)</u></b>		
	72017	White
	261869	Cord Brown
	72032	Black
<b><u>PAINT, SPRAY</u></b>		
	350930	White
	261900	Citrine White
	830864	Black
<b><u>ADHESIVE</u></b>		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
<b><u>SPLICING WIRES--25FT.</u></b>		
<b><u>LENGTH</u></b>		
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242827	Wire (14 Ga. 150 c Yellow)

Illus. No.	Part No.	DESCRIPTION
<b><u>WIRING HARNESS PARTS</u></b>		
	8302154	Harness, Main
	4452400	Lead, Ground Strap
	4450953	Conduit, Double
	4450800	Screw
	98997	Clip
	4448664	Clamp
	4449809	Screw
	7103P027-60	Nut, Terminal Block
	4454835	Tie, Cable
	4451761	Support, Wiring
	4454842	Tie, Cable
<b><u>Miscellaneous</u></b>		
	4448950	Screw, Install.