




COOKTOP PARTS

For Models: RS610PXGW0, RS610PXGN0
(White) (Almond)

30" DROP-IN
ELECTRIC
STANDARD CLEAN
OVEN



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

2	3192459	Burner Box
4	3192454	Bracket, Mounting
5	3196537	Screw, 8-18 x 3/8
7	3192102	Trim, Extension
8		Cooktop
	3191168	White
	3191169	Almond
9	3195210	Clip, Receptacle
10	3191228	Panel, Control
11	3183956	Seal, Switch (4)
12		Switch, Infinite
	3191471	Use W/ 6" Surface (Blue Shaft)
	3191472	Use W/ 8" Surface (Silver Shaft)
13	3191491	Light, Indicator
14	3195917	Clip, Element
15	3400855	Screw, 8-32 x 1/4
17	4448444	Grommet
19		Drip Bowl
	3195208	6" (2)
	3195209	8" (2)
20		Element, Coil
	8053265	6" LF-RR
	8053267	8" RF-LR
21	3400843	Screw, 8-18 x 3/8
22	3196231	Knob, Control (4)
23	3192330	Bracket, Switch Mounting

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RS610PXGW0, RS610PXGN0
(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1	4451230	Control Panel Assy. W/Membrane Switch
	3149333	Screw
	4159465	Screw


Illus. No.	Part No.	DESCRIPTION
2	4451034	Gasket, Control Panel
3	4448873	Microcomputer
	4449745	Screw

Illus. No.	Part No.	DESCRIPTION
LITERATURE PARTS		
	LIT3191799	Installation Instructions
	LIT3191537	Use & Care Guide (Oven)
	LIT3192237	Tech Sheet (Oven)
	LIT3191638	Safer Cooking Tips

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: RS610PXGW0, RS610PXGN0
(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: RS610PXGW0, RS610PXGN0
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1		Trim, Side
	4450844	RH Black
	4450847	LH Black
	4449747	Screw
4	4448520	Bumper, Door
7	4452237	Top, Chassis
	4449809	Screw
9	4452159	Tube, Vent
	3196176	Screw
10	4451664	Fan & Bracket Assy
	4449809	Screw
11	4452368	Oven Light Assy
12	4452166	Bulb, Light
13	4452165	Lens, Light
14	4451740	Frame, Front
	4449040	Screw
	4450118	Nut

Illus. No.	Part No.	DESCRIPTION
15	4450493	Gasket, Door
19	4451478	Support, Insulation
	4449809	Screw
21		Rail, Side
	4450579	Right Side
	4450580	Left Side
	4448444	Grommet
	4449154	Screw
23	4450051	Deflector
	4449154	Screw
25	4454691	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4452234	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
29	4451665	Sensor
	4449154	Screw
37	4451354	Fuse – Thermal
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
43	4451398	Base, Chassis
	4449154	Screw
49	4448933	Retainer
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
51	4448477	Trim, Bottom
53	4449845	Support, Bracket
	4449154	Screw


**FOLLOWING PARTS
NOT ILLUSTRATED**

INSULATION

4449316	Insulation, Wrap
4450365	Insulation, Back

OVEN DOOR PARTS

For Models: RS610PXGW0, RS610PXGN0
(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

- | | | |
|---|---------|--------------|
| 1 | 4451719 | Door Liner |
| 2 | 4449259 | Glass, Inner |

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|---|---------|-----------------|
| 3 | 4454946 | Hinge, Door |
| | 4449743 | Screw (4) |
| 4 | 4451671 | Retainer, Glass |
| | 4449809 | Screw (4) |
| 5 | 4450813 | Bracket, Handle |
| | 4451040 | Screw (4) |
| | 4449743 | Screw (2) |

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|----|---------|------------------|
| 6 | 4451674 | Seal, Top |
| 8 | 4452065 | Assy, Door Glass |
| 9 | 4448854 | Handle, Door |
| 10 | 4450863 | Retainer, Glass |
| | 4449743 | Screw (2) |


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: RS610PXGW0, RS610PXGN0

(White)

(Almond)




Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RS610PXGW0, RS610PXGN0
(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw
11	4449868	Block, Terminal
	3196181	Screw
13	4448549	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Compt.
	3191832	Right
	3191833	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
16	3191842	Cover, Rear
	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: RS610PXGW0, RS610PXGN0
(White) (Almond)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<div style="display: flex; justify-content: space-between;"> <div style="width: 30%;"> <p><u>PAINT, TOUCH-UP (1/2oz.)</u></p> <p>72017 White 261869 Cord Brown 72032 Black</p> <p><u>PAINT, SPRAY</u></p> <p>350930 White 261900 Citrine White 830864 Black</p> <p><u>ADHESIVE</u></p> <p>591014 Adhesive Loctite (1/3 oz.) 482338 Sealer, Silastic (3 oz.)</p> </div> <div style="width: 35%;"> <p><u>SPLICING WIRES--25FT.</u></p> <p><u>LENGTH</u></p> <p>242828 Wire (12 Ga. 150 c Black) 242820 Wire (14 Ga. 150 c Black) 242821 Wire (14 Ga. 150 c Blue) 242822 Wire (14 Ga. 150 c Brown) 242830 Wire (14 Ga. 200 c Brown) 242823 Wire (14 Ga. 150 c Green) 242824 Wire (14 Ga. 150 c Orange) 242829 Wire (12 Ga. 150 c Red) 242825 Wire (14 Ga. 150 c Red) 242831 Wire (14 Ga. 200 c Red) 242826 Wire (14 Ga. 150 c White) 242827 Wire (14 Ga. 150 c Yellow) 242832 Wire (14 Ga. 200 c Yellow)</p> </div> <div style="width: 30%;"> <p><u>WIRING HARNESS PARTS</u></p> <p>4449809 Screw 3191220 Harness, Wire (Main) 4451163 Conduit 3400015 Screw, Ground 4448664 Clamp 3192236 Harness, Wire (Infinite Switch) 3192245 Harness, Wire (Light) 4454384 Ground, Wire 4452222 Spacer, Harness 4454835 Tie, Cable</p> <p><u>Miscellaneous</u></p> <p>4448950 Screw, Install. 8-14 x 1" (4) 814381 Hinge Pin Kit</p> </div> </div>		