

Bravetti™

OWNER'S MANUAL

Model XSP21HCH – Champagne color
Model XSP21HCU – Copper color

7-Qt. Dutch Oven w/Lid



EURO-PRO Operating LLC
94 Main Mill Street, Door 16
Plattsburgh, NY 12901
1 (800) 798-7398

EURO-PRO 



1 – 7 Qt Dutch Oven with Lid

BEFORE USING YOUR COOKWARE FOR THE FIRST TIME

Wash in hot, soapy water. Rinse well and dry.

USE & CARE

Before first use, please remove any stickers found on the cookware and rinse all the pieces with hot, soapy water.
 Use low to medium heat when cooking. Excessive pre-heating of empty cookware may cause damage to cookware. **NEVER Boil dry non-stick cookware. Empty non-stick cookware may produce fumes when heated without food in the pan at temperatures over 400 degrees. These fumes are not harmful to humans and all pets...except birds. Birds have a sensitive respiratory system. For their safety, they should always be kept in a well-ventilated area away from the kitchen.** To prevent damage to the non-stick coating, do not cut food in the cookware.
 The cookware is suitable for gas, electric and ceramic stoves. Choose a cooking element according to the diameter of the pan/pot to avoid losing heat. When using your cookware in the oven, please note that the glass lid is only oven safe up to 350°F and the cookware itself is oven safe up to 450°F. Please note that the handles can get hot while cooking. Use an oven cloth or mitt for protection.
 Bravetti cookware can be washed in your dishwasher. When cleaning your cookware, do not use abrasives such as scouring pads, oven cleaners or sharp instruments as they may scratch or damage the non-stick coating. To clean, use warm, soapy water. To prevent water spots after washing, rinse with hot water and wipe dry immediately.

Caution: Do not immerse hot glass lid under running water. **Always** let glass lid cool first.

XSP21HCH
XSP21HCU

Bravetti™

LIFETIME LIMITED WARRANTY

LIFETIME WARRANTY

EURO-PRO Operating LLC warrants these cookware products to be free from defects in material and workmanship under normal use for the life of the product. This warranty, as it applies to the non-stick finish on the cookware, covers de-lamination, peel off and wear off only. This warranty does not cover scratches, stains or discoloration caused by negligence, misuse or abuse. This warranty is extended only to the original purchaser.

ACTS INVALIDATING WARRANTY

This warranty does not apply to: (1) Vessels and Glass Lids which have been subjected to overheating, alteration, misuse, negligence, accidents or abrasion. (2) Products used in commercial establishments.

WARRANTY PERFORMANCE

In the event of any defect covered under this warranty, **EURO-PRO Operating LLC** will only be obligated, at **EURO-PRO Operating LLC's** option. To repair the defective part or unit or furnish a new or reconditioned part or unit in exchange for the part or unit that is defective. Written notice of any malfunction or defects must be given within 10 days of the time of the defect is discovered and must be accompanied by the **original consumer purchase receipt**.

Send freight prepaid to **EURO-PRO Operating LLC**, 94 Main Mill Street, Door 16, Plattsburgh, N.Y. 12901. Please include \$14.95 to cover the cost of return shipping and handling*.

The liability of **EURO-PRO Operating LLC** is limited solely to the cost of the repair or replacement of the unit at our option. This warranty does not cover normal wear of parts and does not apply to any unit that has been tampered with or used for commercial purposes. This limited warranty does not cover damage caused by misuse, abuse, negligent handling or damage due to faulty packaging or mishandling in transit.

This warranty is extended to the original purchaser of the unit and excludes all other legal and/or conventional warranties. The responsibility of **EURO-PRO Operating LLC** if any, is limited to the specific obligations expressly assumed by it under the terms of the limited warranty. **In no event is EURO-PRO Operating LLC** liable for incidental or consequential damages of any nature whatsoever. Some states do not permit the exclusion or limitation of incidental or consequential damages, so the above may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

***Important: Carefully pack item to avoid damage in shipping. Be sure to include proof of purchase date and to attach tag to item before packing with your name, complete address and phone number with a note giving purchase information, model number and what you believe is the problem with item. We recommend you insure the package (as damage in shipping is not covered by your warranty). Mark the outside of your package "ATTENTION CUSTOMER SERVICE".** We are constantly striving to improve our products, therefore the specifications contained herein are subject to change without notice.



OWNERSHIP REGISTRATION CARD

Please fill out and mail the product registration card within ten (10) days of purchase. The registration will enable us to contact you in the unlikely event of a product safety notification. By returning this card you acknowledge to have read and understood the instructions for use, and warnings set forth in the accompanying instructions.

RETURN TO **EURO-PRO Operating LLC**, 94 Main Mill Street, Door 16, Plattsburgh, N.Y. 12901

XSP21HCH/XSP21HCU

Appliance model

Date purchased Name of store

Owner's name

Address City State Zip Code