


LOWER OVEN PARTS

For Models: GBD307PRB03, GBD307PRQ03, GBD307PRS03, GBD307PRY03

(Black) (Desinger White) (Stainless) (Universal Stainless)

30" BUILT-IN ELECTRIC
DOUBLE OVEN
CONVECTION-UPPER
SELF-CLEAN (GOLD LINE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS

For Models: GBD307PRB03, GBD307PRQ03, GBD307PRS03, GBD307PRY03

(Black) (Desinger White) (Stainless) (Universal Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8303647	Literature Parts Installation Instructions Use & Care Guide	3	4455605	Hinge Receiver Left	24	W10161110	Back, Chassis
	W10162171	English		4455606	Right	25		Liner, Oven (Not serviceable)
	W10162172	French	4	W10105790	Bumper, Door	28	9760677	Deflector, Bottom
	8302068	Tech Sheet	5	9760888	Latch, Motorized	29	9759242	Thermostat (TOD)
	9762761	Safer Cooking Tips	6	8302349	Divider, Vent	30	9759713	Base, Chassis
	W10065852	English	7	8303099	Top, Chassis	31	4448933	Retainer, Gasket
		French	8	8281236	Screw	32	4451747	Cover, Back
2		Trim, Side Right		3400805	Black	33		Vent, Bottom Trim
	W10136098	Black	9	4452158	Silver		8303583	Black
	W10136100	White	10	W10067870	Tube, Vent		8303584	White
	W10166949	Stainless	11	W10009930	Lens, Light		8303582	Stainless
		Left			Assembly, Oven	34	4449845	Support, Bracket
	W10136099	Black	12	4452166	Light			
	W10136101	White	13	4449809	Bulb, Light			
	W10166948	Stainless	14	W10130368	Screw			
	8281236	Screw	15	4455382	Frame, Front			
			16	4455382	Gasket, Door			
			17	4449040	Screw			
			18	4450118	Nut			
			19	4452152	Bracket, Mounting			
			20	4451478	Support, Insulation			
			21	3196176	Screw			
			22	4449154	Screw			
			23	3400832	Screw			
			23	4455641	Side, Chassis			


FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449316 Insulation, Wrap
4450365 Insulation, Back

UPPER OVEN PARTS

For Models: GBD307PRB03, GBD307PRQ03, GBD307PRS03, GBD307PRY03
(Black) (Desinger White) (Stainless) (Universal Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models: GBD307PRB03, GBD307PRQ03, GBD307PRS03, GBD307PRY03
(Black) (Desinger White) (Stainless) (Universal Stainless)

Illus. No.	Part No.	DESCRIPTION
1	4449809	Screw
2	4449154	Screw
3		Hinge Receiver
	4455606	Right
	4455605	Left
4	W10105790	Bumper, Door
5	3196176	Screw
6	8302349	Divider, Vent
7	8303099	Top, Chassis
8	4448444	Grommet
9	4452158	Tube, Vent
10	W10067870	Lens, Light
11	W10009930	Assembly, Oven Light
12	4452166	Bulb, Light
13	9760888	Latch, Motorized
14	W10130368	Frame, Front
15	4455382	Gasket, Door
16	4449040	Screw
17	4450118	Nut
18	3400832	Screw
19	4451478	Support, Insulation
21		Rail, Side
	8302793	Right
	8302794	Left
22	4455641	Side, Chassis
23	W10161110	Back, Chassis
24		Liner, Oven (Not serviceable)
26	4452267	Vent, Center
27	9759242	Thermostat (TOD)
28	4448933	Retainer, Gasket
29	4451747	Cover, Back
30	4449845	Support, Bracket


FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449316 Insulation, Wrap
4450365 Insulation, Back

OVEN DOOR PARTS

For Models: GBD307PRB03, GBD307PRQ03, GBD307PRS03, GBD307PRY03
 (Black) (Desinger White) (Stainless) (Universal Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9759413	Panel, Door
2		Hinge, Door
	9760577	Right
	9760578	Left
3	4449259	Glass, Inner
4	8303810	Nameplate
5	8303878	Pad, Handle
6		Clip, Door
	8303389BL	Black
	8303389WH	White
	W10166937	Stainless
7	9759225	Glass, Inner


Illus. No.	Part No.	DESCRIPTION
8	4449743	Screw
9	4451040	Screw
10	4449809	Screw
11	4448520	Bumper, Door (3)
12		Assembly, Door
		Glass
		Upper
	8303300	Black
	8303306	White
	8303288	Stainless
	8304177	Silver
		Lower
	8303301	Black
	8303307	White
	8303289	Stainless
	8304178	Silver

Illus. No.	Part No.	DESCRIPTION
13		Door Handle
	8302813	Black
	8302814	White
	8303164	Stainless
14	W10136473	Bracket, Handle
15	9759229	Bracket(2nd Glass)
16	9759230	Bracket(3rd Glass)
18	4451722	Insulation, door
19	4457103	Shield, Heat
20	4457132	Retainer, Glass
22	4457114	Shield, Heat

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: GBD307PRB03, GBD307PRQ03, GBD307PRS03, GBD307PRY03
 (Black) (Desinger White) (Stainless) (Universal Stainless)




Illus. No.	Part No.	DESCRIPTION
1	4448988	Cover, Fan
2	9760771	Element, Broil
3	4448717	Rack, Oven
4	9760766	Element, Convection Bake
5	4449154	Screw
6	W10116228	Motor, Convection Fan
7	W10116351	Blade, Fan
8	W10116349	Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GBD307PRB03, GBD307PRQ03, GBD307PRS03, GBD307PRY03
 (Black) (Desinger White) (Stainless) (Universal Stainless)




Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	8302848	Black
	8302849	White
2	8304153	Apollo Gray
	W10161676	Black
	W10161677	White
3	W10112118	Silver
	8303883	Assembly, Control
	4449745	Screw
4	W10153086	Backer, Control Panel
	4449745	Screw
5	4449745	Screw
6	8301848	Latch, Sister Board
7	W10166944	Cladding, Control Panel (Stainless) Model Only

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: GBD307PRB03, GBD307PRQ03, GBD307PRS03, GBD307PRY03

(Black) (Desinger White) (Stainless) (Universal Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Assembly, Vent
2	4455178	Elbow, Vent Top
3	4455177	Elbow, Vent Bottom
4		Blower
	W10016550	45MM Lower Oven
	4457289	65MM Upper Oven
	4455191	Bracket
5	4451758	Foam, Block

Illus. No.	Part No.	DESCRIPTION
6	9760587	Transformer, Control
7	8302390	Bracket, Support Air Stop
8	3400080	Screw
9	4450038	Screw
10	4449809	Screw
11	4449868	Block, Terminal
12	4449154	Screw
13	8303497	Vent, Control Panel
14		Side, Control Top
	4451597	Right
	4451598	Left

Illus. No.	Part No.	DESCRIPTION
15	9759135	Back, Control
16	4450551	Cover, Top Rear
17	4448664	Clamp
18	4452367	Cover, Top Front
19	9759243	Thermostat, Oven
20	8302143	Suppressor
21	7103P027-60	Nut, Terminal Block

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: GBD307PRB03, GBD307PRQ03, GBD307PRS03, GBD307PRY03
 (Black) (Desinger White) (Stainless) (Universal Stainless)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<div style="display: flex; justify-content: space-between;"> <div style="width: 30%;"> <p><u>PAINT, TOUCH-UP (1/2oz.)</u></p> <p>72017 White 261869 Cord Brown 72032 Black</p> <p><u>PAINT, SPRAY</u></p> <p>350930 White 261900 Citrine White 830864 Black</p> <p><u>ADHESIVE</u></p> <p>591014 Adhesive Loctite (1/3 oz.) 482338 Sealer, Silastic (3 oz.)</p> </div> <div style="width: 35%;"> <p><u>SPLICING WIRES--25FT. LENGTH</u></p> <p>242828 Wire (12 Ga. 150 c Black)</p> <p>242820 Wire (14 Ga. 150 c Black)</p> <p>242821 Wire (14 Ga. 150 c Blue)</p> <p>242822 Wire (14 Ga. 150 c Brown)</p> <p>242830 Wire (14 Ga. 200 c Brown)</p> <p>242823 Wire (14 Ga. 150 c Green)</p> <p>242824 Wire (14 Ga. 150 c Orange)</p> <p>242825 Wire (14 Ga. 150 c Red)</p> <p>242831 Wire (14 Ga. 200 c Red)</p> <p>242827 Wire (14 Ga. 150 c Yellow)</p> </div> <div style="width: 30%;"> <p><u>WIRING HARNESS PARTS</u></p> <p>8301909 Harness, Lower Latch</p> <p>4449809 Screw</p> <p>8301777 Harness, Main</p> <p>4450953 Conduit, Double</p> <p>4452400 Lead, Ground Wire</p> <p>4450800 Screw</p> <p>4448664 Clamp</p> <p>4449809 Screw</p> <p>98997 Clip</p> <p>4452222 Spacer, Harness</p> <p>4454835 Tie, Cable</p> <p>4451761 Support, Wiring</p> <p>4454842 Tie, Cable</p> <p><u>Miscellaneous</u></p> <p>4448950 Screw, Install (4)</p> </div> </div>		

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST