



User's Guide

HP Part Number: F2238-90001 First Edition: Jan 2009

Legal Notices

This manual and any examples contained herein are provided "as is" and are subject to change without notice. Hewlett-Packard Company makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability, non-infringement and fitness for a particular purpose. In this regard, HP shall not be liable for technical or editorial errors or omissions contained in the manual.

Hewlett-Packard Company shall not be liable for any errors or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or the examples contained herein.

Copyright © 2008 Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation of this manual is prohibited without prior written permission of Hewlett-Packard Company, except as allowed under the copyright laws.

Hewlett-Packard Company 16399 West Bernardo Drive San Diego, CA 92127-1899 USA

Printing History Edition 1

January 2009

POWER SUPPLY

HP OfficeCalc 300 is a dual-powered (high power solar + back-up battery) calculator operational under any lighting conditions.

Auto power-off function

The calculator switches the off automatically if there has been no key entry for about 8 minutes.

Battery Change

Remove the screw and the battery cover. Install $\underline{\textbf{a}}$ new battery with the '+' symbol facing upwards. Replace the battery cover and secure the screw. When done, press a pointed object on the RESET hole to reset the calculator.

2. KEY INDEX

[ON/AC] : Power on / All Clear key

[C/CE] : Clear/Clear entry key

[→] : Shift-back key $\lceil \sqrt{} \rceil$: Square root key [REPLAY]: Automatic replay key [%] : Percentage key

 $[\Delta][\nabla]$: Check or review keys [CORRECT]: Correction key

[GT] : Grand total key [00] : Double zero key [M+]: Memory plus key [M-]: Memory minus key

[MRC] : Memory recall / Memory Clear key

[SET] : Set tax rate key

 $[{TAX+\over \text{STORE}}^+]$:Price with tax key / To store tax rate when pressing [SET] and $[{TAX+\over \text{STORE}}^+]$ keys

[$^{TAX^-}_{RECALL}$] : Price without tax key / To recall tax rate when pressing [SET] and [$^{TAX^-}_{RECALL}$] keys

F 4 2 9 A OOOOO	Decimal point selection switch – F –: Floating decimal mode – 4 2 0 – : Fixed decimal mode – A –: ADD mode, automatically enters the monetary decimal in addition and subtraction
	calculations.
1.5/4.1 (OO)	Round-up/Round-off/Round-down switch

DISPLAY ANNOTATIONS



REP: Replay mode + : Add operation **CRT**: Correction mode -: Subtract operation

188: Item counter (max 105) x: Multiply operation GT : Grand Total memory loaded ÷ : Divide operation

= : Equals **MEMORY**: Memory Loaded **ERROR**: Overflow/Logic error ANS: Answer

-MINUS: Negative (or Minus)

%: Percent calculation

TAX+: Price including tax TAX: Amount of tax RATE : Set tax rate TAX-: Price excluding tax

Operations General Calculations

Example	TA A	ВВ	Operation	Display
			ON/AC	0.
$100 + 50 \cdot 30 = 10 \times 20 \div 0.5 =$	Free	F	100 ± 50 = 30 = 10 × 20 ÷ 0.5 =	120. 400.
5000 ÷ 3 = 5000 ÷ 3 = 5000 ÷ 3 =	UP 5/4 CUT	2 2 2	5000 ÷ 3 = 5000 ÷ 3 = 5000 ÷ 3 =	1'666.67 1'666.67 1'666.66
\$ 12.34 34.56 -56.78 78.90 \$ 69.02	Free	Α	1234 ± 3456 = 5678 ± 7890 =	12.34 46.9 -9.88 69.02
123456789012x 66666=	Free	F	123456789012 X 66666 = C.CE C.CE	ERROR 82.303702962739 82.303702962739 0.
√9 ×5	Free	F	9√×5=	15.
• 10% of 1500 • 5% add-on of 1500	Free	F	1500×10% 1500+5%	150.
(1500 +5% =) (1500 -5% =)			1500 = 5 %	1'575. 1'425.
Percentage of 20 against 500			20 ÷ 5 00 %	4.(%)
368 + 97 + 97 = 839 - 47 - 47 - 47 = 5 -4 =	Free	F	368±97== 839-47=== 5÷====	562. 698. 0.0016
22.5 ³ =			22.5⋉≡≡	11'390.625
5 x 6 = 5 x 8 =	Free	F	5 x 6 = 8 =	30. 40.
9 ÷ 3 = 6 ÷ 3 =	Free	F	9	3. 2.
25 x 5 -)84 ÷ 3 +)68 + 17	Free	F	0N/AC 25 × 5 M+ 84 ÷ 3 M- 68 + 17 M+ MRC MRC	MEMORY 125. MEMORY 28. MEMORY 85. MEMORY 182. 182.
123478 + 5 =	Free	F	123456 → → 78 + 5 =	123'456. 1'234. 123'478. 123'483.
456 + 378 =	Free	F	456 + 345 C.CE 378 =	0. 834.

Check and Correct

E.g.: 5×6÷3+2-3=9 Key in: $5 \times 6 \div 3 + 5 - 3 = 12$

Input error

Check and correct as below:

Check and t	correct as ber	O * * .	
OPERATION	DISP	REMARK	
A	O1 REP	5. ^X	
_	02 [EF]	6. ÷	Check forward step by step
	03 🖭	3. +	
_	04 REP	5.	
CORRECT	04 CRT REP	5. -	
2	04 CRT REP	2.	Correct input
CORRECT	04 REP	2.	
AUTO	05 REP	3.	Check the
REPLAY	06 REP	9.	correct result

Tax Calculations				
Example	T/A	AB B	Operation	Display
Set Rate (Tax) at 5%	Free	F	ON/AC 5 SET TAX+	0. 5. ^{RATE} 5. ^{RATE}
Check rate set.	Free	Free	SET TAX-	5. RATE
Calculate the selling price and tax amount to include the tax rate of 5% when the cost price is \$1,000.	5/4	2	ON/AC 1000 TAX+ TAX+	0. 1050.00 TAX 50.00
Calculate the selling price and tax amount to exclude the tax rate of 5% when the cost price is \$1,000	5/4	2	1000 TAX- TAX-	TAX- 952.38 TAX 47.62



HP Limited Hardware Warranty and Customer Care

This HP Limited Warranty gives you, the end-user customer, express limited warranty rights from HP, the manufacturer. Please refer to HP's Web site for an extensive description of your limited warranty entitlements. In addition, you may also have other legal rights under applicable local law or special written agreement with HP

Limited Hardware Warranty Period

Duration: 12 months total (may vary by region, please visit www.hp.com/support for latest information)

General Terms

EXCEPT FOR THE WARRANTIES SPECIFICALLY PROVIDED FOR IN SUBSEQUENT PARARGRAPHS OF THIS SECTION, HP MAKES NO OTHER EXPRESS WARRANTY OR CONDITION WHETHER WRITTEN OR ORAL. TO THE EXTENT ALLOWED BY LOCAL LAW, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY SET FORTH IN THE SUBSEQUENT PARAGRAPHS OF THIS SECTION. Some countries, states or provinces do not allow limitations on the duration of an implied warranty, so the above limitation or exclusion might not apply to you. This warranty gives you specific legal rights and you might also have other rights that vary from country to country, state to state, or province to province.

TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATEMENT ARE YOUR SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL HP OR ITS SUPPLIERS BE LIABLE FOR LOSS OF DATA OR FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. Some countries, States or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

FOR CONSUMER TRANSACTIONS IN AUSTRALIA AND NEW ZEALAND: THE WARRANTY TERMS CONTAINED IN THIS STATEMENT, EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT OR MODIFY AND ARE IN ADDITION TO THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THIS PRODUCT TO YOU.

Notwithstanding the above disclaimers, HP expressly warrants to you, the end-user customer, that HP hardware, accessories and supplies will be free from defects in materials and workmanship after the date of purchase, for the period specified above. If HP receives notice of such defects during the warranty period, HP will, at its option, either repair or replace products which prove to be defective. Replacement products may be either new or like-new.

HP also expressly warrants to you that HP software will not fail to execute its programming instructions after the date of purchase, for the period specified above, due to defects in material and workmanship when properly installed and used. If HP receives notice of such defects during the warranty period, HP will replace software media which does not execute its programming instructions due to such defects.

Exclusions

HP does not warrant that the operation of HP products will be uninterrupted or error free. If HP is unable, within a reasonable time, to repair or replace any product to a condition as warranted, you will be entitled to a refund of the purchase price upon prompt return of the product with proof of purchase.

HP products may contain remanufactured parts equivalent to new in performance or may have been subject to incidental use. Warranty does not apply to defects resulting from (a) improper or inadequate maintenance or calibration, (b) software, interfacing, parts or supplies not supplied by HP, (c) unauthorized modification or misuse, (d) operation outside of the published environmental specifications for the product, or (e) improper site preparation or maintenance.

Customer Care

In addition to the one year hardware warranty your HP calculator also comes with one year of technical support. If you need assistance, HP customer care can be reached by either email or telephone. Before calling please locate the call center nearest you from the list below. Have your proof of purchase and calculator serial number ready when you call.

Telephone numbers are subject to change, and local and national telephone rates may apply. A complete list is available on the web at: www.hp.com/support.

Country/Region	Contact
Africa (English)	www.hp.com/support
Afrique (français)	www.hp.com/support
Argentina	0-800-555-5000
Australia	1300-551-664
Belgique (français)	02 620 00 85
Belgium (English)	02 620 00 86
Bolivia	800-100-193
Brasil	0-800-709-7751
Canada	800-HP-INVENT
Caribbean	1-800-711-2884
Česká republikaik	296 335 612
Chile	800-360-999
China 中国	010-58301327
Colombia	01-8000-51-4746-8368
Costa Rica	0-800-011-0524
Denmark	82 33 28 44
Deutschland	069 9530 7103
Ecuador	800-711-2884
El Salvador	800-6160
España	913753382
France	01 4993 9006
Greece Ελλάδα	210 969 6421
Guatemala	1-800-999-5105
Honduras	800-711-2884
Hong Kong 香港特別行政區	852 2833-1111
India	www.hp.com/support/indic
Indonesia	+65 6100 6682
Ireland	01 605 0356
Italia	02 754 19 782
Japan 日本	81-3-6666-9925
Korea 한국	www.hp.com/support/korea
Magyarország	www.hp.com/support
Malaysia	+65 6100 6682
México	01-800-474-68368
Middle East International	www.hp.com/support
Netherland	020 654 5301
New Zealand	0800-551-664
Nicaragua	1-800-711-2884
Norwegen	23500027
Österreich	01 360 277 1203
Panamá	001-800-711-2884
Paraguay	(009) 800-541-0006
Perú	0-800-10111
Philippines	+65 6100 6682
Polska	www.hp.com/support
Portugal	021 318 0093
Puerto Rico	1-877 232 0589
Russia Россия	495 228 3050
Schweiz (Deutsch)	01 439 5358
Singapore	6100 6682
South Africa	0800980410
South Korea 한국	2-561-2700
Suisse (français)	022 827 8780
Suisse (français)	022 827 8780

Country/Region	Contact
Africa (English)	www.hp.com/support
Suomi	09 8171 0281
Sverige	08 5199 2065
Svizzera (italiano)	022 567 5308
Türkiye	www.hp.com/support
Taiwan 臺灣	+852 28052563
Thailand ไทย	+65 6100 6682
United Kingdom	0207 458 0161
United States	800-HP INVENT
Uruguay	0004-054-177
Venezuela	0-800-474-68368
Viêt Nam	+65 6100 6682

Regulatory Information

European Union Regulatory Notice

This product complies with the following EU Directives:

• Low Voltage Directive 2006/95/EC

• EMC Directive 2004/108/EC

Compliance with these directives implies conformity to applicable harmonized European standards (European Norms) which are listed on the EU Declaration of Conformity issued by Hewlett-Packard for this product or product family.

This compliance is indicated by the following conformity marking placed on the product:



This marking is valid for non-Telecom products and EU harmonized Telecom products (e.g. Bluetooth).



non-harmonized Telecom products . *Notified body number (used only if applicable refer to the product label)

Hewlett-Packard GmbH, HQ-TRE, Herrenberger Srasse 140, 71034 Boeblingen, Germany

Japanese Notice

この装置は、情報処理装置等電波障害自主規制協議会 (VCCI) の基準 に基づくクラス B情報技術装置です。この装置は、家庭環境で使用すること を目的としていますが、この装置がラジオやテレビジョン受信機に近接して 使用されると、受信障害を引き起こすことがあります。 取扱説明書に従って正しい取り扱いをして下さい。

Disposal of Waste Equipment by Users in Private Household in the European Union



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste

equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Perchlorate Material - special handling may apply

This calculator's Memory Backup battery may contain perchlorate and may require special handling when recycled or disposed in California

Chemical substances

HP is committed to providing our customers with information about the chemical substances in our products as needed to comply with legal requirements such as REACH (Regulation EC No 1907/2006 of the European Parliament and the Council). A chemical information report for this product can be found at: www.hp.com/qo/reach.

67-OFFICECALC300-01A