

RadioShack®



43-141

QUICK guide START

Expandable • Caller ID 5.8GHz Digital Cordless Phone

Thank you for purchasing your 5.8GHz Cordless Telephone from **RadioShack**.



Please read this Quick Start Guide before installing, setting up and using your new product.

What's Included

- Handsets (2)
- Base (1)
- Charger (1)
- Quick Start Guide (1)
- User's Guide (1)
- Ni-MH Battery Packs (2) (inside handset)
- Modular Cord (1)
- AC Adapters (2)
- Belt Clips (2)


Step 1: Selecting a Location

Select a location that is:

- near an accessible AC outlet
- near a telephone line jack
- away from electrical machinery, electrical appliances, metal walls or filing cabinets, wireless intercoms, alarms, and room monitors
- away from other cordless phones


Step 2: Connecting the Phone Base

1. Plug one end of the modular cord into the **TEL LINE** jack. Then plug the other end into a modular phone line jack.
2. Plug the AC adapter's barrel plug into the **DC IN 9V** jack and route the adapter's cord through the strain relief slot on the base. Then plug the AC adapter into a standard AC outlet.



Step 3: Installing the Charger


1. Insert the supplied AC adapter's barrel plug into the **DC IN 9V** jack.
2. Route the cord through the groove and plug the adapter into a standard AC outlet.



Step 4: Connecting and Charging the Battery Packs

1. Remove the cover.
2. Connect the battery pack with the correct polarity.
3. Replace the cover.
4. Place the handsets in the base or chargers. Make sure that charge LED illuminates.


Before using your phone, you must charge the handsets 15-20 hours.



Step 5: Making and Receiving a Call


To Make a Call

1. Pick up the handset.
2. Press **TALK/FLASH**.
3. Dial the number.




To Receive a Call

1. Pick up the handset.
2. Press **TALK/FLASH**.



To Hang Up a Call

Press **END** or return the handset to the charging cradle.



Note: Actual product may vary from the images found in this document.

©2007. **RadioShack** Corporation.
All rights reserved. **RadioShack** and
RadioShack.com are trademarks
used by **RadioShack** Corporation.

UPZZ69845BZ(0)
43-141
01A07
Printed in China



GUÍA DE Inicio RÁPIDO

43-141

Teléfono Inalámbrico 5.8 GHz Ampliable Digital con Identificador de Llamadas

Le agradecemos la compra del Teléfono Inalámbrico 5.8GHz de **RadioShack**.



Antes de instalar, configurar y utilizar el nuevo teléfono, deberá leer esta Guía de Inicio Rápido.

lo que viene incluido

- Auriculares (3)
- Base (1)
- Cargador (1)
- Manual de Instrucciones (1)
- Guía de Inicio Rápido (1)
- Batería Ni-MH (2) (en el microteléfono)
- Cable Modular (1)
- Adaptadores CA (2)
- Clip para el Cinturón (2)


Paso 1: Seleccionar la Ubicación

Seleccione una ubicación que reúna estas características:

- cerca de una toma eléctrica CA de fácil acceso
- cerca de una toma de la línea telefónica
- lejos de cualquier actividad normal en la zona
- lejos de aparatos eléctricos, electrodomésticos, paredes metálicas o armarios archivadores, intercomunicadores inalámbricos, alarmas, y monitores
- lejos de otros teléfonos inalámbricos


Paso 2: Conectar el Teléfono Base

1. Conecte un extremo del cable modular en la entrada **TEL LINE (LÍNEA TEL)**. Después conecte el otro extremo a una toma de la línea telefónica.
2. Conecte el extremo cilíndrico del cable del adaptador CA en la entrada **DC IN 9V (ENTRADA CC 9V)** e introduzca el cable del adaptador por la ranura de sujeción del cable en la base. Después conecte el adaptador CA en cualquier toma de corriente estándar.




Paso 3: Instalar el Cargador

1. Enchufe el conector cilíndrico del adaptador CA en la toma de entrada **DC IN 9V**.
2. Introduzca el cable por la ranura y conecte el adaptador en una toma eléctrica CA.



Paso 4: Conectar y Cargar la Batería


1. Retire la tapa.
 2. Conecte la batería siguiendo las indicaciones de polaridad.
 3. Vuelva a colocar la tapa.
 4. Coloque el microteléfono en la base o los cargadores. Compruebe que el LED de carga se ilumina.
- Antes de utilizar el teléfono, deberá cargar el microteléfono durante 15-20 horas.**



Paso 5: Hacer y Recibir Llamadas


Para Hacer una Llamada

1. Tome el microteléfono.
2. Pulse **TALK/FLASH**.
3. Marque el número.




Para Recibir una Llamada

1. Tome el microteléfono.
2. Pulse **TALK/FLASH**.



Para Finalizar una Llamada

Pulse **END** o vuelva a colocar el microteléfono en el dispositivo de carga.



Nota: El producto real puede ser distinto de las imágenes mostradas en este documento.