

CXS-3100

SERVICE MANUAL

E Model

Ver 1.0 2001. 04

- CXS-3100 is composed of following models.
As for the service manual, it is issued for each component model, then, please refer to it.

COMPONENT MODEL NAME FOR CXS-3100


FM/AM COMPACT DISC PLAYER	CDX-L570X
DUAL CONE SPEAKER	XS-F1611

• PARTS LIST

Ref. No.	Part No.	Description	Remark
		ACCESSORIES & PACKING MATERIALS *****	
	1-544-814-11	SPEAKER (16cm) (XS-F1611)	
	3-226-763-21	MANUAL, INSTRUCTION (ENGLISH,SPANISH,TRADITIONAL CHINESE) (for CDX-L570X)	
	3-226-762-11	MANUAL, INSTRUCTION, INSTALL (ENGLISH,SPANISH,TRADITIONAL CHINESE) (for CDX-L570X)	
	3-230-418-21	MANUAL, INSTRUCTION, INSTALL (ENGLISH,FRENCH,SPANISH, TRADITIONAL CHINESE) (for XS-F1611)	
	X-3378-390-1	CASE (PANEL) ASSY (for CDX-L570X)	

PARTS FOR INSTALLATION AND CONNECTIONS *****

1	3-232-743-01	TEMPLATE
2	1-574-318-41	CORD, SPEAKER (R-CH) (GRAY)
2	1-574-318-71	CORD, SPEAKER (L-CH) (WHITE)
3	X-3368-736-1	SCREW ASSY
4	X-3380-451-1	NET ASSY, GRILLE
5	3-014-370-21	FRAME, FITTING
6	X-3366-405-1	SCREW ASSY (EXP), FITTING
7	3-934-325-01	SCREW +K (5X8) TAPPING
8	3-226-508-01	COLLAR
9	1-776-207-82	CORD (WITH CONNECTOR) (POWER)
10	3-030-929-01	SPRING, FITTING



CAR STEREO SYSTEM

9-873-516-11
2001D0400-1
© 2001. 4

Sony Corporation
e Vehicle Company
Shinagawa Tec Service Manual Production Group

SONY®

