

STERLING

A KOHLER COMPANY

INSTALLATION INSTRUCTIONS


CERAMIC WASHERLESS TWIN HANDLE BAR FAUCET

1
Before you begin

Use this diagram to familiarize yourself with the various parts of the faucet assembly. Make sure you have all the illustrated parts before you begin installation.

If you are putting in a new sink, it is easier to mount the faucet, drain and any other accessories **before** installing the sink into the countertop.

- Observe all local plumbing codes.
- Carefully inspect the valve parts for any damage.
- Flush all piping thoroughly before installing.
- Shut off hot & cold water supplies.
- Do not use plumber's putty or thread sealants on mounting nuts or coupling nuts.




E045600

5/99

STERLING

A KOHLER COMPANY

P.O. Box 427, Oklahoma Street
Sheridan, Arkansas 72150-0427




SPECIAL NOTE: Wristblade and Decorator Bell Handles are not interchangeable.

E045600

TWIN HANDLE BAR FAUCET

2 Items you need



NOTE: OTHER TOOLS MAY BE NEEDED TO REMOVE OLD FAUCET


1 Phillips screwdriver, channel pliers, adjustable wrench, common screwdriver. Plumber's Putty or silicone caulk and pipe dope. Caution: Do not use pipe dope or threadsealant on plastic nuts.

OPTIONAL MATERIALS:

- Supply stops (2) Some installations may require stops to be installed.
- Supply tubing (2) and fittings will need to be provided. You may need 3/8" water supply with preformed ends.


2 You may need the above materials.

HELPFUL OPTION:




3 Basin wrench for removing old faucet.


3 Remove old faucet



1 Turn off both water supplies.




2 Disconnect supply lines.




3 Remove mounting nuts, lift off faucet.


4 Install faucet




1 With putty plate in position, insert faucet shanks down through top of sink. Align faucet on sink.



2 From underside of sink fasten faucet with plastic mounting nuts. FINGER tighten securely. DO NOT OVER TIGHTEN.



3 Connect hot and cold supply lines onto faucet shanks with coupling nuts. FINGER tighten securely.



4 Unscrew aerator from the end of the spout. Turn on hot and cold water to flush lines and faucet. Turn faucet off and replace aerator.

NOTE: Clean with mild detergent and soft cloth. Do not use abrasive cleaners.

5 Sterling Limited Lifetime Warranty

Sterling Plumbing Group, Inc. ("Sterling") warrants this faucet to be free of manufacturing defects and to be drip free for as long as you own your home. Damage due to improper installation, maintenance or handling are not considered manufacturing defects and are not covered by this warranty. Labor, shipping and installation costs or other charges incidental to warranty service are to be borne by the original purchaser. This warranty is valid for the original purchaser only.

Sterling will, at its election, repair or replace a faucet where Sterling's inspection discloses any such defects occurring in normal residential usage.

To obtain warranty service return the defective part(s) to your cooperating retail seller or send them to our Customer Service Department, P.O. Box 427, Sheridan, AR 72150. Re:ier any questions to our Customer Service Department at 1-800-245-2207.

IMPLIED WARRANTIES INCLUDING THAT OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY LIMITED TO ONE YEAR FROM DATE OF PURCHASE. STERLING DISCLAIMS ANY RESPONSIBILITY FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of special, incidental or consequential damages, so these limitations or exclusions may not apply to you. This warranty gives you special legal rights. You may also have other rights which vary from state to state.

This is our exclusive written warranty.

For more information on Sterling Faucets, please call 1-800-STERLING.

STERLING
A KOHLER COMPANY

P.O. Box 427, Sheridan, AR 72150