

User Guide Toshiba 1.8"ZIF to 2.5" IDE Hard Drive Connector Converter (AAT18ZIF25)



Note: The master and slave pin settings on the 50-pin IDE connector is disabled.

v4.1.11

Technical Support

If you need any assistance to get your unit functioning properly, please have your product information ready and contact Addonics Technical Support at:

Hours: 8:30 am - 6:00 pm PST Phone: 408-453-6212 Email: http://www.addonics.com/support/query/



- 1. Open the locking lever on the Toshiba 1.8" ZIF hard drive.
- 2. Slide the flat ribbon cable of the converter into the ZIF connector on the hard drive.
- 3. Close the lever to secure the ribbon cable connection.

Connecting the Toshiba 1.8" ZIF hard drive to a 40-pin IDE connector

