


Illustrated Parts List

Model 040210-1

15000 Rated Watts Home Generator System

Manual No. 194689A Rev. B (03/25/2008)




Copyright © 2008 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.

2 BRIGGSandSTRATTON.COM

Illustrated Parts List - Main Unit

Item	Part #	Description	Item	Part #	Description
1	U203030GS	BASE, Mounting		809743	SCREW
2	187594GS	MOUNT, Vibration		NSP	ASSY, Alternator (see page 7)
3	24910GS	HHS, Trilobular 5/16 - 18 x 1/2		193506GS	DECAL, Caution Hot Surface
4	194683GS	SOLENOID, Gas Fuel		809872	GASKET
5	194829GS	FITTING, Coupling		197164GS	MUFFLER
6				194681GS	
	194830GS	REGULATOR			BASE, Muffler Box
7	195936GS	BRACKET, Mounting Solenoid		198928GS	KIT, Insulation, Muffler Base
8	842184 *	ASSY, Tee		56893GS	CRIMPTITE, 10 - 24 x 1/2
9		HHCS, M6 - 1.0 x 16	59	201282GS	ASSY, Bulkhead, Alternator End w/
10	*	HHCS, M6 - 1.0 x 30	00	1000000	Insulation
11	*	WASHER, 1/4 Lock		198929GS	KIT, Insulation, Muffler Box
12	*	NUT, M6 - 1.0		194682GS	COLLECTOR, Muffler Box
	B4300GS	HHS, Trilobular, 1/4 - 20 x 1/2		194680GS	BOX, Muffler Top
	194818GS	BATTERY		192445GS	SCREW. 10 - 32 x 5/8
	185939RGS	WIRE-A, Black	64	*	PPHMS, 4-40 x 0.19
16	198913GS	KIT, Battery Hardware	65	*	WASHER, Lock #4
17	198593AGS	WIRE-A, Red		186205GS	SWITCH, Oil Temp
18	194813GS	TUBE, Air Cleaner		194699GS	PLATE, Switch Oil Temp
19	*	HHCS, M6 - 1.0 x 12		186790CGS	WIRE
20	*	WASHER, Flat 5/16 - M8		205397GS	DECAL, Requirements, Fuel
23	1723165SM	HOSE, Oil Drain	900	§	ENGINE
24	186649GS	DECAL, Oil Drain		843644	FUEL HOSE
25	*	HHCS, 5/16 - 18 x 2.5 Full Thread	902	843438	CLAMP
26	*	NUT, 5/16 - 18			
27	*	WASHER, Lock 5/16 - M8	Items	Not Illustrated	
28	*	HHCS, 5/16 - 24 x 3/4 SEMS		199327GS	MANUAL, Install
29	*	HHCS, 5/16 - 18 x 2"		194689GS	MANUAL, Operator's
30	*	HHCS, M12 - 1.75 x 35		MS3483	MANUAL, Engine
31	*	WASHER, M12		204507GS	KIT, Manual/Accessory HGS
32	B194685GS	SUPPORT, Engine/Alternator, Black		198810GS	PAINT, Touchup, Gray 1/2 oz Bottle
34	*	WASHER, Shakeproof Ext. M6-1/4		198811GS	PAINT, Touchup, Silver 1/2 oz Bottle
35	186790GGS	WIRE, Ground		B3518GS	CAP, Funnel Oil Bottle
36	*	WASHER, Lock M10		202295GS	HOSE, Flex
37	*	WASHER, Flat, M10		198866GS	KIT, Led Remote
38	*	HHCS, M10 - 1.5 x 30		198918GS	KIT, Decals, Service
39	B196639GS	BRACKET, Mounting Alternator,			,
		Black	Option	nal Accessories	
40	196387GS	DUCT, Air	•	199475GS	PAINT, Touchup, Spray, Silver, 12oz
41	*	PPHMS, M5 - 0.8 x 20		199474GS	PAINT, Touchup, Spray, Gray, 12oz
42	*	WASHER, Lock 3/8		6030	KIT, Cold Weather (Includes Battery
43	*	SHCS, 3/8 - 16 x 1-1/4			and Oil Warmers)
44	*	HHCS, 5/16 - 18 x 3/4			
45	*	WASHER, M12 Lock	* - Ito	ms without nart n	umbers are common fasteners and
46	*	NUT, Hex M12 - 1.75		ailable at local hai	
47	*	WASHER, Flat M12			
48	*	NUT, M10 - 1.5	§ - CO	ntact Engine Man	utacturer
49	B4260GS	DISK, Engine Air			
10	2 120000	Diori, Engino / in			




4 BRIGGSandSTRATTON.COM

Illustrated Parts List - Enclosure

Item 1	Part #	Description PAD Mounting w/ Holes		Part # 194819GS	Description SEAL, Foam, Engine Air
2	19/2/303	PAD, Mounting w/ Holes BASE, Mounting ASSY, Bulkhead, Engine End		201459GS	SEAL, Foam, Alternator Air
3	10001500	ACCV Dulkhood Engine End		195733GS	MOUNT, Tie Wrap
J	19091303	Bulkhead, Engine End		195733GS 195935GS	DUCT, Rubber Alternator
		Dood Eucliniot		201058GS	
		Decal, Fuel Inlet	21		ADAPTER, Alternator
		Seal, Foam Engine Air	21		ASSY, Roof/Siderails
		Seal, Foam Engine Air			. Weldment Roof/Siderails
		Busning, 1-1/2	00		. IIISUIALIOII
		Busning, 1-3/8	22	20128265	ASSY, Bulkhead, Alternator End
		Plug, Dome 1-1/2			Decal, Caution Hot Muffler
		Pin, Hinges with Hardware			. Seal, Foam
4	198986GS	ASSY, Door, Engine. End Weldment, Door Engine End			. Pin, Hinges with Hardware
		Weldment, Door Engine End			. Bracket, Muffler
		Insulation	23	200409GS	
_		Barrel, Hinges with Hardware	24	194679GS	COVER, Air Intake Alternator
5		ASSY, Duct, Engine Air		198926GS	ASSY, Vent, Exhaust
		Decals		B1797GS	CLIP, Tree
		Lug, Ground Connect w/Hardware		198927GS	ASSY., Vent, Alternator
		Bracket, Mounting Breaker		198888GS	SEAL, Foam
		w/Hardware		194694GS	COVER, Air Intake Engine
6	198993GS	ASSY, Support, Rail		203302GS	INSULATION, Engine Door, Top
		Support Rail Engine. End Seal, Foam		197312GS	SEAL, Foam
		Seal, Foam		196397GS	INSULATION, Front/Rear Door
		Decal, Rainproof		195597GS	INSULATION, Roof
7	B4300GS	HHS, Trilobular, 1/4-20 x ½		203303GS	INSULATION, Engine Door, Bottom
8	186173GS	BUSHING, Snap, 1-3/8"		198460GS	PLUG, Dome
9	197493GS	HHS, Trilobular, 1/4-20 x ½ BUSHING, Snap, 1-3/8" BUSHING, Snap, 1-1/2"	36	192940GS	RETAINER, Hose
10	198461GS	PLUG, Dome, 1-1/2"	38	198890GS	KIT, Door, Hinge
11	*	HHCS, 3/8 - 16 x 1	39	194828GS	SET, Latch Key
12	*	WASHER, Flat, 3/8 - M10	40	198889GS	KIT, Door Latch
13	*	WASHER, Lock 3/8			
14	*	NUT, 3/8 - 16	* - Ite	ms without part r	numbers are common fasteners and
15	200438GS	ASSY, Door		ailable at local ha	
		Barrel Hinges with Hardware			
		Decals			


Exploded View & Illustrated Parts List - Control Panel



Item	Part #	Description	Item	Part #	Description
1	198911GS	ASSY, Cover, Circuit Breaker w/			DECAL, Caution, Electric Shock
		Decals	18	205395GS	DECAL, Warning Shock
2	*	SCREW, 10 x 0.62, Plastite	19	*	NUT, 1/4 - 20
3	198313GS	BREAKER, Circuit 70A, 2P	21	*	WASHER, Shakeproof, Ext M6 1/4
4	192770GS	BRACKET, Mounting Breaker	22	*	HHCS, 1/4 - 20 x 3/4
5	199011GS	LUG, Ground Connect			
6	191991GS	BOLT, 1/4-10 x 1, Plastite	Items	Not Illustrated	
7	198573GS	FUSE, Auto Type 15 Amp		201085GS	HARNESS, Wire, CTL Board to
8	196655GS	ASSY, Control Panel			Engine/Alternator
9	197492GS	SCREW, PT, M4 - 1.79 x 16.0		198517GS	HARNESS, Wire, E1 & E2 Sensing
10	198910GS	ASSY, Duct, Engine Air w/ Decals		198515GS	CONNECTOR, Terminal, 2 Pin
12	198549GS	DECAL, Terminal Block		198516GS	CONNECTOR, Terminal, 10 Pin
13	198550GS	DECAL, Ground, Neutral			
14	205393GS	DECAL, Warning, Outdoor Install	* - Ite	ms without part n	umbers are common fasteners and
15	193297GS	DE041 0 .: 0: !!		ailable at local ha	
16	205392GS	DECAL, Warning, Auto Start	5 6.1		

6 BRIGGSandSTRATTON.COM

Exploded View & Illustrated Parts List - Alternator



1	Part # 201472GS 201410GS	Description FLANGE, Front GUARD, Front
	201397GS	SHIELD, Front
4	201412GS	FAN
5	B4908GS	STAY ROD
6	201473GS	ASSY, ROTOR (Includes Items 4, 7 & 8)
7	201474GS	DIODE + VARISTOR
8	201383GS	BEARING
	201475GS	STATOR
10	201406GS	COVER, Side
	201476GS	CAPACITOR
. –	201477GS	TERMINAL BLOCK
	201478GS	GROMMET
	201407GS	SHEILD, Rear
	201479GS	BOLTS, Stator
16	*	SCREW, M5 - 0.8 x 10mm
17	205171GS	CLIP

 $^{^{\}star}$ - Items without part numbers are common fasteners and are available at local hardware stores.