



Operating Instructions for the Nickel Cadmium Rechargeable Battery Pack
Model S1465

For use with AmpliVox Amplifiers S/SW805A, S/SW222, S/SW122A, S/SW132A Model S1465 must be used with S1460 AC Adapter/recharger on AmpliVox models that incorporate the S/SW805A Stereo Multimedia Amplifier. The S1465 nickel cadmium battery pack must be fully charged prior to first use.

CAUTION: MAKE SURE THE S1460 INTERNATIONAL AC ADAPTER/RECHARGER IS CONNECTED TO THE DC IN NOT LAMP ON THE S/SW805A FRONT PANEL AND THE POWER SWITCH IS OFF .

The S/SW805A recharging system is designed for use with the AmpliVox S1465 NiCad battery pack only.

Remove the 10 D size battery holder from the unit and replace with the S1465 NiCad battery pack. When charging for the first time, allow a minimum of 24 hours . The charger automatically protects from overcharging and may be left on continually to keep the batteries in a ready state.

NOTE: The S/SW805A does not recharge while in use. The average use-



Operating Instructions for the Nickel Cadmium Rechargeable Battery Pack
Model S1465

For use with AmpliVox Amplifiers S/SW805A, S/SW222, S/SW122A, S/SW132A Model S1465 must be used with S1460 AC Adapter/recharger on AmpliVox models that incorporate the S/SW805A Stereo Multimedia Amplifier. The S1465 nickel cadmium battery pack must be fully charged prior to first use.

CAUTION: MAKE SURE THE S1460 INTERNATIONAL AC ADAPTER/RECHARGER IS CONNECTED TO THE DC IN NOT LAMP ON THE S/SW805A FRONT PANEL AND THE POWER SWITCH IS OFF .

The S/SW805A recharging system is designed for use with the AmpliVox

S1465 NiCad battery pack only. Remove the 10 D size battery holder from the unit and replace with the S1465 NiCad battery pack. When charging for the first time, allow a minimum of 24 hours . The charger automatically protects from overcharging and may be left on continually to keep the batteries in a ready state.

NOTE: The S/SW805A does not



Operating Instructions for the Nickel Cadmium Rechargeable Battery Pack
Model S1465

For use with AmpliVox Amplifiers S/SW805A, S/SW222, S/SW122A, S/SW132A Model S1465 must be used with S1460 AC Adapter/recharger on AmpliVox models that incorporate the S/SW805A Stereo Multimedia Amplifier. The S1465 nickel cadmium battery pack must be fully charged prior to first use.

CAUTION: MAKE SURE THE S1460 INTERNATIONAL AC ADAPTER/RECHARGER IS CONNECTED TO THE DC IN NOT LAMP ON THE S/SW805A FRONT PANEL AND THE POWER SWITCH IS OFF .

The S/SW805A recharging system is designed for use with the AmpliVox

S1465 NiCad battery pack only. Remove the 10 D size battery holder from the unit and replace with the S1465 NiCad battery pack. When charging for the first time, allow a minimum of 24 hours . The charger automatically protects from overcharging and may be left on continually to keep the batteries in a ready state.

NOTE: The S/SW805A does not



Operating Instructions for the Nickel Cadmium Rechargeable Battery Pack
Model S1465

For use with AmpliVox Amplifiers S/SW805A, S/SW222, S/SW122A, S/SW132A Model S1465 must be used with S1460 AC Adapter/recharger on AmpliVox models that incorporate the S/SW805A Stereo Multimedia Amplifier. The S1465 nickel cadmium battery pack must be fully charged prior to first use.

CAUTION: MAKE SURE THE S1460 INTERNATIONAL AC ADAPTER/RECHARGER IS CONNECTED TO THE DC IN NOT LAMP ON THE S/SW805A FRONT PANEL AND THE POWER SWITCH IS OFF .

The S/SW805A recharging system is designed for use with the AmpliVox

S1465 NiCad battery pack only. Remove the 10 D size battery holder from the unit and replace with the S1465 NiCad battery pack. When charging for the first time, allow a minimum of 24 hours . The charger automatically protects from overcharging and may be left on continually to keep the batteries in a ready state.

Model S1465 is a product of:



Model S1465 is a product of:



Model S1465 is a product of:



Model S1465 is a product of:

