

### IMPORTANT SAFETY INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- > Reorient or relocate the receiving antenna.
- > Increase the separation between the equipment and receiver.
- > Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- > Consult the dealer or an experienced radio / TV technician for help.

Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits.

**SEIZURE WARNING:** A small percentage of individuals may experience epileptic seizures when exposed to certain light patterns or flashing lights. Exposure to certain patterns or backgrounds on a television screen or while playing video games, including games played on the TV Games unit, may induce an epileptic seizure in these individuals. Certain conditions may induce previously undetected epileptic seizure or symptoms in these individuals or in persons who have no history of prior seizures or epilepsy. If you or anyone in your family has an epileptic condition, consult your physician prior to playing. If you or anyone in your family experience any of the following symptoms while playing a video game — dizziness, altered vision, eye or muscle twitches, loss of awareness, disorientation, any involuntary movement or convulsions — IMMEDIATELY discontinue use and consult your physician before resuming play.

-To reduce the likelihood of a seizure while playing video games:

1. Sit or stand as far from the screen as possible.
2. Play video games in a well-lit room and on the smallest available screen.
3. Do not play if you are tired.
4. Take a 10 to 15 minute break every hour.

**REPETITIVE STRAIN WARNING:** Playing video games continuously can make your muscles, joints or skin hurt after a few hours. To avoid problems such as Tendonitis, Carpel Tunnel Syndrome or skin irritation:

1. Take a 10 to 15 minute break every hour, even if you don't think you need it.
2. If your hands, wrists or arms become tired or sore while playing, stop and rest them for several hours before playing again.
3. If you continue to have sore hands, wrists or arms during or after play, stop playing and see a doctor.

**WARNING: BATTERY SAFETY INFORMATION:** Battery acid leakage can cause personal injury and cause damage to the product and surrounding property. If battery leakage occurs, thoroughly wash any affected skin, making sure to keep battery acid away from eyes, ears, nose and mouth. Immediately wash any clothing or other surface that comes into contact with leaked battery acid. Leaking batteries may make "popping" sounds.

**NEVER** mix old and new batteries or different brands of batteries.

**NEVER** mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

**NEVER** use rechargeable batteries with this product.

**NEVER** dispose of batteries in fire, as they may leak and explode.

**NEVER** disassemble, modify, or attempt to short circuit the battery compartment.

**NEVER** leave batteries in the product for long periods (a week or more) of non-use.

**NEVER** leave the product on after the batteries have lost their charge.

**NEVER** put batteries in backwards by placing the negative (-) battery pole into the positive (+) receptor slot.

**ALWAYS** have an adult install and change the batteries.

**ALWAYS** remove exhausted batteries from toy.

**ALWAYS** have an adult install batteries consistent with installation instructions.

**WARRANTY** > For warranty information, visit [www.jakks.com/warranty](http://www.jakks.com/warranty)

**TROUBLESHOOTING** > If you cannot get the product to work with your audio/video devices, please contact the device manufacturer.

TM & © 2009 JAKKS Pacific, Inc., Malibu, CA, 90265 USA.

All other symbols, marks, logos, and designs (collectively "Trademarks") are Trademarks of and proprietary to their respective owners and used under license by JAKKS Pacific, Inc.

**MADE IN CHINA.**

Contents may vary in style, color, shape and decoration from images shown on package or in advertising.

Questions or comments? [www.jakks.com](http://www.jakks.com), [consumers@jakks.com](mailto:consumers@jakks.com), or 1-877-875-2557 in North America.

Developed by HotGen Limited, London.

The ratings icon is a trademark of the Entertainment Software Association.

JAKKS Pacific

TV games.com

HotGen



AGES

8+

Menu Button

LED

ON/OFF

A Button

B Button

Directional Pad

Turn game off when not in use.



**FOR SET-UP:** (ADULT INSTALLATION REQUIRED)

**Requires 4 AAA alkaline batteries (not included)**

**1. Battery installation:** Locate the battery compartment underneath the unit. Using a Phillips screwdriver, remove the screw and the battery door. Install fresh batteries, matching polarity icons with those on the unit. Replace the battery compartment and the screw.

**2. Unit Connection:** Connect unit to TV, VCR or DVD player and select the appropriate "line in" source. Consult the audio/video device's manual for details.

## GETTING STARTED

**Press the Menu Button to exit the Title Screen and advance to the Main Menu.**



## JAKKS Pacific® Battery or Electrically-Operated Toy 90 DAY LIMITED WARRANTY

Thanks for purchasing a great JAKKS Pacific® product!  
Please immediately register your product online at [www.jakks.com/warranty](http://www.jakks.com/warranty).  
Registration is not required for the effectiveness of this limited warranty.

### IMPORTANT NOTICE TO CONSUMER:

This 90 DAY LIMITED WARRANTY applies to the original product purchaser, provided the product: 1) was purchased from an authorized JAKKS™ distributor/dealer/retailer, and 2) is returned at your expense, postage pre-paid and insured, along with the original dated sales receipt to the address noted below. Please save a copy of your original sales receipt, as the original receipt will not be returned to you. If you return the product to us without the original dated sales receipt, this warranty coverage will not apply. If the product is determined by JAKKS to be defective and returned to JAKKS within the 90 day warranty period, we will (at our option) repair or replace it. Return shipment to you may take up to 6 weeks, depending upon your location. If your product is repaired or replaced, it will be warranted for the longer of the original warranty or for 30 days after warranty service.

**SCOPE OF LIMITED WARRANTY:** The product is warranted to be: a) tested and inspected before shipment, and b) free of defects in material and workmanship for 90 days from date of purchase. If a covered defect occurs within the warranty period, then at our sole option, we will repair or replace the product or provide you with another product of equal value.

**WHAT IS NOT COVERED BY LIMITED WARRANTY:** THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN MODIFIED OR REPAIRED BY USER OR OTHERS OR IF IT HAS BEEN DAMAGED AS A RESULT OF ACCIDENT, IMMERSION IN WATER, NEGLIGENCE, ABUSE, MISUSE, BATTERY LEAKAGE, IMPROPER BATTERY INSTALLATION, UNAUTHORIZED SERVICE, LOSS OF PARTS, WEATHER, ACTS OF GOD, ANY ACTION OR OMISSION WHICH CONSTITUTES A DEVIATION FROM THE OPERATING INSTRUCTIONS, OR ANY OTHER CAUSES NOT ARISING OUT OF DEFECTS IN WORKMANSHIP OR MATERIALS.

**EXCLUSIONS FROM LIMITED WARRANTY:** THIS WARRANTY IS EXCLUSIVE OF AND IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES RELATED TO THIS PRODUCT, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SPECIAL, INCIDENTAL AND CONSEQUENTIAL DAMAGES ARISING FROM POSSESSION, USE, OR MALFUNCTION OF THIS PRODUCT ARE EXCLUDED BOTH FOR PROPERTY DAMAGE AND PERSONAL INJURY TO THE EXTENT LEGALLY PERMITTED.

**ADDITIONAL LEGAL RIGHTS:** This warranty provides specific legal rights. You may have other or different rights in your state or country.

**QUESTIONS OR COMMENTS:** If you experience product difficulties or have questions or comments, you may contact our Consumer Relations department as follows: Phone: 877-875-2557 (toll-free, North America only) or 909-594-7771 x560 (Monday-Friday, 7:30AM-4:30PM Pacific/GMT -8). Mail: JAKKS Consumer Relations, 21749 Baker Parkway, Walnut, California USA 91789. Email: [consumers@jakks.com](mailto:consumers@jakks.com)

**WHEN WRITING TO US:** Please include: 1) product name; 2) item number; 3) purchase date; 4) description of the problem being experienced; and 5) your name, address and phone number. Additionally, if eligible under the warranty and so advised by JAKKS Consumer Relations, also include the defective product and the ORIGINAL dated sales receipt evidencing product purchase. Please retain a copy of your receipt.

110108

**TAKE A BOW** Written by Mikkel Eriksen, Tor Hermansen & Shaffer Smith. Published by EMI Music Publishing; Universal Music; Sony/ATV Tunes LLC (ASCAP)

**BIG GIRLS DON'T CRY** Written by Stacy Ferguson & Tobias Gad. Published by Sony/ATV Tunes LLC; Cherry Lane Music Publishing (ASCAP)

**NO ONE** Written by Alicia J Augello-Cook, Kerry D. Brothers Jr., George Harry. Published by EMI Music; Universal Music (ASCAP)

**SHAKE IT** Written by Trace Cyrus, Timothy Healy, Anthony Improgo and Mason Musso. Published by EMI Music Publishing (ASCAP)

**I'M LIKE A BIRD** Written by Nelly Furtado. Published by EMI Music Publishing (ASCAP)

**FOREVER** Written by Robert Allen, Christopher Brown, Jamal Jones, Andre Merritt, Brian Seals. Published by Universal Music (ASCAP)

**THIS AIN'T A SCENE, IT'S AN ARMS RACE** Written by Andrew Hurley, Patrick Stumph, Joseph Trohman, Peter Wentz. Published by Sony/ATV Tunes LLC (BMI)

**GIRLS JUST WANNA HAVE FUN** Written by Robert Hazard. Published by Sony/ATV Tunes LLC (ASCAP)

**LOVE SONG** Written by Sara Bareilles. Published by Sony/ATV Tunes LLC (ASCAP)

**LOVE STORY** Written by Taylor Swift. Published by Sony/ATV Tunes LLC (BMI)

Music production by East Drive Music, Inc., New York City, NY. Produced by Brendan O'Malley and Mike Caffrey

## MAIN MENU

Press Left and Right on the Directional Pad to choose from the following Menu Options. Press the A button to select an option. Press the B button to return to the Main Menu.

**Freeplay** – Play the game as a single player.

**2 Player** – Play the game with two players.

**Options** – Adjust Volume, View High Scores, Erase Saved Data

## PAUSE MENU

Press the Menu Button to Pause the game. Select from the following options:

**Continue** – Continue playing the game.

**Vocal Level** – Adjust the volume of the vocals.

**Backing Track Level** – Adjust the volume of the background music.

**Microphone Level** – Adjust the volume of the microphone output.

**Restart** – Start the current song over.

**Exit** – Quit the game.

## SONG SELECT

After selecting either Freeplay or 2 Player mode, the Song Select screen will appear. Press Left and Right on the Directional Pad to browse. Press the A Button to select one of the following songs:

**Fergie**  
Big Girls Don't Cry

**Miley Cyrus**  
Girls Just Wanna Have Fun

**Fall Out Boy**  
This Ain't A Scene It's An Arms Race

**Sarah Bareilles**  
Love Song

**Alicia Keys**  
No One

**Rihanna**  
Take A Bow

**Chris Brown**  
Forever

**Nelly Furtado**  
I'm Like A Bird

**Taylor Swift**  
Love Story

**Metro Station**  
Shake It

*Includes Top Hits Made Famous By...*

*Get ready to show off your hot vocal chops as you sing chart-busting hits like the stars who made them famous! Blow the roof off the place, and you'll be the hit of the party. But be careful... the Success Monitor is listening, and you'll fail the song if you blow it!*

**Metro Station**  
Shake It