


COOKTOP PARTS

For Models: GW395LEPB01, GW395LEPQ01, GW395LEPT01, GW395LEPS01
(Black) (White) (Biscuit) (S.Steel)

30" Slide-In
GAS OVEN
NON-CONV



Literature Parts

Illus. No.	Part No.	DESCRIPTION
1	9761413	Literature Parts Installation Instructions
	9762258	Use & Care Guide
	9761386	Tech Sheet
	9757680	Anti-Tip Instruct.
	3191638	Safe Cooking Tips
	9759133	Safe Cooking Tips
2	9759523	Burner Box
3	4454023	Bracket, Mounting
4		Cooktop
	9760428BT	Biscuit
	9760428WH	White
	9760428BL	Black
5	3400843	Screw
6		Trim-CkTop, SI
	9759531WH	White LH
	9759531BT	Biscuit LH
	9759531BL	Black LH
	9759531SS	S.Steel LH
	9759530WH	White RH
	9759530BT	Biscuit RH
	9759530BL	Black RH
	9759530SS	S.Steel RH


Illus. No.	Part No.	DESCRIPTION
7	3196537	Screw
8	4453989	Shield, Heat
9	3192811	Bracket, Burner
10	9756821	Support, Wiring
11	9756505BL	Dome Cap, Vent
12		Grate, Burner
	9759756BL	Black (RH)
	9759756EP	Espresso (RH)
	9759756MG	Mouse Grey (RH)
	9759755BL	Black (LH)
	9759755EP	Espresso (LH)
	9759755MG	Mouse Grey (LH)
13	4449809	Screw
14	3196160	Screw
16	9759944	Thermostat (60c)
17		Vent, Center
	9760224BL	Black
	9760224WH	White
	9760224BT	Biscuit

Illus. No.	Part No.	DESCRIPTION
18		Trim, Extension
	9760520WH	White
	9760520BT	Biscuit
	9760520BL	Black
	9760520SS	S.Steel
19		Cap, Burner
		14K (LF)
	9753939GB	Black
	9753939EP	Espresso
	9753939GS	Mouse Grey
		12.5K (RR)
	3191904	Black
	3191905	Mouse Grey
	8273345	Espresso
		6K (RF, LR)
	3191898	Black
	3191899	Mouse Grey
	8273343	Espresso
23	9759629	Cover, Cktp Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GW395LEPB01, GW395LEPQ01, GW395LEPT01, GW395LEPS01
 (Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Control Panel	7	9757409	Support, Gas Valve	9		Knob
	8191141	White	8		Endcap		9759941BL	Black
	8191142	Biscuit		9756614BT	Biscuit LH		9759941WH	White
	8191143	Black		9756614WH	White LH		9759941BT	Biscuit
	8191144	S.Steel		9756614BL	Black LH	10	9758080	Module, Spark
3	9760013	Control, Migration		9756611BT	Biscuit RH	11	9780271	Screw
4	9757119	Bracket, Console		9756611WH	White RH	12	3196172	Screw
5	3196537	Screw		9756611BL	Black RH			
6	9759731	Bracket, Control						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: GW395LEPB01, GW395LEPQ01, GW395LEPT01, GW395LEPS01
 (Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: GW395LEPB01, GW395LEPQ01, GW395LEPT01, GW395LEPS01
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)	16	4453951	Deflector, Vent Bottom	37	8300802	Thermostat (TOD) (Temp.) SPST
	9757735WH	White	17	4452152	Bracket, Mounting	39	9757070	Plate, Relectance
	9757735BT	Biscuit	18	9757685	Guide, Side Panel	43	4453981	Base, Chassis
	9757735BL	Black	19	9757811	Brace, SidePanel		9756637	Gasket
	9757735SS	S.Steel (Left Hand)	20		Oven, Side Panel	49	4448933	Retainer, Gasket
	9757734WH	White		9760723PB	Black	50	4451747	Cover, Back
	9757734BT	Biscuit		9760723PW	White	51	4449809	Screw
	9757734BL	Black		9760723PC	Biscuit	54		Vent, Bottom Upper
	9757734SS	S.Steel	22	9760888	Latch, Motorized		9756481WH	White
2	3400832	Screw	23	9757807	Thermostat SPST (230)		9756481BT	Biscuit
3		Hinge Receiver	24	8053971	Brace, Main Back		9756481BL	Black
	4455605	Left Hand	25	4455641	Side, Chassis (R.H. & L.H.)	55	9756481SS	S.Steel
	4455606	Right Hand	26	9759762	Back, Chassis		9756485WH	White
4	4448520	Bumper, Door	27		Liner, Oven (Not serviceable)		9756485BT	Biscuit
5	3196160	Screw	29	4455636	Sensor		9756485BL	Black
6	9757461	Bracket,Side Panel	30	9756454	Bracket, GOC		9756485SS	S.Steel
7	8303099	Top Chassis	31	9760223	Slide, GOC	FOLLOWING PARTS NOT ILLUSTRATED		
8	9759469	Bracket, Vent Sprt	32	3196537	Screw	INSULATION		
9	9761062	Tube, Vent	33	9759890	Clip, Side Panel		9756817	Insulation, Wrap
10	4452165	Lens, Light	34	9757717	Insulation		9756470	Insulation, Back
11	4452368	Oven Light Assy						
12	4452166	Bulb, Light						
13	9757732	Shield, Heat						
14	9759060	Frame, Front						
15	4455382	Gasket, Door						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: GW395LEPB01, GW395LEPQ01, GW395LEPT01, GW395LEPS01
 (Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models: GW395LEPB01, GW395LEPQ01, GW395LEPT01, GW395LEPS01
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
5	9759641	Glass, Door Front Black
	9759639	White
	9759640	Biscuit
	9759642	S.Steel
6	3196537	Screw
7	9759635	Spacer, Glass
8		Handle, Door
	4448854	Black
	4448855	White
	4448856	Biscuit
9	8302094	Bracket, Central
10		Hinge, Door
	9760571	White RH
	9760572	White LH
11	9761935	Foot, Rear
12	8302092	Bracket, Side
13	9760592	Panel, Drawer
15	9757706	Glass, Inner
16	4457114	Shield, Heat Btm
17	4449263	Glass, Inner (2)
18	4451722	Insulation, Door
19	9759413	Liner, Door
20	9757806	Drawer & Roller
21	3196037	Foot, Front
22	422604	Roller, Drawer
23	4457132	Retainer, Glass
24		Front, Drawer
	4453921WH	White
	4453921BL	Black
	4453921BT	Biscuit
	4453921SS	S.Steel
25		Bracket, Handle
	9763497	R. Hand
	9763496	L. Hand
	4451040	Screw
26		Handle, Drawer
	9756674WH	White
	9756674BT	Biscuit
	9756674BL	Black
28	4450863	Retainer, Clip
29		Track, Drawer
	9756837	R.Side
	9756839	L.Side
30		Side, Base
	9759953	R.Side
	9759954	L.Side
31	4449743	Screw
32	9756673	Guide, Roller
33	9757707	Shield, Heat Top
34	4451040	Screw
35	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: GW395LEPB01, GW395LEPQ01, GW395LEPT01, GW395LEPS01
 (Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
1	9758810	Front, Air Duct
2		Top, Air Duct
	9757827	L.Hand
	9757828	R.Hand
3	9759320	Blower
4	4451758	Block, Foam
5		Corner, Air Duct
	9756639	R.Hand
	9756638	L.Hand
6	9757117BL	Vent, (Control Panel)
7	4450038	Screw
8	4449809	Screw
9	4449040	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: GW395LEPB01, GW395LEPQ01, GW395LEPT01, GW395LEPS01
(Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9752980	Shield, Flame	8	4453957	Pan Support, Bake	14	9756831	Tube, Broil
2	3196176	Screw	9	4454048	Electrode, Bake	15	9757700	Burner, Broil
3	4457277	Grill, Broiler	10	4454047	Burner, Bake Log	16	8054129	Ignitor, Broil
4	4457276	Pan, Broiler	11	9752737	Shield, Oven	17	4454009	Cover, Ignitor
5	9757779	Fitting, Broiler	12	4453984	Shield, Bake Flame	18	4453920	Pan, Oven Bottom
6	3196176	Screw	13	4453999	Valve, Assy	19	3196176	Screw
7	4448717	Rack, Oven						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP BURNER PARTS

For Models: GW395LEPB01, GW395LEPQ01, GW395LEPT01, GW395LEPS01
(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Burner Base w/Orifice
	9782447	Small (2)
	9782448	Large
	9782449	Turbi
2	9756827	Tubing, Burner(RF)
3	9756828	Tubing, Burner(RR)
4	9759759	Tubing, Burner(LF)
5	9756829	Tubing, Burner(LR)
6	4456818	Valve, Turbi

Illus. No.	Part No.	DESCRIPTION
7	4456816	Valve, Burner Small (2)
8	4456817	Valve, Burner Large
9	9756822	Spark Switch & Harness Assembly
10	4453755	Tube, Manifold
11	9756803	Manifold

Illus. No.	Part No.	DESCRIPTION
12	3196537	Screw
14	8523704	Bolt, Valve (4)
18	4453754	Tubing GDS to Manifold
21		Head, Burner
	9759894	Small
	4455981	Large
	4455849	Turbi
	3368921	Screw, 7-18 x .750

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: GW395LEPB01, GW395LEPQ01, GW395LEPT01, GW395LEPS01
 (Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	261869	Cord Brown
	72032	Black
<u>PAINT, SPRAY</u>		
	350930	White
	261900	Citrine White
	830864	Black
<u>ADHESIVE</u>		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
<u>SPLICING WIRES--25FT. LENGTH</u>		
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
<u>WIRING HARNESS PARTS</u>		
	9760533	Harness, Wire (Main)
	9756892	Harness, Wire (Cooktop Power)
	9756920	Harness, Wire Bake/Broil Ignit.
	9757727	Harness, Wire (Cooktop Right)
	313660	Clip, Ground Wire
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	4452222	Spacer, Harness
	3400015	Screw, Ground
<u>Miscellaneous</u>		
	814381	Hinge Pin Kit
	4448950	Screw, Install (4)
	9756609	Gasket, 19 x 388
	9758677	Power Cord
	9782676	Anit-Tip Assy
	9757427	Kit, Orific (LP) Filler,Counter Top
	9757785WH	White
	9757785BL	Black
	9757785BT	Biscuit
	9758677	Cord, Power

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST