


INSTALLATION INSTRUCTIONS

WASHERLESS CERAMIC TWIN HANDLE KITCHEN FAUCET With Spray




Before you begin

Use this diagram to familiarize yourself with the various parts of the faucet assembly. Make sure you have all the illustrated parts before you begin installation.

If you are putting in a new sink, it is easier to mount the faucet, drain and any other accessories **before** installing the sink into the countertop.

- Observe all local plumbing codes.
- Carefully inspect the valve parts for any damage.
- Flush all piping thoroughly before installing.
- Shut off hot & cold water supplies.
- Do not use plumber's putty or thread sealants on mounting nuts or coupling nuts.

_Spray Hose & Head Black w/Chrome 99S0878 White w/Chrome 00W0878C



E033300

4/99




TWIN HANDLE KITCHEN FAUCET

Items you need

NOTE: OTHER TOOLS MAY BE NEEDED TO REMOVE OLD FAUCET


Adjustable wrench, Phillips and flathead screwdrivers, and pipe sealant or Teflon tape.

Remove old faucet




Turn off both water supplies

Install faucet



If your faucet has a spray, place hole guide down through hole at extreme right of sink top. Add mounting nut to underside and FINGER tighten firmly.



on sink with shanks extending through their appropriate holes.





Flush lines

and check for leaks. With faucet off remove aerator. Turn on hot and cold to flush lines and faucet. Operate spray. Turn off faucet and replace


OPTIONAL MATERIALS

- · Supply stops (2) Some installations may require stops to be installed
- · Supply tubing (2) and fittings will need to be provided.





2 Disconnect supply lines.



Insert spray hose down through hose guide and up through center hole in sink and putty plate.


Position putty plate. Apply

Teflon tape to spray outlet on

spray outlet by rotating faucet body. Tighten securely with

body. Attach spray hose to


wrench.




5 Fasten faucet to sink with

mounting nuts supplied.

6 Connect hot & cold supply lines onto faucet shanks with coupling nuts. FINGER tighten securely.



3 Basin wrench for removing old faucet.



Remove mounting nuts, lift off faucet.



1 Turn on water supplies aerator.

Sterling Limited Lifetime Warranty

Sterling Plumbing Group, Inc. ("Sterling") warrants this faucet to be free of manufacturing defects and to be drip free for as long as you own your home. Damage due to improper installation, maintenance or handling are not considered manufacturing defects and are not covered by this warranty. Labor, shipping and installation costs or other charges incidental to warranty service are to be borne by the original purchaser. This warranty is valid for the original purchaser

Sterling will, at its election, repair or replace a faucet where Sterling's inspection discloses any such defects occurring in normal residential usage.

To obtain warranty service return the defective part(s) to your cooperating retail seller or send them to our Customer Service Department, P.O. Box 427, Sheridan, AR 72150. Refer any questions to our Customer Service Department at 1-800-245-2207.

IMPLIED WARRANTIES INCLUDING THAT OF MERCHANTABILITY AND FIT-NESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY LIMITED TO ONE YEAR FROM DATE OF PURCHASE. STERLING DISCLAIMS ANY RESPON-SIBILITY FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of special, incidental or consequential damages, so these limitations or exclusions may not apply to you. This warranty gives you special legal rights. You may also have other rights which vary from state to state.

This is our exclusive written warranty.

For more information on Sterling Faucets, please call 1-800-STERLING

