

## COMPLIANCE WITH FCC REGULATIONS

This equipment has been tested and found to comply with the limits for a Radio Receiver, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio technician for help.

## SERVICE

Please refer to the instructions on the enclosed warranty card for returning your unit for service. When returning the unit, please remove batteries to prevent damage to the unit in transit and/or from possible battery leakage. We are not responsible for batteries returned with the product or for the cost of replacement.

### Distributed by:

Spectra Merchandising International, Inc.  
Chicago Industry Tech Park  
4230 North Normandy Avenue  
Chicago, IL60634, U.S.A.  
Please have model number ready, for Customer Service, call 1-800-777-5331



## AM/FM RADIO



## OWNER'S MANUAL

**KT2042**

809-2042000-010

Printed in China

## WELCOME TO THE WORLD OF HELLO KITTY

We have taken great care to make sure that your AM/FM Radio was in perfect working order when it left our factory. It has been designed to give you many years of enjoyment and trouble free operation. Read this manual before operating this unit to become familiar with its features and obtain the performance that will bring you continued enjoyment for many years.

For future reference, record the serial number in the space provided.

**Model Number:** KT2042


**Serial Number:** \_\_\_\_\_

### IMPORTANT NOTES

Avoid using or storing this unit in locations described below:

- Places exposed to direct sunlight or close to heat radiating appliances such as electric heaters.
- Dusty places.
- Places subject to constant vibration.
- Humid or moist places.

## LOCATION OF CONTROLS




- |                         |                     |
|-------------------------|---------------------|
| 1. VOLUME/POWER Control | 4. Wire Antenna     |
| 2. BAND (AM/FM) Switch  | 5. Tuning Control   |
| 3. Battery Compartment  | 6. Built-in Speaker |

## POWER SOURCE

### BATTERY OPERATION

1. Open the battery compartment by pushing the tab at the center of the cover and lift it up.
2. Insert two AA size (UM-3) batteries (not included) into the Battery Compartment following the diagram inside the compartment and replace the Battery Compartment cover.



### BATTERY PRECAUTIONS

Follow these precautions when using batteries in this device:

1. Use only the size and type of batteries specified.
2. Be sure to follow the correct polarity when installing the batteries as indicated next to the battery compartment. Reversed batteries may cause damage to the device.
3. Do not mix different types of batteries together (e.g. Alkaline and Carbon-zinc) or old batteries with fresh ones.
4. If the device is not to be used for a long period of time, remove the batteries to prevent damage or injury from possible battery leakage.
5. Do not try to recharge batteries which are not intended to be recharged; they can overheat and rupture. (Follow battery manufacturer's directions.)
6. Do not dispose of batteries to fire, batteries may explode or leak.

## OPERATION

### LISTENING TO THE RADIO

<b>1</b>	<b>2</b>	<b>3</b>
Rotate the VOLUME/POWER control clockwise to turn the power on.	Slide the BAND switch ① to select AM or FM. Rotate the TUNING control ② to tune in a station.	Rotate the VOLUME/POWER control to adjust the volume. Rotate the VOLUME/POWER control counter-clockwise until a click is heard to turn the unit off.

### Antennas

FM: Extend the antenna wire for better FM reception.  
AM: Turn the unit for better AM reception.