



## REMOTE CONTROL



### Inserting batteries


1. Open the battery cover as shown below.



2. Insert batteries into the remote control.




3. Close the battery cover as shown below.



### QWERTY Side - Front



### QWERTY Side - Back



# Quick Setup Guide

### How to pair the remote control



Press the Pointer button to pair the remote control.

### How to use the zoom in/out gestures



1. Press and hold the Gesture button for 2 seconds.
2. While holding the Gesture button, draw a circle in a clockwise direction to zoom in or counter-clockwise direction to zoom out. (This feature is only available in the Chrome browser.)

For more information

Refer to manual or go to [www.lg.com](http://www.lg.com)

# CONNECTIONS

# IR BLASTER SETTINGS

# HOME

The Setup Wizard will begin when you turn on the TV for the first time. You can connect the LG remote to a cable/satellite box by following the steps shown below.



- 1 Connecting to a network**  
Connect the TV to a router with a LAN cable. Or connect with Wi-Fi by accessing Network Setup in the initial Setup Wizard. For seamless internet streaming LG recommends a stable 4Mbps broadband speed and 1.5Mbps as a minimum.
- 2 Connecting the cable/satellite box**  
Use the appropriate cable that is provided from your cable or satellite provider to connect the cable/satellite box to the TV. Place the IR Blaster near the remote sensor.
- 3 Connect other devices**  
Connect the Audio amplifier and other devices to the TV if necessary.



You can see the screen shown above to start the set up routine. There, select (A) to access the IR blaster settings.



Select the correct port that is connected to the cable/satellite box. You should see a TV signal once the correct port is selected.



Select your connected device type.



Select your lineup provider from the list. A TV signal should appear once you pick the correct provider.



Select the correct cable/satellite box manufacturer.



Check if the IR Blaster is firmly plugged into the IR Blaster port and is placed near the remote sensor of your device as shown above.



The TV will generate a test code to see if the remote is properly working with the cable/satellite box. Press the CH up and down to check the code. If the Channel doesn't change, then select [No, try next code] to repeat this step until you find right code.




The TV will generate a list of premium channels. Select [Yes] if you receive any of these channels.



Your channels are analyzed. If it is finished successfully. Select [Next].



Your LG remote is now set up to your cable/satellite box. You can now access the channel guide or connected set-top box with your remote.



\* Please note that you need to have a Google account to setup the TV. It makes it more convenient to use Google's services and automatically restores your personal apps after a software update.

# PRIMETIME QUICK GUIDE

The new quick guide makes it easy to find live TV content well organized in categories (Movies, Drama, Sports, etc.). Press the guide key anytime to bring up the best live TV content to you immediately.

