TIGERIE.

MODEL: 70-138



INTRODUCTION

GIGA PETS ARE THE CUTEST PETS YET, AND NOW BARBIE HAS A GIGA OF HER
VERY OWN: PRECIOUS KITTY! IT'S UP TO YOU AND BARBIE TO KEEP
YOUR KITTY AS HEALTHY AND HAPPY AS IT CAN BE ARE YOU READY?

CONGRATULATIONS!

YOU ARE THE PROUD NEW OWNER OF A GIGA PET, THE TAKE-IT-ANYWHERE INTERACTIVE PET! YOUR NEW GIGA PET IS GOING TO NEED LOTS OF ATTENTION TO GROW UP HEALTHY AND HAPPY. THE HEALTHIER AND HAPPIER YOUR PET IS, THE HIGHER YOUR SCORE WILL BE! THESE INSTRUCTIONS WILL HELP YOU ON YOUR WAY.

STARTING THE GAME
TO START YOUR GAME, PULL THE PLASTIC TAB FROM THE BACK OF YOUR GIGA
PET. THE PLASTIC TAB IS NOT PART OF THE TOY AND SHOULD BE THROWN AWAY.
ONCE YOU TURN YOUR GIGA PET ON, IT SHOULD STAY ON. YOU NEVER NEED TO TURN YOUR GIGA PET OFF

SETTING THE CLOCK
IT IS VERY IMPORTANT THAT YOU SET THE CLOCK ON YOUR GIGA PET FOR
THE CORRECT TIME YOUR GIGA PET EATS, PLAYS, AND SLEEPS ACCORDING TO
A NATURAL SCHOOLE IF YOU DON'T SET THE TIME CORRECTLY, YOUR GIGA PET
MAY GET CONFUSED-- YOU PON'T WANT YOUR PET TO SLEEP ALL DAY AND KEEP
YOU AWAKE ALL NIGHT! WHEN YOU FIRST START THE GAME, YOUR GIGA PET
WILL BE IN GLOCK MODE, HERPS HOW TO SET THE CLOCK:

- D THE ROUR WILL BE FLASHING. PRESS LEFT/RIGHT TO ADJUST THE HOUR. WHEN THE CORRECT HOUR IS SET, PRESS ENTER.

  2) THE MINUTES WILL BE FLASHING. PRESS LEFT/RIGHT TO ADJUST THE MINUTES. WHEN THE CORRECT MINUTES ARE SET, PRESS ENTER.

  3) THE CLOCK IS NOW SET, AND YOU WILL AUTOMATICALLY ENTER NAME MODE.

- NAMING YOUR GIGA PET

  1) A RASHING BAR WILL APPEAR UNDER THE SPACE FOR EACH LETTER.

  2) PRESS LEFT/RIGHT TO SEARCH THROUGH THE ALPHAPET.

  3) PRESS ENTER TO SELECT A LETTER AND MOVE TO THE NEXT SPACE IN THE PET'S NAME YOU MAY USE UP TO 12 LETTERS.

  4) PRESS ENTER TWICE TO ACCEPT THE CURRENT NAME AND RETURN TO GAME

TURNING OFF THE SOUND

- D PRESS MODE TO ENTER CLOCK MODE.

  2) PRESS LEFT TO TURN THE SOUND OFF-- THE SOUND IGON & WILL
- 3) PRESS RIGHT TO TURN THE SOUND ON-- THE SOUND ICON 4 WILL PRESS MODE AGAIN TO RETURN TO GAME MODE

IAPPY BIRTHDAY!

WHEN YOU ENTER GAME MODE FOR THE RRST TIME, YOU WILL SEE THE ARRIVAL OF YOUR NEW GIGA PET! EVERY GIGA PET ARRIVES IN A DIFFERENT KIND OF WAY. PRECIOUS KITTY COMES TO YOU IN A LITTLE BASIZET HOW CUTE!

RETURNING TO CLOCK MODE ONCE THE GAME BEGINS IN GAME MODE, YOU CAN RETURN TO CLOCK MODE BY PRESSING MODE UNTIL THE CLOCK APPEARS.

- U) IF YOU WISH TO ADJUST THE CLOCK WILL START FLASHING.

  2) AFTER YOU SET THE TIME, YOUR PET'S NAME WILL APPEAR. PRESS ENTER TO ADJUST THE NAME.
- 3) TO RETURN TO GAME MODE, PRESS MODE UNTIL YOUR PET APPEARS

THE GAME SCREEN
THE GAME SCREEN IS YOUR PET'S "HOME." YOU WILL SEE THE PET MOVE AROUND THE SCREEN AND GO ABOUT ITS DAILY ROUTINE, JUST LIKE A REAL PET.

PRESS THE **LEFT/RIGHT** KEYS TO SELECT THE DIFFERENT **ICONS** AROUND THE OUTSIDE OF THE SCREEN. THESE KONS REPRESENT ALL OF THE DIFFERENT ACTIVITIES THAT ALLOW YOU TO INTERACT WITH YOUR PET.

JUST LIKE A REAL PET, YOUR **GIGA PET** NEEDS YOU IN ORDER TO GROW UP HAPPY AND HEALTHY. AT VARIOUS TIMES, YOUR PET WILL REQUIRE A CERTAIN KIND

OF ATTENTION FROM YOU. YOUR PET WILL MAKE NOISE AND THE **ALERT** ICON ?! WILL LIGHT UP.

NOW YOU'VE GOT TO RIGURE OUT WHAT YOUR PET NEEDS! IF YOUR PET IS HUNGRY, FEED IT. IF YOUR PET IS LONELY, PLAY WITH IT. IF YOUR PET IS DIRTY, GIVE IT A BATH. THERE ARE MANY DIFFERENT WAYS FOR YOU TO INTERACT WITH YOUR PET. THE TRICK IS TO RIGURE OUT WHAT YOUR PET NEEDS FROM YOU! USE THE LEFT REIGHT KEYS TO MOVE TO THE ACTIVITY YOU WANT, AND PRESS ENTER. HERE ARE THE ACTIVITIES:



FEED W WHEN YOU SELECT THIS ACTIVITY, YOU WILL BE GIVEN A CHOKE OF FOODS FOR YOUR PET. USE THE ELEFT OR PRESENT KIND OF PET LIKES PHER HEATHY FOOD OR TREATS, EVERY KIND OF PET LIKES PHEFERENT KINDS OF FOOD, YOUR PRECEIOUS RETTY NEEDS A BOWL OF HEALTHY FOOD TO GROW, BUT IF YOUR KITTY IS VERY GOOD, YOU CAN FEED IT A TREAT-- A TASTY RSH NIBBLE!

YOU CAN SEE HOW HUNGRY YOUR PET IS BY CHECKING

TIS HUNGER AO ON THE SCORE SCREEN TO A DIO MEANS YOUR PET IS BY CHECKING TO MEANS YOUR PET HAS A FOLL TUMANY-- AND A O MEANS YOUR PET HAS A A DIO IT MAY REFUSE TO EAT, AND IF IT HAS A O MAY REFUSE TO DO ANYTHING BLSE UNTIL YOU FEED IT!

YOUR PET WILL ALWAYS EAT TREATS, EVEN WHEN IT'S FULL! THOSE TREATS TASTE SO GOOD, IT'S IMPOSSIBLE TO SAY NO! BUT BE CAREFUL, TOO MANY TREATS WILL MAKE YOUR KITTY FAT,



SLEEP 🐿 SELECT THIS KON TO TURN OUT THE LIGHT WHEN YOUR PET WANTS TO SLEEP. YOUR PET LIKES TO TAKE NAPS DURING THE DAY. IF YOU TURN OUT THE LIGHT FOR IT, IT WILL HAPPILY GO TO SLEEP, A NIGHT, YOUR PET WILL BE VERY TIRED, AND JUST FALL ASLEEP RIGHT ON THE ROOR. IF YOU WANT YOUR PET TO HAVE GOOD DREAMS, TURN OUT THE LIGHT AT NIGHT, TOO.



SOMETIMES IT'S HARD TO TELL WHEN YOUR PET NEEDS TO SLEEP, IF YOU TRY EVERYTHING BLSE-- FEEING, PLAYING, OR CLEANING-- AND YOUR PET STILL SEEMS UPSET, MAYBE IT'S TIME FOR A LITTLE NAP.

PLAY
TO KEEP YOUR BARBIE PRECIOUS KITTY
HEALTHY AND HAPPY, YOU SHOULD PLAY WITH IT OFTEN.
WHEN YOU SELECT THIS ACTIVITY, YOUR PET WILL PLAY A GAME WITH YOU.

TO PLAY WITH YOUR **PRECIOUS KITTY**, WATCH FOR THE BUTTERRY AND HELP YOUR KITTY POUNCE ON IT! QUICKLY PRESS THE **LEFT** OR **RIGHT** KEY IN THE DIRECTION OF THE BUTTERRY TO POUNCE ON IT. YOUR KITTY WILL LET THE BUTTERRY GO EACH TIME, SO YOU CAN PLAY AS OFTEN AS YOU LIKE!



IF YOUR PETS HEALTH DROPS, YOU CAN ALWAYS TRY A VISIT TO THE DOCTOR. BUT BE CAREFUL! THERE'S ONLY SO MUCH THE DOCTOR CAN DO, AND YOUR PET DOES NOT LIKE TO GO. BARBIE SAYS, "ONLY ONE TRIP TO THE DOCTOR EACH DAY, MORE THAN THAT WILL MAKE VIVID DET (INHADOW).

YOUR PET UNHAPPY!" CLEANING ?

CLEANING TO SOMETIMES YOUR PET WILL LEAVE DROPPINGS, AND YOU MUST CLEAN THEM UP, IF THERE ARE PROPPINGS ON SCREEN, SELECT CLEANING TO CLEAR THEM AWAY. IF THERE ARE NO PROPPINGS ON SCREEN, YOU CAN SELECT THIS ACTIVITY TO GIVE YOUR PET A THOROUGH, ALL OVER CLEANING. IF YOU WANT YOUR PET TO STAY HEALTHY, DON'T LEAVE DROPPINGS ON THE SCREEN, AND DON'T FORGET TO GIVE YOUR PET A BATH AT LEAST ONCE A DAY.



Score 🥏 CHOOSE THIS ICON TO CHECK ON YOUR PET'S PROGRESS. USE THE LEFT/RIGHT TO DISPLAY SCREENS SHOWING YOUR PETS AGE AND WEIGHT, HEALTH O AND HAPPINESS (B), HUNGER (A) AND DISCIPLINE (B), AND TOTAL SCORE

YOUR PET'S AGE INCREASES BY I EVERY DAY, WHAT SEEMS LIKE A DAY TO YOU IS ACTUALLY ONE COMPLETE YEAR TO YOUR GIGA PET! A GIGA PET REACHES ADULT AGE AT ABOUT 3 DAYS, AND OLD AGE AT I4 DAYS. A GIGA PET MORE THAN I4 DAYS OLD IS VERY OLD INDEED!

YOUR PET'S **WEIGHT** WILL VARY PEPENDING ON YOUR PET'S AGE, DIET, AND EXERCISE. TOO MANY TREATS AND TOO MUCH SLEEP WILL MAKE YOUR PET FAT AND LAZY, MAKE SURE YOUR PET GETS ENOUGH EXERCISE.

HEALTH O. NAPPINESS @. NUNGER ... AND DISCIPLINE ... AND DISCIPLINE ... RANGE FROM 0 (BAD) TO 100 (GOOD) AND HELP YOU PETERMINE WHAT YOUR PET NEBS. IF ANY OF THESE FALLS BELOW 20, YOU SHOULD TAKE CARE OF YOUR

THE FINAL STATISTIC, SCORE, IS AN INDICATION OF HOW WELL YOU ARE DOING. THE HIGHER YOUR SCORE, THE BETTER YOU ARE DOING, YOUR SCORE IS AN AVERAGE OF HEALTH, HAPPINESS, HUNGER, AND DISCIPLINE.

TRAINING YOUR PET CAN DO ALL SORTS OF INTERESTING THINGS. TRAINING YOUR PET TO PERFORM TRICKS ON COMMAND IS VERY ENTERTAINING! SELECT THE TRAIN KON AND PRESS ENTER. THE WORD REWARD WILL APPEAR, BUT DON'T REWARD YOUR PET YET! FIRST, PRESS ELET OR RIGHT UNTIL THE WORD TRICK APPEARS. NOW PRESS ENTER AGAIN.

A LIST OF TRICKS WILL APPEAR. YOU CAN PRESS **LEFT** OR **RIGHT** TO SEARCH THROUGH ALL THE TRICKS YOUR PET CAN LEARN, WHEN YOU SEE THE TRICK YOU WANT TO TEACH YOUR PET, PRESS **ENTER**, YOUR PET WILL TRY ITS PEST TO DO THE TRICK YOU ASKED FOR.

IF YOUR PET DOES NOT GET THE TRICK RIGHT, TRY AGAIN! IF YOUR PET DOES THE TRICK CORRECTLY, PRESS ENTER AGAIN. THE WORD REWARD SHOULD APPEAR. PRESS ENTER AGAIN TO REWARD YOUR PET WITH A TREAT, NOW YOUR PET KNOWS THIS TRICK, CONGRATULATIONS!

IF YOU WANT YOUR PET TO PERFORM ITS TRICK AT YOUR COMMAND, SELECT THE TRAINING KON AGAIN. NOW PRESS ETHER THE LEFT OR RIGHT KEY UNTIL THE WORD TRICK APPEARS. PRESS ENTER. NOW PRESS EFF/RIGHT UNTIL THE TRICK YOU WANT APPEARS ON THE SCREEN, AND PRESS ENTER.



SELECT THIS ACTIVITY TO DISCIPLINE YOUR PET, YOUR PET DOES NOT LIKE TO BE DISCIPLINE, SO YOU SHOULD ONLY DISCIPLINE YOUR PET IF ITS **DISCIPLINE** FALLS PELOW 20, PONT SELECT THIS ACTIVITY TOO OFTEN, OR YOUR PET HAILS PELOW TOO OFTEN, OR YOUR PET WILL BECOME UNHAPPY AND UNHEALTHY!

WHEN THIS KON LIGHTS UP, IT MEANS YOUR PET NEEDS SOMETHING, USE THE SCORE OF ACTIVITY TO TRY TO RIGURE OUT WHAT YOUR PET NEEDS: FOOD? TIME? DISCIPLINE? SLEEP? PLAY



MEETING YOUR PETS NEEDS IF YOU TRY TO SELECT AN ACTIVITY THAT YOUR PET

POES NOT WANT TO PO, IT
MAY REFUSE TRY SELECTING A DIFFERENT ACTIVITY UNTIL
YOU REGURE OUT WHAT YOUR PET NEEDS

game over

THE GAME IS OVER WHEN YOUR PET DIES. YOUR PET CAN DIE FROM BAD HEALTH OR OLD AGE IF YOUR PET DIES FROM BAD HEALTH, YOU SHOULD RESTART THE GAME AND TRY AGAIN, TAKING CARE TO PAY CLOSE ATTENTION TO YOUR PET'S NEEDS.

YOUR PET CAN ALSO DIE FROM OLD AGE. YOUR PET IS DESIGNED TO LIVE FOR ABOUT 2 WEEKS. HOWEVER, IF YOU TAKE VERY GOOD CARE OF YOUR PET, IT MAY
LIVE LONGER, KEEP YOUR PET'S HEALTH ABOVE 73 AND IT MAY LIVE INDEPRNITELY.

20

WHEN THE GAME IS OVER, YOU WILL SEE YOUR PET TURN INTO AN ANGEL, YOU CAN PRESS MODE TO SEE YOUR HINAL SCORE, AND PRESS MODE AGAIN TO SEE THE ANGEL AGAIN.

RESTARTING THE GAME
IF YOUR PET DIES AND BECOMES AN ANGEL PRESS EMTER
TO RESTART THE GAME IF YOU JUST WISH TO START
OVER FROM THE BEGINNING, PRESS THE RESET BUTTON
LOCATED ON THE BACK OF YOUR GAME.

INSERTING THE BATTERIES
TO ACTIVATE YOUR GIGA PETS GAME, PULL THE PLASTIC TAN FROM BACK OF GAME

TO INSERT THE BATTERIES, REMOVE THE BATTERY COMPARTMENT COVER AT THE BACK OF THE GAME. (TO PENOVE COVER, UNISCREW THE COVER, THEN PUSH THE COVER IN THE DIRECTION OF THE ARROW).

INSERT TWO LOV "LR44" OR "GISA" BUTTON CELL BATTERIES (BATTERY INCLUDED), MAKING SURE TO AUGN "" AND "-" AS SHOWN.

CAUTION: BATTERY SHOULD BE REPLACED BY ADULT.
NOT SUITABLE FOR CHILDREN UNDER 30 MONTHS, MAY CONTAIN SMALL PARTS.

NOT SUITABLE FOR CHILDREN UNDER 90 MONTHS, MAY CONTAIN SMALL PARTS.

\*\*TO ENSURE PROPER FUNCTION\*\*:

\*\*PO NOT MAX OR AND RAW BATTERIES.\*\*

\*\*PO NOT MAX OR AND RAW BATTERIES.\*\*

\*\*PO NOT MAX ALICALINE, STANDARD OR RECHARGEBLE BATTERIES.\*\*

\*\*PATTERY INSTALLATION SHOULD BE DONE BY ADULT.\*\*

\*\*NON-RECHARGEBALE BATTERIES ARE NOT TO BECHARGEB.\*\*

\*\*RECHARGEBALE BATTERIES ARE ONLY TO BE CHARGEB UNDER ADULT SUPERVISION (IF REMOVEBALD.\*\*

\*\*PRECHARGEBALE BATTERIES ARE ONLY TO BE CHARGEB UNDER ADULT SUPERVISION (IF REMOVEBALD.\*\*

\*\*PRECHARGEBALE BATTERIES ARE ONLY TO BE CHARGEB UNDER ADULT SUPERVISION (IF REMOVEBALD.\*\*

\*\*PATTERIES OF THE SAME OR EQUINALIST TYPE AS RECOMMENDED ARE TO BE USED.\*\*

\*\*PATTERIES ARE TO BE REMOVED FROM THE TOY.\*\*

\*\*EDULAUSTED BATTERIES ARE TO BE REMOVED FROM THE TOY.\*\*

\*\*THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCOTED.\*\*

DEFECT OR DAMAGE.

IF A PART OF YOUR CAME IS DAMAGED OR SOMETHING HAS BEEN LIFT OUT, DO N'O'T RETURNY
THE CAME TO THE STORE. THE STORE DOESN'T HAVE REPLACEMENT PART.

INSTEAD, WRITE TO US AT:

TIGGE ELECTRONIC TOYS REPAIR CENTRE 180 WCQDLANDS PARKWAY, VERNON HILLS, HLINOIS BOODI, U.S.A.

IN YOUR NOTE MENTION THE NAME OF YOUR GAME, YOUR GAME'S MOREL NUMBER, AND TELL US BRIEFLY WHAT THE PROPLEM IS, ALSO INCLUDE SALES SUP, DATE, PLACE OF PURCHASE AND PRICE PAID. WE WILL DO OUR BEST TO HELP.

## 90-day limited warranty

TIGER ELECTRONICS, INC. (TIGER) WARRANTS TO THE ORIGINAL CONSUMER PURCHASER OF THIS PRODUCT THAT THE PRODUCT WILL BE FREE FROM PEFECTS IN MATERIALS OR WORKMANSHIP FOR 70 PAYS FROM THE PATE OF ORIGINAL PURCHASE. THIS WARRANTY POES NOT COVER PAMAGES RESULTING FROM ACCIPENT, NEGLIGENCE, IMPROPER SERVICE OR USE OR OTHER CAUSES NOT ARISING OUT OF PEFECTS IN MATERIALS OR WORKMANSHIP.

puring this 70-pay warranty period, the product will either be repaired or replaced (at tiger's option) without charge to the purchaser, when returned with proof of the pate of purchase to EITHER THE DEALER OR TO TIGER.

PRODUCT RETURNED TO TIGER WITHOUT PROOF OF THE DATE OF PURCHASE OR AFTER THE 70-DAY WARRANTY PERIOD HAS EXPIRED, BUT PRIOR TO ONE YEAR FROM THE ORIGINAL DATE OF PURCHASE, WILL BE REPAIRED OR REPLACED (AT TIGER'S OPTION) FOR A SERVICE FEE OF USPA-00. PAYMENTS MUST BE BY CHECK OR MONEY ORDER PAYABLE TO TIGER ELECTRONICS, INC

THE FOREGOING STATES THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY FOR ANY BREACH OF WARRANTY WITH RESPECT TO THE PROPUCT.

ALL PRODUCT RETURNED MUST BE SHIPPED PREPAID AND INSURED FOR LOSS OR DAMAGE TO

TIGER ELECTRONICS, INC. REPAIR DEPT. 780 WOODLANDS PARKWAY VERNON HILLS, ILLINOIS BOODL

THE PRODUCT SHOULD BE CAREFULLY PACKED IN THE ORIGINAL BOX OR OTHER PACKING MATERIALS SUFFICIENT TO AVOID DAMAGE DURING SHIPMENT, INCLUDE A COMPLETE WRITTEN DESCRIPTION OF THE DEFECT, A CHECK IF PRODUCT IS BEYOND THE 70-DAY WARRANTY PERIOD, AND YOUR PRINTED NAME, APDRESS AND TELEPHONE NUMBER

AND TELEPHONE NUMBER.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AND NO OTHER REPRESENTATIONS OR CLAIMS OF ANY NATURE SHALL BE BINDING ON OR OBLIGATE TIGER IN ANY WAY. ANY IMPLIED WARRANTIES APPLICABLE TO THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE NUMBER YOU DAY PERIOD DESCRIBED ABOVE. IN NO EVENT WILL TIGER BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM POSSESSION, USE, OR MALFUNCTION OF THIS TIGER PRODUCT.

SOME STATES DO NOT ALLOW LIMITATIONS AS TO HOW LONG AN IMPLIED WARRANTY LASTS AMO/OR EXCLUSIONS OR LIMITATIONS OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AMO/OR EXCLUSIONS OF LIABILITY MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AMD YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE

BARBIE is a trademark owned by and used under license from Mattel, Inc. © 1997 Mattel, Inc. All Rights Reserved.