



LENNOX HEARTH PRODUCTS

750.184M REV. B 05/2006	H5051	DASK-LSM40-2	Dual Arch Screen Kit, LSM40-2
	H5052	SK-LSM40-2	Classic Screen Kit, LSM40-2
	H5053	ASK-LSM40-2	Arch Screen Kit, LSM40-2
	H5054	DASK-LSM45-2	Dual Arch Screen Kit, LSM45-2
	H5055	SK-LSM45-2	Classic Screen Kit, LSM45-2
	H5056	ASK-LSM45-2	Arch Screen Kit, LSM45-2

**INSTALLATION INSTRUCTIONS FOR DECORATIVE SCREEN KITS FOR USE WITH MONTEBELLO®  
DAVE LENNOX SIGNATURE COLLECTION MODELS LSM40-2 & LSM45-2 DIRECT VENT GAS FIREPLACES**

Kit Contents:	Tools Required:
1 Ea. Screen Assembly 2 Ea. Bottom Legs 2 Ea. Long Screws 2 Ea. Short Screws 2 Ea. Long Spacers	2 Ea. Short Spacers 4 Ea. Nuts 2 Ea. L- Brackets 1 Ea. Instruction Sheet
	7/32" Allen Wrench 7/16" Nut Driver




Figure 1

**GENERAL INFORMATION**

These optional decorative freestanding firescreen panels are designed to enhance the beauty of the fireplace and helps prevent direct human contact with the hot glass surface.

A chain is also provided for additional safety. When attached to the fireplace, it helps prevent the screen from tipping.

**WARNINGS**

Hot! Do not touch! These decorative screen panels are NOT heat guards. The glass behind the screens will be hot during operation and will retain heat for a while after shutting off the appliance. Severe burns may result. Carefully supervise children in the same room as appliance.

- As with any similar heating appliance, surfaces of the frame, the door and appliance can become very hot.

**INSTALLATION INSTRUCTIONS**

- Step 1** Using a 7/32" allen wrench and 7/16" nut driver, loosely assemble the parts as shown in **Figure 1** and **Figure 2** (do not tighten yet).
- Step 2** Adjust the L-bracket to the height needed for this installation (slot allows up to 1 inch vertical adjustment). When you are satisfied that the screen will stand stable in front of the fireplace, then tighten the nuts on both sides.





Figure 2 - Assemble Legs & L-Brackets to Screen

**Step 3** Place the assembled freestanding screen in front of the fireplace in a close proximity to the glass door assembly.

**Step 4** Hook the chain to the unit by dropping the free end of chain in the slot provided on the left side of modesty panel. Check to be sure that the chain is attached securely. See **Figure 3**.



**Note:** The “no-tip” chain feature provided with this screen is designed to work with the following Montebello™ models:

- H4793 LSM40MN-2
- H4794 LSM40MP-2
- H4797 LSM40EN-2
- H4795 LSM45MN-2
- H4796 LSM45MP-2
- H4798 LSM45EN-2

If you have a previously released model of the Montebello™, there will not be a slot on the fireplace for the chain to attach to.

NOTE: DIAGRAMS & ILLUSTRATIONS ARE NOT TO SCALE.

Lennox Hearth Products reserves the right to make changes at any time, without notice, in design, materials, specifications, prices and the discontinuance of colors, styles and products. Consult your local distributor for fireplace code information.



**HEARTH PRODUCTS**

1110 West Taft Avenue  
Orange, CA 92865