


Model 200G Paint Sprayer Exploded Diagram



(Dwg. TP2145)

Model 200G Paint Sprayer Parts List

Item	Part Description	Part Number	Item	Part Description	Part Number
1	Fluid Needle Kit	200G-K20	7	Trigger Kit	200G-K80
2	Fluid Nozzle	200G-30	8	Cup Lid	200G-90
3	Air Cap	200G-40	9	Cup	200G-100
4	Valve Kit	200G-K50	10	Accessories Kit	200G-200
5	Pattern Controller	200G-60	11	Filter	200G-1727
6	Air Controller	200G-70			

Parts and Maintenance

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Tool repair and maintenance should only be carried out by an authorized Service Center.

Refer all communications to the nearest **Ingersoll Rand** Office or Distributor.

Related Documentation

For additional information refer to:

Product Safety Information Manual 16576563.

Product Information Manual 47083068.

Maintenance Information Manual 16577645.

Manuals can be downloaded from www.ingersollrandproducts.com.