

TCM-21DV

SONY

Pressman® Portable Cassette Recorder

▲ **ALL-IN-ONE KIT (INCLUDES TWO "AA" BATTERIES, CASSETTE, EXTERNAL MICROPHONE, CARRYING POUCH)**

- **DOUBLE RECORDING TIME**
- **VOICE OPERATED RECORDING (VOR)**
- **CLEAR VOICE™ SOUND SYSTEM**
- **MIC JACK**
- **L/R MONAURAL EARPHONE JACK**
- **ONE TOUCH RECORDING**
- **LED (BATTERY LEVEL)**
- **FRONT SPEAKER**
- **AUTOMATIC SHUT-OFF**
- **CUE/REVIEW FUNCTION**
- **PAUSE SWITCH**
- **STOP PAUSE RELEASE FUNCTION**
- **HINGED BATTERY LID**
- **DC-IN JACK**
- **HAND STRAP ATTACHED**

▲ **STEP-UP FEATURE** ▶ **NEW FEATURE**



PRESSMAN

features

- **DOUBLE RECORDING TIME** gives you the option of recording on a standard cassette at either normal speed or half the normal speed, for extended recording or dictation sessions
- **VOICE OPERATED RECORDING (VOR)** activates the recorder only when audible sound is present, conserving tape and eliminating soundless passages
- **CLEAR VOICE™** sound system enhances voice quality during recording and playback for greater clarity
- **MIC JACK** allows connection of an external microphone
- **L/R MONAURAL EARPHONE JACK** provides sound in both ears when using an optional stereo headset
- **ONE TOUCH RECORDING** for simplified, quick play/record operation
- **LED (BATTERY LEVEL)** provides visible indication of battery power remaining
- **FRONT SPEAKER** has excellent sound quality to monitor tape playback
- **AUTOMATIC SHUT-OFF** at end of tape reduces mechanical wear and conserves battery power
- **CUE/REVIEW FUNCTION** provides sound during fast Forward and Rewind modes to help find specific passages
- **PAUSE SWITCH** allows for instant on-the-spot editing
- **STOP PAUSE RELEASE FUNCTION** automatically turns off the Pause switch whenever the Stop button is pressed, to prevent loss of recording
- **HINGED BATTERY LID** helps prevent accidental loss
- **DC-IN JACK** for two-way power operation, using replaceable batteries or optional AC power adaptor
- **HAND STRAP ATTACHED** affords very convenient one-hand use

specifications

RECORDING SYSTEM: 2 track, 1 channel (standard cassette)

FREQUENCY RESPONSE: 250 - 6300Hz

SPEAKER: 1 7/16" (36mm) dia.

POWER REQUIREMENTS: DC 3V with "AA" x 2 batteries

BATTERY LIFE: Rec/Play: Approx. 11 hours with Sony alkaline batteries

COLOR: Black

DIMENSIONS (WHD): 3 1/2 x 4 3/8 x 1 1/2 (91 x 111 x 37mm)

WEIGHT: 9.6 oz (273g)

SUPPLIED ACCESSORIES: "AA" Batteries x 2, Standard Cassette, External Mic, Carrying Pouch, Hand Strap

OPTIONAL ACCESSORIES: AC-E30HG AC Adaptor

©2002 Sony Electronics Inc.

Reproduction in whole or in part without written permission is prohibited. All rights reserved. Sony, Clear Voice and Pressman are trademarks of Sony.

Features and specifications are subject to change without notice. Non-metric weights and measures are approximate.