

CLASSÉ AUDIO

CA-150

POWER AMPLIFIER

CA-150

OWNER'S MANUAL

## *CLASSÉ DESIGN PHILOSOPHY*

---

### 1. REPEATED LISTENING DESIGN SESSIONS:

Fine tuning of sound by exchanging and mixing of parts (transistors, capacitors, wiring, PCB boards etc.), and adjusting many specific operating voltages within proper engineering ranges, producing an overall sonic recipe giving the most natural harmonic realism of music typical of instruments in a live performance.

### 2. UPGRADABLE SINGLE CIRCUIT DESIGNS:

All Classé products (all preamps and all amps) share exactly the same circuit (excluding moving coil and moving magnet phono circuits). This means all amplifiers and all high level circuits of the preamps are the same. The same circuit is tailored to different power levels etc. Differences between less expensive models and more expensive models are parts quality and compliment, power supply extravagance and the amount of filtering etc., as well as features and packaging.

This means that for years Classé has been constantly fine tuning and upgrading this circuit and its application, thus reaching a very high level of understanding and musical achievement which benefits all models - least expensive, most expensive, preamps and amplifiers alike.

### 3. EXTREME LONG LIFE IN REAL WORLD CONDITIONS:

Choosing the best attainable quality parts and materials combined with the advantages of the two above-mentioned areas provides Classé owners with years of proven trouble free reliability and musical enjoyment.

CA-150  
OWNER'S MANUAL

TABLE OF CONTENTS

UNPACKING & SET-UP.....	4
GENERAL CONNECTIONS.....	5
CONNECTIONS FOR REGULAR OR BALANCED INPUTS.....	7
WARRANTY .....	10
WARRANTY REGISTRATION .....	12
SPECIFICATIONS .....	13

## ***UNPACKING & SET-UP***

---

Your CLASSE **CA-150** power amplifier is packed in high density, semi-rigid foam placed in a special cardboard box. To remove the unit, open and spread all the top flaps of the box and by its sides, lift out the entire unit and put it on a large flat surface. Take it out of the plastic bag and inspect the unit for any concealed damage. Apart from this owner's manual, please ensure the following has also been included:

- 1) Detachable linecord
- 2) Allen key for top plate

Please report any damage or missing parts to your dealer as soon as possible.

Place the **CA-150** at or near its final set-up position, allowing 8 inches at the rear for tightening the speaker output connectors. For optimum sonic performance, we recommend the optional CLASSE REFERENCE A.C. LINECORD. Consult your dealer regarding this accessory.

The power transformer in the **CA-150** is located at the front-center of the unit. Ideally, a few feet should separate this area from components which potentially could pick up hum. These include preamplifiers, turntables, and interconnect cables. In terms of providing adequate airspace for cooling, a good rule of thumb is to allow 6 inches above and 3 inches on each side of the unit.

Check the Serial Number sticker on the back of the unit for the correct operating voltage.

The **CA-150** has only one fuse, the rating of which should be as follows:

<b><u>LINE VOLTAGE</u></b>	<b><u>FUSE RATING</u></b>
100 or 120 V.A.C.	6 AMP FAST BLOW 125 or 250 volts
220 or 240 V.A.C.	4 AMP FAST BLOW 250 volts

## ***GENERAL CONNECTIONS***

---

### **A.C. LINE**

Insert the linecord into the A.C. receptacle on the rear of the unit.

---

### **CAUTION: SAFETY INSTRUCTIONS**

DISCONNECT AC LINE CABLE WHILE MAKING ALL CONNECTIONS. "FLOATING THE GROUND", OR DEFEATING THE GROUND ON A 3-PRONG LINECORD MAY CREATE A SHOCK HAZARD. CONNECT ALL INTERCONNECT CABLES BETWEEN THE ELECTRONICS BEFORE CONNECTING THE A.C. LINECORDS TO THE WALL OUTLETS. THIS WILL REDUCE THE POTENTIAL SHOCK HAZARD. SEE ALSO THE 10 WARRANTY SECTION OF THIS OWNER'S MANUAL.

---

### **STEREO**

Input and output connectors are clearly marked on the back of the amplifier. Left/Right connections are oriented from the front of the unit. Stereo output connections are marked above the connectors. Switch stereo/mono switch to [UP] position. (Units preset at factory for STEREO.)

Use only high quality interconnect and loudspeaker cables, and make all connections tight. If the input plugs are loose, remove them and pinch down the ground leaves slightly with pliers. Observe correct phasing of the loudspeaker connections, and tighten.

## MONO

Please read through the previous Stereo section for general notes on securing good connections, and safety tips. If the unit has been previously used in stereo, make sure it is OFF, and remove all connections, including the AC line cable. Make sure the STEREO/MONO switch is switched to the MONO position [DOWN].

The MONO "Input" is the "left channel input", as marked. The unused right channel input is automatically disconnected. MONO output connections are marked below the connectors.

Repeat the above MONO settings and connections on the second **CA-150** to be used for the other channel.

Please remember that the negative output connection of a bridged amplifier is NOT a ground. Do not use a "common ground" or switchbox set-up. Do not use with electronic crossovers which have a common ground.

## REMOTE CONTROL: (OPTIONAL)

With a simple connection from the receiver box to the remote jack at the back of the amplifier, (see Figure 1) the power amplifier can be turned ON/OFF from a distance (or from another room).

## ***CONNECTIONS FOR REGULAR OR BALANCED INPUTS:***

---

The CLASSÉ **CA-150** power amplifier is equipped with both regular and balanced inputs. Either one may be used SEPARATELY BUT NOT SIMULTANEOUSLY. The balanced inputs must be connected to a preamplifier which has balanced main outputs, and balanced interconnects with "XLR" connectors are also required. Regardless of the amplifier inputs used, stereo or mono operation is still possible on the **CA-150**.

### **REGULAR INPUTS**

Switch the REGULAR/BALANCED switch to the position marked "REGULAR" [UP]. (The amplifier is factory set for regular use.) Connect the regular interconnects to the RCA input jacks on the rear panels of the **CA-150**. The balanced connectors are automatically disabled.

### **BALANCED INPUTS**

Switch the REGULAR/BALANCED switch to the position marked "BALANCED" [DOWN]. A balanced preamplifier and balanced interconnects are also required. For use with balanced preamplifiers other than Classé, the wiring of the 3-pin XLR connectors must be matched to that of the CLASSÉ **CA-150** which are wired as follows:

PIN 1: GROUND

PIN 2: POSITIVE (NON-INVERTED) SIGNAL

PIN 3: NEGATIVE (INVERTED) SIGNAL

If the pin configuration of the preamplifier differs from above, the balanced interconnects must be modified to accommodate the different preamp.

Having confirmed the correct connections, plug the XLR connectors of the balanced interconnects into the locking XLR connectors on the rear panel of the **CA-150**. (To remove the connectors, press the tab above the connector.)

### MONO OPERATION

As stated before, regular or balanced inputs can be used in stereo or mono. Connect a single interconnect, either regular or balanced, to the left channel input of each amplifier. See the "Mono" section above for complete details.




Fig 1: CA-150 rear view

***CLASSÉ CA-150 LIMITED FACTORY WARRANTY*** (North America only).

---

**IMPORTANT:** Warranty registration, and a copy of the “Authorized Dealer Bill of Sale” must be received at the Classé Audio factory (address: pages 12) within thirty (30) days of purchase by the original retail purchaser in order to validate these warranty.

**FIVE YEAR WARRANTY (all parties)**

Classé Audio, Inc. warrants this product to be free from defects in materials and workmanship to the original retail purchaser for a period of FIVE YEARS from date of manufacture, provided that any claim in virtue of this warranty be made in writing within such period.

This warranty may not be transferred to any subsequent owner unless the following conditions have been met: the product will be re-sold through an authorized Classé Audio dealer, who will be responsible for contacting Classé with all specifics (name of new owner, address of new owner, serial number of the product) of the subsequent sale. If the subsequent owner has purchased the product through an authorized Classé Audio dealer, and all of the above conditions have been met, the new owner will have the benefit of any remaining coverage from the original five year period.

In order to initiate service of any kind, it is necessary to OBTAIN PRIOR FACTORY AUTHORIZATION, AND SHIP THE UNIT PREPAID TO THE CLASSÉ FACTORY. Units coming from the USA should be shipped directly to our CUSTOMS BROKER: STARBER FRITZ INTERNATIONAL C/O CLASSÉ AUDIO, HIGHWAY 114 EAST, NORTON, VERMONT 05907 USA.

The warranty shall be void and of no effect in the event of any of the following:

- 1) Operation not in accordance with this manual.
- 2) Accident, abuse, tampering, or unauthorized modification, as determined by Classé Audio Inc.
- 3) Removal, defacing, or falsifying the serial number plate.
- 4) Shipping without the complete factory packaging;
- 5) Transfer or sale of this amplifier by the original owner;
- 6) Non-compliance with any of the other conditions hereof.

CLASSÉ AUDIO INC. SHALL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING FROM OR RELATING TO THE SET-UP, OPERATION, FAILURE, TROUBLESHOOTING, OR REPAIR OF THE AMPLIFIER AND/OR ANY OTHER EQUIPMENT USED THEREWITH.

THIS WARRANTY, ALL CLAIMS MADE IN VIRTUE HEREOF, AND ALL ISSUES RELATING TO ANY SUCH CLAIM SHALL BE GOVERNED BY THE LAWS OF THE PROVINCE OF QUÉBEC.

***WARRANTY REGISTRATION***

---

You must fill out and return the form below, along with a copy of the authorized dealer bill of sale, to the factory within thirty (30) days of purchase. This will allow us to provide expedient service, information regarding updates and new products, and validate the Classé warranty.

|||||  
|||

**CA-150** SERIAL NUMBER \_\_\_\_\_ PURCHASE  
DATE \_\_\_\_\_ AUTHORIZED  
DEALER \_\_\_\_\_  
PURCHASER'S NAME \_\_\_\_\_  
STREET ADDRESS \_\_\_\_\_  
CITY \_\_\_\_\_ STATE/PROV. \_\_\_\_\_  
COUNTRY \_\_\_\_\_ ZIP/POSTAL CODE \_\_\_\_\_  
I BECAME AWARE OF THIS PRODUCT BY: \_\_\_\_\_  
(DEALER, MAGAZINE, FRIEND, ETC.)

|||||  
|||

SEND TO: CLASSÉ AUDIO INC.  
Product Registration  
5070 François Cusson  
Lachine, Quebec, Canada  
H8T 1B3

# **CLASSÉ CA-150**

## **STEREO BALANCED POWER AMPLIFIER**

### **SPECIFICATIONS SHEET**

#### **CA-150 FEATURES:**


150 watts stereo, 325 watts mono, high current, sleek curved chassis with large dual heat sinks at rear, both regular and balanced inputs externally switchable, sculpted one piece handles. Available in both Satin Black and Soft Shadow Silver finishes.

#### **CA-150 SPECIFICATIONS:**

Frequency Response:	20 Hz to 20 KHz +/- 0.1 dB	
Sensitivity:	1.15 Volts in for rated output	
Input Impedance:	75 Kohms	
Output Impedance:	0.021 Ohm	
Gain:	29.02 db	
S/N Ratio:	132 dBR	
THD+N:	0.006%	
Rated output:	Stereo	Mono
8 Ohms:	150	500 Watts
4 Ohms:	300	900 Watts
Dimensions:	Gross:	22" x 19 1/2" x 10 1/2"
	Net:	19" x 16 1/2" x 7"
Weight:	Gross:	55 lbs.

Net:

47 lbs.



**Notice to all Classé Product owners:**

Thank you for your purchase of a Classé Audio component.

All of us at Classé have taken extreme care to ensure that your purchase will become a prized investment. We are proud to inform you that all Classé Audio components have been officially approved for the European Community CE mark.

This means that your Classé product has been subjected to the most rigorous manufacturing and safety tests in the world, and have proven to meet or exceed all European Community CE requirements for unit to unit consistency and consumer safety.

All of us at Classé Audio wish you many years of musical enjoyment.

**As of July 18, 1996, Classé Audio has been granted Certificate No: C401CLA1.MGS, which indicates CE approval for all models of the Classé Audio product line.**