

90-day limited warranty

For complete warranty, visit
www.dynexproducts.com.

© 2009 Dynex. DYNEX and the DYNEX logo are trademarks of Best Buy Enterprise Services, Inc. Other brands and product names are trademarks or registered trademarks of their respective holders. Specifications and features are subject to change without notice or obligation.


ENGLISH 09-0406

DYNEX

DX-VIDLT LED Camcorder Light

To install the batteries:

- 1 Make sure that the power switch is in the **OFF** position.
- 2 Press in on the battery door tab, then remove the battery door.



QUICK SETUP GUIDE

- 3 Insert two AAA batteries (not included) into the battery compartment. Make sure that the + and - symbols on the batteries match the + and - symbols in the battery compartment.
- 4 Snap the battery door back into place.

To install the light:

- Mount the light on your camcorder by sliding it into place on the accessory shoe and tightening the mounting screw.

If your camcorder does not have an accessory shoe, the Dynex Video Bracket (model DX-VIDBKT) can provide a mounting platform.

To use the light:

- Turn the light on by sliding the power switch to the **MED** or **HI** position. You can then take pictures or video. To conserve batteries, turn the light off when you are finished.

Specifications:

LEDs: 10 ~ 3700K (+/- 500K) color balanced

Power:

2 AAA Alkaline/ NiMH batteries

Run Time:

60-90 minutes depending on battery usage and type

Dimmer: Off / Medium / High

Weight: 1.9 oz (with batteries)

Size: 2.35" x 1.75" x 1"