

USB 2.0 4 PORT HUB RHUB210

User Manual

## System Requirements

PC

- Windows® 98SE, 2000, ME, XP
- USB 2.0 Compliant System

Mac

- Mac OS 8.6 to 9.x®, Mac OS X or greater
- USB 2.0 Compliant System

## **Features**

- USB 1.1 and 2.0 Compliant
- Fully Backward Compatible with USB 1.1
- Up to 480 Mbps (Megabits-Per-Second) Data Transfer Rate
- 40 Times Faster Than The USB 1.1
- Four Independent, Fully Functional, Downstream Ports
- Hot Swappable Plug-n-Play
- 4 USB Type A Ports
- PC Power Management
- Power Adapter: DC 5V/2A

## Hardware Installation

- 1. Plug the Hi-Speed USB 2.0 Cable (type B end) into the upstream port on the Hi-Speed USB 2.0 Hub.
- 2. Plug the Hi-Speed USB 2.0 Cable (type A end) into your computers Hi-Speed USB 2.0 Port.
  - Important Note: The Hub must be connected to a USB 2.0-compliant host in order to function in high-speed Mode (480Mbps data rate). If connected to a USB 1.1-compliant host, the Hub will operate only in low or full-speed mode (1.5/12Mbps)
- 3. Upon powering up your computer, the USB 2.0 hub will be recognized by the computer's operating system
- 4. Once complete, you are ready to plug all peripheral devices into your new USB 2.0 pocket hub

## **Specification**

Ports	4 Type A USB ports
Output voltage(per port)	+5V DC
Output voltage(per port)	500mA (max.)
Operating Temperature	5~40 oC
Storage Temperature	-20-60 oC
Humidity	0~80% RH

Thank you for purchasing a quality Rosewill Product.

Please register your product at: www.rosewill.com for complete warranty information and future support for your product.